

TOSHIBA

FILE NO. 810-200550

SERVICE MANUAL



DVD RECORDER & VCR

D-VR15SB

D-VR25SB

D-VR35SB

D-VR30SF

D-VR30SG



Issued in Japan., June., 2005 ©



CONTENTS

1. Precautions
 2. Product Specification
 3. Software Update
 4. Alignment and Adjustments
 5. Disassembly and Reassembly
 6. Troubleshooting
 7. Exploded View and Parts List
 8. Electrical Parts List
 9. Block Diagrams
 10. Wiring Diagram
 11. PCB Diagrams
 12. Schematic Diagrams
 13. Operating Instructions
 14. Circuit Operating Descriptions
-

MEMO

1. Precautions

1-1 Safety Precautions

1) Before returning an instrument to the customer, always make a safety check of the entire instrument, including, but not limited to, the following items:

(1) Be sure that no built-in protective devices are defective or have been defeated during servicing.
(1) Protective shields are provided to protect both the technician and the customer. Correctly replace all missing protective shields, including any removed for servicing convenience.
(2) When reinstalling the chassis and/or other assembly in the cabinet, be sure to put back in place all protective devices, including, but not limited to, nonmetallic control knobs, insulating fish papers, adjustment and compartment covers/shields, and isolation resistor/capacitor networks. Do not operate this instrument or permit it to be operated without all protective devices correctly installed and functioning.

(2) Be sure that there are no cabinet openings through which adults or children might be able to insert their fingers and contact a hazardous voltage. Such openings include, but are not limited to, excessively wide cabinet ventilation slots, and an improperly fitted and/or incorrectly secured cabinet back cover.

(3) Leakage Current Hot Check-With the instrument completely reassembled, plug the AC line cord directly into a 120V AC outlet. (Do not use an isolation transformer during this test.) Use a leakage current tester or a metering system that complies with American National Standards institute (ANSI) C101.1 Leakage Current for Appliances and Underwriters Laboratories (UL) 1270 (40.7). With the instrument's AC switch first in the ON position and then in the OFF position, measure from a known earth ground (metal water pipe, conduit, etc.) to all exposed metal parts of the instrument (antennas, handle brackets, metal cabinets, screw-heads, metallic overlays, control shafts, etc.), especially any exposed metal parts that offer an electrical return path to the chassis. Any current measured must not exceed 0.5mA. Reverse the instrument power cord plug in the outlet and repeat the test. See Fig. 1-1.

Any measurements not within the limits specified herein indicate a potential shock hazard that must be eliminated before returning the instrument to the customer.




Fig. 1-1 AC Leakage Test

(4) Insulation Resistance Test Cold Check-(1) Unplug the power supply cord and connect a jumper wire between the two prongs of the plug. (2) Turn on the power switch of the instrument. (3) Measure the resistance with an ohmmeter between the jumpered AC plug and all exposed metallic cabinet parts on the instrument, such as screwheads, antenna, control shafts, handle brackets, etc. When an exposed metallic part has a return path to the chassis, the reading should be between 1 and 5.2 megohm. When there is no return path to the chassis, the reading must be infinite. If the reading is not within the limits specified, there is the possibility of a shock hazard, and the instrument must be repaired and rechecked before it is returned to the customer. See Fig. 1-2.






Fig. 1-2 Insulation Resistance Test

- 2) Read and comply with all caution and safety related notes on or inside the cabinet, or on the chassis.
- 3) Design Alteration Warning-Do not alter or add to the mechanical or electrical design of this instrument. Design alterations and additions, including but not limited to, circuit modifications and the addition of items such as auxiliary audio output connections, might alter the safety characteristics of this instrument and create a hazard to the user. Any design alterations or additions will make you, the servicer, responsible for personal injury or property damage resulting therefrom.
- 4) Observe original lead dress. Take extra care to assure correct lead dress in the following areas:
(1) near sharp edges, (2) near thermally hot parts (be sure that leads and components do not touch thermally hot parts), (3) the AC supply, (4) high voltage, and (5) antenna wiring. Always inspect in all areas for pinched, out-of-place, or frayed wiring. Do not change spacing between a component and the printed-circuit board. Check the AC power cord for damage.
- 5) Components, parts, and/or wiring that appear to have overheated or that are otherwise damaged should be replaced with components, parts and/or wiring that meet original specifications. Additionally, determine the cause of overheating and/or damage and, if necessary, take corrective action to remove any potential safety hazard.
- 6) Product Safety Notice-Some electrical and mechanical parts have special safety-related characteristics which are often not evident from visual inspection, nor can the protection they give necessarily be obtained by replacing them with components rated for higher voltage, wattage, etc. Parts that have special safety characteristics are identified by shading, an () or a () on schematics and parts lists. Use of a substitute replacement that does not have the same safety characteristics as the recommended replacement part might create shock, fire and/or other hazards. Product safety is under review continuously and new instructions are issued whenever appropriate.

1-2 Servicing Precautions

CAUTION : Before servicing units covered by this service manual and its supplements, read and follow the Safety Precautions section of this manual.

Note : If unforeseen circumstances create conflict between the following servicing precautions and any of the safety precautions, always follow the safety precautions. Remember: Safety First.

1-2-1 General Servicing Precautions

- (1) a. Always unplug the instrument's AC power cord from the AC power source before (1) re-moving or reinstalling any component, circuit board, module or any other instrument assembly, (2) disconnecting any instrument electrical plug or other electrical connection, (3) connecting a test substitute in parallel with an electrolytic capacitor in the instrument.
- b. Do not defeat any plug/socket B+ voltage interlocks with which instruments covered by this service manual might be equipped.
- c. Do not apply AC power to this instrument and /or any of its electrical assemblies unless all solid-state device heat sinks are correctly installed.
- d. Always connect a test instrument's ground lead to the instrument chassis ground before connecting the test instrument positive lead. Always remove the test instrument ground lead last.

Note : Refer to the Safety Precautions section ground lead last.

- (2) The service precautions are indicated or printed on the cabinet, chassis or components. When servicing, follow the printed or indicated service precautions and service materials.
- (3) The components used in the unit have a specified flame resistance and dielectric strength. When replacing components, use components which have the same ratings. Components identified by shading, by (⚡) or by (⚡) in the circuit diagram are important for safety or for the characteristics of the unit. Always replace them with the exact replacement components.

- (4) An insulation tube or tape is sometimes used and some components are raised above the printed wiring board for safety. The internal wiring is sometimes clamped to prevent contact with heating components. Install such elements as they were.

- (5) After servicing, always check that the removed screws, components, and wiring have been installed correctly and that the portion around the serviced part has not been damaged and so on. Further, check the insulation between the blades of the attachment plug and accessible conductive parts.

1-2-2 Insulation Checking Procedure

Disconnect the attachment plug from the AC outlet and turn the power ON. Connect the insulation resistance meter (500V) to the blades of the attachment plug. The insulation resistance between each blade of the attachment plug and accessible conductive parts(see note) should be more than 1 Megohm.

Note : Accessible conductive parts include metal panels, input terminals, earphone jacks, etc.

1-3 ESD Precautions

Electrostatically Sensitive Devices (ESD)

Some semiconductor (solid state) devices can be damaged easily by static electricity.

Such components commonly are called Electrostatically Sensitive Devices(ESD). Examples of typical ESD devices are integrated circuits and some field-effect transistors and semiconductor chip components. The following techniques should be used to help reduce the incidence of component damage caused by static electricity.

- (1) Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, obtain and wear a commercially available discharging wrist strap device, which should be removed for potential shock reasons prior to applying power to the unit under test.
- (2) After removing an electrical assembly equipped with ESD devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.
- (3) Use only a grounded-tip soldering iron to solder or unsolder ESD devices.
- (4) Use only an anti-static solder removal devices. Some solder removal devices not classified as "anti-static" can generate electrical charges sufficient to damage ESD devices.
- (5) Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ESD devices.
- (6) Do not remove a replacement ESD device from its protective package until immediately before your are ready to install it.(Most replacement ESD devices are packaged with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive materials).

- (7) Immediately before removing the protective materials from the leads of a replacement ESD device, touch the protective material to the chassis or circuit assembly into which the device will be installed.

CAUTION : Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.

- (8) Minimize bodily motions when handling unpackaged replacement ESD devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity sufficient to damage an ESD device).

1-4 Handling the optical pick-up

The laser diode in the optical pick up may suffer electrostatic breakdown because of potential static electricity from clothing and your body.

The following method is recommended.

- (1) Place a conductive sheet on the work bench (The black sheet used for wrapping repair parts.)
 - (2) Place the set on the conductive sheet so that the chassis is grounded to the sheet.
 - (3) Place your hands on the conductive sheet (This gives them the same ground as the sheet.)
 - (4) Remove the optical pick up block
 - (5) Perform work on top of the conductive sheet. Be careful not to let your clothes or any other static sources to touch the unit.
- ◆ Be sure to put on a wrist strap grounded to the sheet.
 - ◆ Be sure to lay a conductive sheet made of copper etc. Which is grounded to the table.




Fig.1-3

- (6) Short the short terminal on the PCB, which is inside the Pick-Up ASS'Y, before replacing the Pick-Up. (The short terminal is shorted when the Pick-Up Ass'y is being lifted or moved.)
- (7) After replacing the Pick-up, open the short terminal on the PCB.

MEMO

2. Product Specification

2-1 Product Specification

General	Power requirements	AC 220-240V, 50Hz
	Power consumption	45Watts
	Weight	4.8Kg
	Dimensions	430(W) x 321(D) x 84(H)
	Operating temp	+5°C to + 35°C
	Other conditions	Keep level when operating.Less than 75%operating humidity
Input	Video input(Rear)	Euro Scart socket :1.0Vp-p(unbalanced)75 Ω
	Audio input(Rear)	Euro Scart socket :-8dBm,47Kohm unbalanced
	Front input	RCA jack,S-Video In
Output	RF out	UHF 21-69 (Initial CH60)
	Audio (DVD, VCR)	RCA jack,Euro Scart socket,Audio L/R
	Audio (DVD, Only)	Digital audio out COAXIAL
	Video (DVD, VCR)	RCA jack,Euro Scart socket (Composite,RGB), S-Video Out,Component Out
VCR	Tape format	VHS type video tape
	Colour system	PAL
	Tuning System	I
	Video S/N	Above 43dB (standard recording)
	Resolution	Above 240 lines (standard recording)
	Audio S/N	Above 68dB (Hi-Fi), 39dB(Mono)
	Audio frequency characteristics	20Hz-20KHz(Hi-Fi)
DVD	Picture compression format	MPEG-II
	Audio compression format	Dolby AC-3 256kbps
	Recording Qallity	XP(8Mbps), SP(4Mbps), LP(2Mbps), EP(1.2/0.8Mbps)
	Video S/N	Ratio Min.50dB at standard recording
	Audio S/N	Ratio Min. 75dB
	Audio frequency characteristics	20Hz ~ 20KHz

MEMO

3. Software Update

3-1 Drive Firmware Update

3-1-1 Introduction

Toshiba will often support software update to improve the performance of DVD Recorder&VCR to the latest status.

3-1-2 How to make an update disc

NOTE

- Recommended Application Programme
 - Nero Burning / Easy CD Creator ..etc
- Option
 - Name : SDM2224
 - Extension name : "*.REC"
 - Multisession : No Multisession
 - File name lenght : Max. of 11 = 8 + 3
 - Format : Mode 1
 - Character set : ISO 9660 or Joliet Format
 - CD Close & Disc at once
 - Label : RAMBO

WARNING

It is very important : please read the below notice before updating your unit.

The following events may interrupt the update process and MAY RESULT IN PERMANENT DAMAGE TO THE UNIT WHILE UPDATING

- ① The power cord unplugged.
- ② Power Outage.
- ③ Dirt or Scratches on the disc.
- ④ Opening a disc tray during processing.

3-1-3 How to update software

- 1) Press **OPEN/CLOSE** to open the disc tray.
 - 2) Insert the update CD-R disc with the software update, label facing up.
 - 3) Press **OPEN/CLOSE** to close the disc tray.
- * It takes about 1~2 minites before the message below appears.




Fig. 3-2

* If you don't see the message above, try another disc. Generally, this is caused by disc quality and by disc creating problem.

- 4) Press the **OK** button on the remote control (Fig. 3-1).




Fig.3-3

- 5) It takes about 1~2 minutes to complete the update.
The message below will be displayed in the screen after update is completed and the tray will open automatically.




Fig. 3-4

- 6) After removing the update disc, turn off the unit with power button.
And turn on the unit with power button and then the tray will close.
The drive firmware is now completed.




Fig. 3-1 Remote Controller

After checking old and new version, select "Yes" or "No" with "◀" or "▶" on the remote controller.

* The Version is indicated by "XX.X modelname"

You will see "LOAD" on FLT Display.



Fig. 3-5

3-2 Flash Update

3-2-1 Introduction

Toshiba will often support software update to improve the performance of DVD Recorder&VCR to the latest status.

3-2-2 How to make an update disc

NOTE

- Recommended Application Program
 - Nero Burning / Easy CD Creator ..etc
- Option
 - Only single session
 - CD close & disc at once
 - ISO 9660 or joliet format
 - Extension name : "*.RUF"
- In order to increase disc playability, add a dummy file (over 100MB) together with the latest program.
(The dummy file can be used any kind of file except MP3, AVI, MPEG, MPG, divx, LPCM, AAC, Ogg file which can be played in the unit and we recommend to use a file with extension name as "*.dmy", which can be changed from original one.)

WARNING

It is very important : please read the below notice before updating your unit.

The following events may interrupt the update process and MAY RESULT IN PERMANENT DAMAGE TO THE UNIT WHILE UPDATING

- ① The power cord unplugged.
- ② Power Outage.
- ③ Dirt or Scratches on the disc.
- ④ Opening a disc tray during processing.

3-2-3 How to update software

- 1) Press **OPEN/CLOSE** to open the disc tray.
- 2) Insert the update CD-R disc with the software update, label facing up.
- 3) Press **OPEN/CLOSE** to close the disc tray.




Fig. 3-7

* If you don't see the message above, try another disc.
Generally, this is caused by disc quality and by disc creating problem.

- 4) Press the **OK** button on the remote control (Fig. 3-6).



Fig. 3-8

- 5) It takes about 5 minutes to complete the update.
The message below will be displayed in the screen after update is completed and the tray will open automatically.




Fig. 3-9

- 6) After removing the update disc, turn off the unit with power button.
And turn on the unit with power button and then the tray will close.
The Flash update is now completed.




Fig. 3-6 Remote Controller

After checking old and new version, select "Yes" or "No" with "◀" or "▶" on the remote controller.

* The Version is indicated by "YYMMDD.xx modelname"

* If the message to the left isn't displayed after 10minutes and the unit is no longer functioning properly, contact a **TOSHIBA** authorized service center.

4. Alignment and Adjustments

4-1 VCR Adjustment

4-1-1 Reference

- 1) X-Point (Tracking center) adjustment, "Head switching adjustment" and "NVRAM option setting" can be adjusted with remote control.
- 2) When replacing the Main PCB Micom (IC601) and NVRAM (IC603 ; EEPROM) be sure to adjust the "Head switching adjustment" and "NVRAM option setting".
- 3) When replacing the cylinder ass'y, be sure to adjust the "X-Point" and "Head switching adjustment".
- 4) How to adjust.
 - Intermittently short-circuit the Test Point on Main PCB with pincers to the adjustment mode.
 - If the corresponding adjustment button is pressed, the adjustment is performed automatically.
 - When the adjustment is completed, be sure to turn the power off.

4-1-1(a) Location of adjustment button of remote control

- ✎ X-Point (Tracking Center) Adjustment ; ① + ⑤
- ✎ NVRAM Option Setting ; ① + ④
- ✎ Head Switching Adjustment ; ① + ①




Fig. 4-1

4-1-1(b) TEST location for adjustment mode setting




Fig. 4-2 VCR Main PCB (Top View)

4-1-2 Head Switching Point Adjustment

- 1) Playback the alignment tape.
- 2) Intermittently short-circuit the two Test Points on VCR Main PCB while setting the adjustment mode. (See Fig. 4-2)
- 3) Press the “1, 0” buttons; remote control adjustment operates automatically. (See Fig. 4-1)

4-1-3 NVRAM Option Setting

- 1) NVRAM Option is adjusted in the factory.
- 2) In case Main PCB Micom (IC601) and NVRAM (IC603 ; EEPROM) are replaced, be sure to set the corresponding option number of the required model. (If the option is not set, the unit will not operate.)

- 1) Intermittently short-circuit the two Test Points on VCR Main PCB. (See Fig. 4-2)
- 2) Press the “1, 4” button on the remote control. The option setting appears. (See Fig. 4-3)
- 3) Select the option number (See table 4-1) of corresponding model with “◀, ▶, ▲, ▼” buttons on the remote control.
- 4) After selecting the option number is completed, press the “▲” button of remote control.
(If “▲” button is pressed, the selected number is changescolor. ; See Fig. 4-4)
- 5) Press the “ENTER” button of remote control again to store the option number.
- 6) Turn the Power off.




Fig. 4-3




Fig. 4-4

<Table 4-1 NVRAM Option Table>

MODEL	OPTION NUMBERS
D-VR15-S-TB	4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 18, 25, 26, 32, 34, 38, 40, 41, 45, 47, 50, 58, 61, 63, 64, 65, 66, 68, 69, 70, 72
D-VR25-S-TB	4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 18, 25, 26, 32, 34, 38, 40, 41, 45, 47, 50, 58, 61, 62, 63, 64, 65, 66, 68, 69, 70, 72
D-VR35-S-TB	3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 18, 25, 26, 32, 34, 38, 40, 41, 45, 47, 50, 58, 61, 63, 64, 65, 66, 68, 69, 70, 72
D-VR30-S-TF	4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 18, 20, 21, 26, 32, 33, 34, 35, 36, 38, 40, 44, 45, 47, 50, 58, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 72
D-VR30-S-TG	4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 18, 32, 34, 36, 38, 40, 42, 44, 45, 47, 50, 58, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 72

4-2 VCR Mechanical Adjustment

4-2-1 Tape Transport System and Adjustment Locations

The tape transport system has been adjusted precisely in the factory. Alignment is not necessary except for the following :

- 1) Noise observed on the screen.
- 2) Tape damage.
- 3) Parts replacement in the tape transport system.

Lower flange height of tape guide is used as the reference for the transport adjustment.

To maintain the height of the tape guide and prevent damage, do not apply excessive force onto the main base.




Fig. 4-5 Location of Tape Transport Adjustment




Fig. 4-6 Tape Travel Diagram

4-2-2 Tape Transport System Adjustment

When parts are replaced, perform the required adjustments by referring to procedures for the tape transport system. If there are any changes to the tape path, first run a T-120 tape and make sure excessive tape wrinkle does not occur at the tape guides.

- ◆ If tape wrinkle is observed at the guide roller S, T, turn the guide roller S, T until wrinkle disappears.
- ◆ If the tape wrinkle is still observed at the tape guide, perform the tilt adjustment of the ACE head.

(1) ACE Head Assembly Adjustment

a. ACE HEAD HEIGHT ADJUSTMENT

- 1) Run the alignment tape (Color bar) in the playback mode.
- 2) Observe surface of the audio head using a dental mirror.
- 3) Turn screw (C) clockwise or counterclockwise until the gap of lower tape edge and the lower edge of the control head is about 0.25mm. (Refer to Fig. 4-7 and 4-8)




Fig. 4-7 Location of ACE Head Adjustment Screw




Fig. 4-8 ACE Head Height Adjustment

b. ACE HEAD TILT ADJUSTMENT

- 1) Playback a blank tape and observe the position of the tape at the lower flange of tape guide.
- 2) Confirm that there is no curl or wrinkle at the lower flange of tape guide as shown in Fig. 4-9 (B).
- 3) If a curl or wrinkle of the tape occurs, slightly turn the screw (A) tilt adjust on the ACE head ass'y.
- 4) Reconfirm the ACE head height.




Fig. 4-9 Tape Guide Check

c. AUDIO AZIMUTH ADJUSTMENT

- 1) Load alignment tape (Mono scope) and playback the 7KHz signal.
- 2) Connect channel-1 scope probe to audio output.
- 3) Adjust screw (B) to achieve maximum audio level. (See Fig. 4-7)

d. ACE HEAD POSITION (X-POINT) ADJUSTMENT

- 1) Playback the alignment tape (Color bar)
- 2) Intermittently short-circuit the two Test Points on VCR Main PCB. (See Fig. 4-2)
- 3) Press the "0, 5" remote control buttons, then adjustment is operates automatically. (See Fig. 4-1)
- 4) Connect the CH-1 probe to "Envelope" the CH-2 probe to "H'D switching pulse" and then trigger to CH-1.
- 5) Insert the (-) driver into the X-Point adjustment hole and adjust it so that envelope waveform is maximum.

Test point :	TP2 (Audio Output)
	TP3 (Envelope)
	TP4 (H'D S/W -Trigger)
	TP5 (Control Pulse)




Fig. 4-10 Location of Test point (VCR Main PCB-Top View)

(2) Linearity adjustment (Guide roller S, T adjustment)

- 1) Playback the Mono Scope alignment tape (SP mode).
- 2) Observe the video envelope signal on an oscilloscope (triggered by the video switching pulse).
- 3) Make sure the video envelope waveform (at its minimum) meets the specification shown in Fig. 4-11.

If it does not, adjust as follows :

Note :

a=Maximum output of the video RF envelope.

b=Minimum output of the video RF envelope at the entrance side.

c=Minimum output of the video RF envelope at the center point.

d=Maximum output of the video RF envelope at the exit side.

- 4) If the section A in Fig. 4-12 does not meet the specification, adjust the guide roller S up or down.
- 5) If the section B in Fig. 4-12 does not meet the specification, adjust the guide roller T up or down.




Fig. 4-11 Envelope Waveform Adjustment





Fig. 4-12 Adjustment Points

- 6) Play back the Mono Scope alignment tape (SP mode).
- 7) Connect an oscilloscope CH-1 to the "Envelope" and CH-2 to the "H'D SW Pulse" for triggering.
- 8) Turn the guide roller heads with a flat head () driver to obtain a flat video RF envelope as shown in Fig. 4-13.




Fig. 4-13 Guide Roller S, T Height Adjustment

(3) Check Transitional Operation from RPS to Play

Check transition from RPS mode to play mode : Using a pre-recorded SP tape, make sure the entry side of envelope comes to an appropriate steady state within 3 seconds (as shown in Fig. 4-14).

If the envelope waveform does not reach specified peak-to-peak amplitude within 3 seconds, adjust as follows :

- 1) Make sure there is no gap between the supply roller lower flange and the tape.
If there is a gap, adjust the supply guide roller again.
- 2) Change operation mode from the RPS to the play mode (again) and make sure the entry side of envelope rises within 3 seconds.




Fig. 4-14 Video Envelope Rising when Operation mode Changes from RPS to Play Mode

(4) Envelope Check

- 1) Make recordings on T-120 (E-120) and T-160 (E-180) tape.
Make sure the playback output envelope meets the specification as shown in Fig. 4-15.
- 2) Play back a self recorded tape (recording made on the unit using with T-120 (E-120)).
The video envelope should meet the specification as shown in Fig. 4-15.
In SP mode, (A) should equal (B).
If the head gap is wide, upper cylinder should be checked.




Fig. 4-15 Envelope Input and Output Level

(5) Tape Wrinkle Check

- 1) Run the T-160 (E-180) tape in the playback, FPS, RPS and Pause modes and observe tape wrinkle at each guide.
- 2) If excessive tape wrinkle is observed, perform the following adjustments in Playback mode :
 - ◆ Tape wrinkle at the guide roller S, T section : Linearity adjustment.
 - ◆ Tape wrinkle at tape guide flange : ACE head assembly coarse adjustment.

4-2-3 Reel Torque

- 1) The rotation of the capstan motor causes the holder clutch ass'y to rotate through the belt pulley.
- 2) The spring wrap PLAY/REV of holder clutch ass'y drives the disk reel S, T through gear idler by rotation of gear center ass'y.
- 3) Brake is operated by slider cam at FF/REW mode.
- 4) Transportation of accurate driving force is done by gears. (Gear Center Ass'y)

Note : If the spec. does not meet the followings specifications, replace the holder clutch ass'y and then recheck.

<Table 4-2>

MODE	TORQUE g/cm	GAUGE
PB	42 ± 11	Cassette Torquemeter
RPS	145 ± 30	Cassette Torquemeter

5. Disassembly and Reassembly

5-1 Cabinet and PCB

5-1-1 Cabinet Top Removal




Fig. 5-1 Cabinet Top Removal

5-1-2 Ass'y Bottom Cover Removal




Fig. 5-2 Ass'y Bottom Cover Removal

5-1-3 Ass'y Front Panel Removal




Fig. 5-3 Ass'y Front Panel Removal(Top View)




Fig. 5-4 Ass'y Front Panel Removal(Bottom View)

5-1-4 Chassis Removal




Fig. 5-5 Chassis Removal

5-1-5 VCR Main PCB Removal




Fig. 5-6 VCR Main PCB Removal

5-2 Circuit Board Locations




Fig. 5-7 Circuit Board Locations

5-3 VCR Deck Parts Locations

5-3-1 Top View




Fig. 5-8 Top parts Location-1

- ① GEAR FL CAM
- ② MOTOR LOADING ASS'Y
- ③ LEVER FL ARM ASS'Y
- ④ HOLDER FL CASSETTE ASS'Y
- ⑤ LEVER FL DOOR
- ⑥ SLIDER FL DRIVE




Fig. 5-9 Top Parts Location-2

- | | |
|--------------------------|-----------------------|
| ① FE HEAD | ⑧ DISK S REEL |
| ② CYLINDER ASS'Y | ⑨ LEVER S BRAKE ASS'Y |
| ③ ACE HEAD ASS'Y | ⑩ GEAR IDLE |
| ④ LEVER UNIT PINCH ASS'Y | ⑪ LEVER IDLE |
| ⑤ LEVER #9 GUIDE ASS'Y | ⑫ LEVER T BRAKE ASS'Y |
| ⑥ LEVER TENSION ASS'Y | ⑬ DISK T REEL |
| ⑦ BAND BRAKE ASS'Y | |

5-3-2 Bottom View




Fig. 5-10 Bottom Parts Location

- ❶ GEAR JOINT 1
- ❷ GEAR JOINT 2
- ❸ BRACKET GEAR
- ❹ MOTOR CAPSTAN ASS'Y
- ❺ LEVER T LOAD ASS'Y
- ❻ GEAR LOADING DRIVE
- ❼ LEVER S LOAD ASS'Y
- ❽ HOLDER CLUTCH ASS'Y
- ❾ BELT PULLEY
- ❿ SLIDER CAM

5-4 VCR Deck

5-4-1 Holder FL Cassette Ass'y Removal

- 1) Pull the Holder FL Cassette Ass'y ❶ to the eject position.
- 2) Pull the Holder FL Cassette Ass'y ❶ as grasping the Holder FL Cassette Ass'y ❶ and Lever FL Cassette-R ❷ in the same time to release hooking from Main Base until the Boss [A] of Holder FL Cassette Ass'y ❶ is taken out from the Rail [B].
- 3) Lift the Holder FL Cassette Ass'y ❶, in this time, you have to grasp the Lever FL Cassette-R ❷ continuously until the Holder FL Cassette Ass'y ❶ is taken out completely.

Note : Be sure to insert Lever FL Cassette-R ❷ in the direction of "A" to prevent separation and breakage of the Lever FL Cassette-R ❷ at disassembling and reassembling.




Fig. 5-11 Holder FL Cassette Ass'y Removal

5-4-2 Lever FL Arm Ass'y Removal

- 1) Push the hole "A" in the direction of arrow "B" use the pin.(about Dia. 2.5)
- 2) Pull out the Lever FL Arm Ass'y ❶ from the Boss of Main Base.
- 3) Remove the Lever FL Arm Ass'y ❶ in the direction of arrow "C".




Fig. 5-12 Lever FL Arm Ass'y Removal

5-4-3 Lever FL Door Removal

- 1) Release the Hook **2** and Remove the Lever FL Door **1** in the direction of arrow "A".




Fig. 5-13 Lever FL Door Removal

5-4-4 Slider FL Drive, Gear FL Cam Removal

- 1) Pull the Slider FL Drive **1** to the front direction.
- 2) Remove the Slider FL Drive **1** in the direction of arrow. (Refer to Fig. 5-13)
- 3) Remove the Gear FL cam **2**.

Note : When reinstalling be sure to reassemble Slider FL drive **1** after you insert the Boss of Lever FL ARM-R in Groove of Slider FL drive **1**.

Assembly : Align the Gear FL Cam **1** with the Gear worm wheel Post as shown drawing. (Refer to Timing point)




Fig. 5-14 Slider FL Drive Removal




Fig. 5-15 Gear FL Cam, Gear Worm

5-4-5 Gear Worm Wheel Removal

- 1) Remove the Gear Worm wheel **1**.




Fig. 5-16 Gear Worm Wheel Removal

5-4-6 Cable Flat Removal

- 1) Remove the Drum connecting part of Cable Flat **1** from Connector Wafer **2**.
- 2) Remove the Loading Motor connecting part of Cable Flat **1** from Connector Wafer **3**.




Fig. 5-17 Cable Flat Removal

5-4-7 Motor Loading Ass'y Removal

- 1) Remove the screw ❶.
- 2) Remove the Motor Loading Ass'y ❷.




Fig. 5-18 Motor Loading Ass'y Removal

5-4-8 Bracket Gear, Gear Joint 2, 1 Removal

- 1) Remove the SCREW ❶.
- 2) Remove the Bracket Gear ❷.
- 3) Remove the Gear Joint 2 ❸.
- 4) Remove the Gear Joint 1 ❹.

Assembly :

- 1) Be sure to align dot mark of Gear Joint 1 ❶ with dot mark of Gear Joint 2 ❷ as shown Fig 5-20. (Refer to Timing point1)
- 2) Confirm the Timing Point 2 of the Gear Joint 2 ❷ and Slider Cam ❸.




Fig. 5-19 Bracket Gear, Gear Joint 1,2 Removal




Fig. 5-20 Gear Joint 1,2 Assembly

5-4-9 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Removal

- 1) Remove the Belt Pulley. (Refer to Fig. 5-38)
- 2) Remove the Gear Loading Drive **1** after releasing Hook [A] in the direction arrow as shown in detail drawing.
- 3) Remove the Slider Cam **2**.
- 4) Remove the Lever Load S Ass'y **3** & Lever Load T Ass'y **4**.




Fig. 5-21 Gear Loading Drive, Slider Cam, Lever T, S Load Ass'y Removal

5-4-10 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly

- 1) When reinstalling, be sure to align dot of Lever Load T Ass'y **1** with dot of Lever Load S Ass'y **2** as shown in drawing, (Refer to Timing Point 1).
- 2) Insert the Pin A,B,C,D into the Slider Cam **3** hole,
- 3) Be sure to align dot of Lever Load T **1** and dot of Gear Loading Drive **4**, (Refer to Timing Point 2).
- 4) Aline dot of Gear Loading drive **4** with mark of Slider Cam **3** as shown in drawing(Refer to Timing Point 3).




Fig. 5-22 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly

5-4-11 Lever Pinch Drive, Lever Tension Drive Removal

- 1) Remove the Lever Pinch Drive **①**, Lever Tension Drive **②**.




Fig. 5-23 Lever Pinch Drive,
Lever Tension Drive Removal

5-4-12 Lever Tension Ass'y, Band Brake Ass'y Removal

- 1) Remove the Lever Brake S Ass'y (Refer to Fig 5-25).
- 2) Remove the Spring Tension Lever **①**.
- 3) Rotate stopper of Main Base in the direction of arrow "A".
- 4) Lift the Lever Tension Ass'y **②** & Band brake Ass'y **③**.

Note :

- 1) When replacing the Lever Tension Ass'y **②**, be sure to apply Grease on the post,
- 2) Take care not to touch stain on the felt side, and not to be folder and broken Band brake Ass'y
- 3) After Lever Tension Ass'y seated, Rotate stopper of Main Base to the Mark[B].




Fig. 5-24 Lever Tension Ass'y,
Band Brake Ass'y Removal

5-4-13 Lever Brake S, T Ass'y Removal

- 1) Release the Hook [A] and the Hook [B], [C] in the direction of arrow as shown in Fig 5-25.
- 2) Lift the Lever S, T Brake Ass'y ❶, ❷ with spring brake ❸.

Assembly :

- 1) Assemble the Lever S Brake Ass'y ❶ on the Main Base.
- 2) Assemble the Lever T Brake Ass'y ❷ with spring brake ❸.

Note : Take extreme care not to be folded and transformed Spring Brake at removing or reinstalling.




Fig. 5-25 Lever Brake S, T Ass'y Removal

5-4-14 Gear Idle Ass'y Removal

- 1) Push the Lever Idle ❶ in the direction of arrow "A", "B".
- 2) Lift the Lever Idle ❶.

Assembly :

- 1) Apply oil in two Bosses of Lever Idle ❶.
- 2) Assemble the Gear Idle ❷ with the Lever Idle ❶.

Note : When replacing the Gear Idle ❷, be sure to add oil in the boss of Lever Idle ❶.




Fig. 5-26 Gear Idle Ass'y Removal

5-4-15 Disk S, T Reel Removal

- 1) Lift the Disk S, T Reel ❶, ❷.




Fig. 5-27 Disk S, T Reel Removal

5-4-16 Holder Clutch Ass'y Removal

- 1) Remove the Washer Slit ❶.
- 2) Lift the Holder Clutch Ass'y ❷.

Note : When you reinstall Holder Clutch Ass'y

- 1) Check the condition of spring as shown in detail A.
- 2) Don't push Holder Clutch Ass'y down with excessive force Just insert Holder Clutch Ass'y into post center with dead force and Rotate it smoothly. Be sure to confirm that spring is in the slit of Gear Center Ass'y as shown in detail B.





Fig. 5-28 Holder Clutch Ass'y Removal

5-4-17 Lever Up Down Ass'y, Gear Center Ass'y Removal

- 1) Remove the 2 hooks in the direction of arrow as shown Fig. 5-28 and lift the Lever Up Down Ass'y ❶.
- 2) Lift the Gear Center Ass'y ❷.

Assembly :

- 1) Insert the Lever Up Down Ass'y ❶ in the rectangular holes on Main Base as shown in Fig 5-30.
- 2) Lift the Lever Up Down Ass'y ❶ about 35°.
- (Refer to Fig 5-30)
- 3) Insert Ring of the Gear Center Ass'y ❷ in the Guide of the Lever Up Down Ass'y ❶.
- 4) Insert the Gear Center Ass'y ❷ in the post on Main Base.
- 5) Push down the Lever Up Down Ass'y ❶ for locking of the Hook.

Note :

- 1) Take care not to separate and sentence does not mark sense.
- 2) Be sure to confirm that Ring of the Gear Center Ass'y ❷ is in the Guide of the Lever Up Down Ass'y ❶ after finishing assembly of Lever Up Down Ass'y ❶ and Gear Center Ass'y ❷.




Fig. 5-29 Lever Up Down Ass'y Removal




Fig. 5-30 Lever Up Down Ass'y Removal

4-4-18 Guide Cassette Door Removal

- 1) Lift the Hook [A].
- 2) Rotate the Guide Cassette Door ❶ in the direction of arrow.

Note : After reinstalling the Guide Cassette Door ❶ sure the Hook [A].




Fig. 5-31 Guide Cassette Door Removal

5-4-19 Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal

- 1) Lift the Unit Pinch Ass'y **①**.
- 2) Remove the Plate Joint **②** from Lever Pinch Drive.
- 3) Remove the Spring Pinch Drive **③**.

Note :

- 1) Take extreme care not to touch the grease on the Roller Pinch.
- 2) When reinstalling, be sure to apply grease on the post pinch roller.




Fig. 5-32 Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal

5-4-20 Lever #9 Guide Ass'y Removal

- 1) Remove the Spring #9 Guide **①**.
- 2) Lift the Spring #9 Guide Ass'y **②** in the direction of arrow "A".

Note :

- 1) Take extreme care not to get grease on the tape Guide Post.
- 2) After reinstalling, check the bottom side of the Post #9 Guide to the top side of Main Base.




Fig. 5-33 Lever #9 Guide Ass'y Removal

5-4-21 FE Head Removal

- 1) Remove the screw ❶.
- 2) Lift the FE Head ❷.




Fig. 5-34 FE Head Removal

5-4-22 ACE Head Removal

- 1) Pull out the FPC from connector of ACE Head Ass'y ❷.
- 2) Remove the screw ❶.
- 3) Lift the ACE Head Ass'y ❷.




Fig. 5-35 ACE Head Removal

5-4-23 Slider S, T Ass'y Removal

- 1) Move the Slider S, T Ass'y ❶, ❷ to slot, and then lift it to remove. (Refer to arrow)




Fig. 5-36 Slider S, T Ass'y Removal

5-4-24 Plate Ground Deck, Cylinder Ass'y Removal

- 1) Remove the 3 Screws ❶.
- 2) Lift the Plate Ground Deck ❷.
- 3) Lift the Cylinder Ass'y ❸.

Assembly :

- 1) Match the 3 holes in the bottom of Cylinder ass'y ❸ to the 3 holes of Main Base as attending not to drop or knock the Cylinder ass'y ❸.
- 2) Tighten the 1 Screw ❶.
- 3) Match the Plate Ground Deck ❷ to the Hole of Base Main.
- 4) Tighten the other 2 Screws ❶.

Note :

- 1) Take care not to touch the Cylinder Ass'y ❸ and the tape guide post at reinstalling.
- 2) When reinstalling, Don't push down too much on Screw Driver.




Fig. 5-37 Plate Ground Deck, Cylinder Ass'y Removal

5-4-25 Hook Capstan, Belt Pulley Removal

- 1) Remove the Hook Capstan ❶ after realeasing Hook in the direction arrow as shown in detail drawing.
- 2) Remove the Belt Pulley ❷.

Note : Take extreme care not to get grease on Belt Pulley ❷ at assembling or reassembling.




Fig. 5-38 Hook Capstan, Belt Pulley Removal

5-4-26 Motor Capstan Ass'y Removal

- 1) Remove the Damper Capstan ❶ in the direction of arrow.
- 2) Remove the 3 Screws ❷.
- 3) Remove the Motor Capstan Ass'y ❸.

Assembly :

- 1) Match the 3 holes of Motor Capstan Ass'y ❸ to the 3 holes of Main Base. Be careful not to drop or knock the Motor Capstan Ass'y ❸.
- 2) Tighten the 3 Screws ❷ in the direction of arrow as shown detail drawing.
- 3) Assemble the Damper Capstan ❶.

Note : After tightening screws, check if there is gap between the head of screws and the top side of Main Base. There should have no gap between the head of screws and the top side of Main Base. After reinstalling, adjusting the tape transport system again.




Fig. 5-39 Motor Capstan Ass'y Removal

5-4-27 Post #8 Guide Ass'y Removal

- 1) Rotate the Post #8 Guide Ass'y ❶ in the direction of arrow to lift up.




Fig. 5-40 Post #8 Guide Ass'y Removal

5-4-28 Level Head Cleaner Ass'y Removal (Optional)

- 1) Release the Hook ❶.
- 2) Lift the Lever Head Cleaner Ass'y ❷.




Fig. 5-41 Lever Head Cleaner Ass'y Removal

5-4-29 How to Eject the Cassette Tape (If the unit does not operate on condition that is inserted into housing ass'y)

- 1) Turn the Gear worm ❶ clockwise with screw driver.(Refer to arrow)
(Other method : Remove the Screw of Motor Load Ass'y, Separate the Motor Load Ass'y)




Fig. 5-42

- 2) When Slider S,T are approached in the position of unloading, rotate holder Clutch counterclockwise after inserting screw driver in the hole of frame's bottom in order to wind the unwinded tape.
(Refer to Fig.5-43)

(If you rotate Gear Worm ❶ continuously when tape is in state of unwinding, you may cause a tape contamination by grease and tape damage. Be sure to wind the unwinded tape in the state of set horizontally.)

- 3) Rotate Gear Worm ❶ clockwise using screw driver again up to the state of eject mode and then pick out the tape.(Refer to Fig.5-42)




Fig. 5-43

5-5 The table of cleaning, Lubrication and replacement time about principal parts

- 1) The replacement time of parts is not life of parts.
- 2) The table 5-1 is that the VCR Set is in normal condition (normal temperature, normal humidity).
The checking period may be changed owing to the condition of use, runtime and environmental conditions.
- 3) Life of the Cylinder Ass'y is depend on the condition of use.
- 4) See exploded view for location of each parts.

<Table 5-1>

*	Parts Name	Checking Period										Remark
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	
T A P E P A T H S Y S T E M	POST TENSION	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	- To clean the parts, use patch and alcohol (solvent).
	SLANT POST S, T	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	#8 GUIDE SHAFT	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	CAPSTAN SHAFT	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	- After cleaning, use the video tape after alcohol is gone away completely.
	#9 GUIDE POST	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	#3 GUIDE POST	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	GUIDE ROLLER S, T	Δ	Δ	Δ	O	O	O	O	O	O	O	- We recommend to use oil [EP-50] or solvent.
	CYLINDER ASS'Y	Δ	O	O	O	O	O	O	O	O	O	
	FE HEAD	Δ	Δ	Δ	O	O	O	O	O	O	O	
	ACE HEAD	Δ	O	O	O	O	O	O	O	O	O	- One or two drops of oil should be applied after cleaning with alcohol.
	PINCH ROLLER	Δ	O	O	O	O	O	O	O	O	O	
	POST REEL S, T		◆		◆		◆		◆		◆	
	SLEEVE TENSION		◆		◆		◆		◆		◆	- Periodic time of applying oil (Apply oil after cleaning) - The excessive applying oil may be the cause of malfunction.
	POST CENTER		◆		◆		◆		◆		◆	
	LEVER IDLE BOSS (2Point)		◆		◆		◆		◆		◆	
D R I V I N G S Y S T E M	CAPSTAN MOTOR PULLEY	Δ	Δ	Δ	Δ	Δ	O	O	O	O	O	
	BELT PULLEY				O	O	O	O	O	O	O	
	HOLDER CLUTCH ASS'Y	Δ	O	O	O	O	O	O	O	O	O	
	GEAR CENTER ASS'Y		O	O	O	O	O	O	O	O	O	
	GEAR IDLE (2Point)		O	O	O	O	O	O	O	O	O	
	LOADING MOTOR		O	O	O	O	O	O	O	O	O	
B R A K E S Y S T E M	BAND BRAKE ASS'Y		O	O	O	O	O	O	O	O	O	
	BRAKE T ASS'Y		O	O	O	O	O	O	O	O	O	


Δ : Cleaning


O : Check and replacement in necessary


◆ : Add Oil


MEMO


6. Troubleshooting






































































































MEMO

7. Exploded View and Parts List

7-1 Cabinet Assembly	7-2
7-2 VCR Mechanical Parts (Top Side)	7-4
7-3 VCR Mechanical Parts (Bottom Side)	7-6


7-1 Cabinet Assembly



● S.N.A. : Service Not Available


Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
A001	AK59-00028E	BY644792	REMOCON-ASSY;D-VR4S-S-TB,TSB,187.5*54,-,-	D-VR15-S-TB Only
	AK59-00028G	BY644794	REMOCON-ASSY;D-VR4D-S-TG,TSB,187.5*54,-,-	D-VR30-S-TG Only
	AK59-00028G	BY644794	REMOCON-ASSY;D-VR4D-S-TG,TSB,187.5*54,-,-	D-VR30-S-TF Only
	AK59-00028F	BY644793	REMOCON-ASSY;D-VR4P-S-TB,TSB,187.5*54,-,-	D-VR35-S-TB Only
	AK59-00028E	BY644792	REMOCON-ASSY;D-VR4S-S-TB,TSB,187.5*54,-,-	D-VR25-S-TB Only
C001	AK97-01256A	BY731758	ASSY-PANEL FRONT;HIPS94HB GRAY,D-VR15,05	D-VR15-S-TB Only
	AK97-01256D	BY731765	ASSY-PANEL FRONT;HIPS94HB GRAY,D-VR30,05	D-VR30-S-TG Only
	AK97-01256C	BY731760	ASSY-PANEL FRONT;HIPS94HB GRAY,D-VR30/TF	D-VR30-S-TF Only
	AK97-01256E	BY731761	ASSY-PANEL FRONT;HIPS94HB GRAY,D-VR35,05	D-VR35-S-TB Only
	AK97-01256B	BY731759	ASSY-PANEL FRONT;HIPS94HB GRAY,D-VR25,05	D-VR25-S-TB Only
C002	AK64-01236A	BY731757	DOOR-TRAY;D-VR4,ABS94HB,T2.0,H26.5,W5,L1	
C003	AK64-01235A	BY731753	DOOR-CASSETTE;D-VR15,ABS94HB,T2.0,H26.5,	D-VR15-S-TB Only
	AK64-01235D	BY731764	DOOR-CASSETTE;D-VR30/TG,ABS94HB,T2.0,H26	D-VR30-S-TG Only
	AK64-01235C	BY731755	DOOR-CASSETTE;D-VR30/TF,ABS94HB,T2.0,H26	D-VR30-S-TF Only
	AK64-01235E	BY731756	DOOR-CASSETTE;D-VR35,ABS94HB,T2.0,H26.5,	D-VR35-S-TB Only
	AK64-01235B	BY731754	DOOR-CASSETTE;D-VR25,ABS94HB,T2.0,H26.5,	D-VR25-S-TB Only
C011	AK64-00334A	BY734041	DOOR-SPRING;DVD-V3500,SWPB,,,,,-,-,-,-	
C012	AC61-62032A	BY730093	SPRING ETC-MASK;SV-C130,SUS,4.4,-,-,-,-,-,-,-	
C015	AK64-01073A	BY731752	CABINET-TOP;DVD-VR320,TEXTURE,T0.525,W59	
C022	AK64-01238A	BY731763	DOOR-FRONT;D-VR15,ABS94HB,T4,H30,W2.5,L1	D-VR15-S-TB Only
	AK64-01238B	BY731762	DOOR-FRONT;D-VR25,ABS94HB,T4,H30,W2.5,L1	D-VR30-S-TG Only
	AK64-01238B	BY731762	DOOR-FRONT;D-VR25,ABS94HB,T4,H30,W2.5,L1	D-VR30-S-TF Only
	AK64-01238A	BY731763	DOOR-FRONT;D-VR15,ABS94HB,T4,H30,W2.5,L1	D-VR35-S-TB Only
	AK64-01238B	BY731762	DOOR-FRONT;D-VR25,ABS94HB,T4,H30,W2.5,L1	D-VR25-S-TB Only
C452	AK39-00049A	BY634843	LEAD CONNECTOR;-,-,-,-,4,150,WHT,-,-,SMH200-	
FL593	3809-001702	BY634957	FFC CABLE-FLAT;30V,80C,290mm,40P,0.5mm,U	
H001	AK97-01211A	BY634963	ASSY-ASSY LOADER DRIVE;-,-,SV-R250,ASSY LO	
P001	AK92-00683C	BY630501	ASSY PCB-MAIN;D-VR15-S-TB,DVD Recorder C	U.K Only
	AK92-00683D	BY630502	ASSY PCB-MAIN;D-VR30-S-TF,DVD Recorder C	Other models Only
P001A	AK92-00666F	BY630496	ASSY PCB-VCR;D-VR4XTF/TSB,DVD Recorder C	D-VR30-S-TF Only
	AK92-00666G	BY630497	ASSY PCB-VCR;D-VR4XTB/TSB,DVD Recorder C	Other models Only
P022	AK92-00667E	BY630498	ASSY PCB-JACK;D-VR4TB/TSB,DVD Recorder C	D-VR15-S-TB Only
	AK92-00667E	BY630498	ASSY PCB-JACK;D-VR4TB/TSB,DVD Recorder C	D-VR35-S-TB Only
	AK92-00667H	BY630505	ASSY PCB-JACK;D-VR4XTG/TSB,DVD Recorder	D-VR30-S-TG Only
	AK92-00667F	BY630499	ASSY PCB-JACK;D-VR4XTF/TSB,DVD Recorder	D-VR30-S-TF Only
	AK92-00667G	BY630500	ASSY PCB-JACK;D-VR4XTB/TSB,DVD Recorder	D-VR25-S-TB Only
P025	3903-000175	BY634814	CBF-POWER CORD;AT,GB,GP2,HOUSING(2P),250	U.K Only
	3903-000176	BY634777	CBF-POWER CORD;AT,EU,CP2,HOUSING(2P),250	Other models Only
P030	3103-001152	BY731622	FAN-DC;DC 12.0V,110mA,1700rpm,0.581m^	
W202	6003-000277	22709856	SCREW-TAPTITE;BH,+,-,B,M3,L12,ZPC(YEL),SWR	
W252	AC60-12126A	70790218	SCREW-MACHINE;-,-,-,FE,FZY,BH,-,-,-,4*12,-,-	
W272	6003-001464	BY731645	SCREW-TAPTITE;BH,+,-,B,M3,L10,ZPC(WHT)	
W275	6003-001561	BY731750	SCREW-TAPTITE;BH,+,-,WT,B,M3,L6,ZPC(YEL),S	
	AC39-00017A	BY634253	CABLE-ETC-RF(PAL);-,-,MALE/FEMALE,1200MM,R	Other models Only
	AC39-00018A	BY634851	CABLE-ETC-RF(SECAM);-,-,BOTH MALE,1200MM,R	D-VR30-S-TF Only
	AC39-22017Z	BY634852	CABLE-RCA PHONE CORD;-,-,-,1500M/M,SINGLE,	
	AC39-42001U	BY631148	CABLE-RCA PHONE CORD;DOUBLE,-,-,1.5MT,BLK,	
	AK68-00676M	BY634959	MANUAL USERS;D-VR4S-S-TB,TSB,ENGLISH,-,-,M	D-VR15-S-TB Only
	AK68-00676P	BY634965	MANUAL USERS;D-VR4D-S-TG,TSB,GERMAN,ENGL	D-VR30-S-TG Only
	AK68-00676R	BY634961	MANUAL USERS;D-VR4D-S-TF,TSB,FRENCH,-,-,MO	D-VR30-S-TF Only
	AK68-00676N	BY634960	MANUAL USERS;D-VR4P-S-TB,TSB,ENGLISH,-,-,M	D-VR35-S-TB Only
	AK68-00676S	BY634962	MANUAL USERS;D-VR25-S-TB,TSB,ENGLISH,-,-,M	D-VR25-S-TB Only

7-2 VCR Mechanical Parts (Top Side)



Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
T001	AC97-02537A	BY630503	ASSY-CYLINDER;6SA,CX11A-DS,SECAM 6HD	
T002	AC70-00002A	BY731640	PLATE-GND DECK;X-11,SPT,TO.3,-,-,-,-	
T003	AC97-01652A	BY630459	ASSY-LOADING MOTOR;SANKYO LOADING MOTOR,	
T003	AC31-00018A	BY631184	MOTOR-LOADING ASSY;-SCORPIO2(TS-10A),-	
T004	AC66-00008A	BY730743	GEAR-WORM WHEEL;TS-10,POM,0.8,40,-,NAT,3	
T005	AC66-00011A	BY730745	GEAR-FL CAM;TS-10,POM,0.8,59,-,BLK,48.48	
T006	AC61-00105A	BY730723	SPRING ETC-PINCH DRIVE;TS-10,SUS304-WPB,	
T007	AC61-30180A	BY730244	PLATE-JOINT;X-9,SECC20/20,TO.8,-,-,-,-	
T008	AC66-80142A	BY730124	SLIDER-SUPPLY ASSY;X-9,SUS,-,-,-,-,SIL,-	
T009	AC66-80141A	BY730123	SLIDER-TAKE UP ASSY;X-9,SUS,-,-,-,-,SIL,-	
T010	AC97-02517A	BY630467	ASSY-HEAD ACE;ASSY-HEAD ACE,DX11A,DX11A	
T011	AC66-00074A	BY731526	LEVER-GUIDE(#9);TS-9,PPS,-,-,-,-,BLK,KHA	
T012	AC61-60553A	BY730088	SPRING ETC-GUIDE 9;X-9,SUS304-WPB,0.25,-	
T013	AC33-00015A	BY634836	HEAD-FE;HVFHP0050A,PBT3300,2PIN,NATURA	
T014	AC66-00083A	BY731636	LEVER-FL DOOR;X-11,POM(K300),-,-,-,-,BLU	
T015	AC97-02293A	BY731528	ASSY-UNIT PINCH;SECC+SUS304,TS-10,FOR X-	
T016	AC97-02215A	BY630397	ASSY-POST #8 GUIDE;SUS303+POM(M90-44)EQ,	
T019	AC66-10267A	BY730102	REEL-DISK S;X-9,POM,-,-,-,-,-	
T020	AC66-10268A	BY730103	REEL-DISK T;X-9,POM,-,-,-,-,-	
T021	AC66-30524A	BY730112	LEVER-IDLER;-POM,-,-,-,-,BLK,-	
T022	AC66-00039A	BY730760	GEAR-IDLE;TS-10,PET K3372,0.5,-,-,NTR,28	
T023	AC66-00035A	BY730759	LEVER-TENSION ASS'Y;TS-10,SECC E20/20+SU	
T024	AC61-00107A	BY730725	SPRING ETC-TENSION LEVER;TS-10,SUS304-WP	
T025	AC69-00104A	BY730762	BAND-BRAKE ASS'Y;TS-10,-,-,-,-,-	
T026	AC66-30550A	BY730121	LEVER-S.BRAKE ASSY;-POM+SUS,-,-,-,-,X-9	
T027	AC66-30549A	BY730120	LEVER-T.BRAKE ASSY;-POM+SUS,-,-,-,-,X-9	
T028	AC61-00106A	BY730724	SPRING ETC-BRAKE;TS-10,SUS304-WPB,-,-,-,-	
T029	AC66-00020A	BY730750	SLIDER-FL DRIVE;TS-10,SECC ,T1.0,-,-,SIL	
T030	AC97-02323A	BY731660	ASSY-HOLDER FL CASSETTE;SECC+POM,X-11,Fo	
T031	AC61-60561A	BY730091	SPRING ETC-FL.LEVER-LR;X-9,SUS304 WPB,OD	
T032	AC97-02324A	BY731661	ASSY-LEVER FL ARM;SECC+POM,X-11,For X-11	
T033	AC61-50658A	BY730086	GUIDE-CASS. DOOR;X-9,POM,-,-,-,-,NTR	
W015	6006-001092	BY634416	SCREW-MACHINE;WS,PH,+,M3.0,L6.0,ZPC(YEL)	
W016	6006-001154	BY731647	SCREW-TAPTITE;WSP,PH,+,M2.6,L5.6,ZPC(YEL)	
W201	6001-001711	BY731536	SCREW-MACHINE;PH,+,M3,L3.3,ZPC(YEL)	

7-3 VCR Mechanical Parts (Bottom Side)



Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
T034	AC66-00076A	BY731626	GEAR-JOINT 1;X-11,POM(K300),-, -, -,BLUE,-	
T035	AC66-00077A	BY731627	GEAR-JOINT 2;X-11,POM(K300),-, -, -,BLUE,-	
T036	AC61-00338A	BY731599	BRACKET-GEAR;X-11,SECC,T0.8,W20,L20,NTR,	
T037	AC66-00075A	BY731651	SLIDER-CAM;X-11,SECC,T1.2, -, -, -,SIL,-	
T038	AC66-00017A	BY730748	LEVER-PINCH DRIVE;TS-10,SECC E20/20,1.0	
T039	AC70-00003A	BY634837	HOOK-CAPSTAN; -, -,L10,W10,H10,POM(M90-44)	
T040	AC66-00016A	BY730747	LEVER-TENSION DRIVE;TS-10,SECC E20/20,1	
T041	AC66-00078A	BY731628	GEAR-LOADING DRIVE;X-11,POM(K300), -, -, -,	
T042	AC97-02195A	BY630393	ASSY-LEVER LOADING S;SECC+POM+SUS,X-11,F	
T043	AC97-02196A	BY630394	ASSY-LEVER LOADING T;SECC+POM+SUS,X-11,F	
T044	3101-001419	BY634900	MOTOR-CAPSTAN; -, -,12V,90mA	
T045	3809-001270	BY634670	CABLE-FLAT;30V,80C,140MM,10P,1.25MM,UL28	
T046	AC66-60051A	BY730122	BELT-PULLEY; -,5CM-70,2 * 2, -,71.3, -,X-9	
T047	AC61-21012A	BY730084	HOLDER-CLUTCH ASSY;X-9,ABS, -, -, -,BLK,-	
T048	AC66-20581A	BY730111	GEAR-CENTER ASSY;X-9,POM,M=0.5, -, -, -,GRY,-	
T049	AC60-30306A	BY730076	FASTENER-WASHER SLIT; -, -,ID2.1,OD5.0,T0.	
T050	AC66-00006A	BY730742	LEVER-UP DOWN;TS-10,POM, -, -, -, -,NAT,-	
W018	6003-001450	BY731520	SCREW-TAPTITE;PH,+,S,M2.6,L5,ZPC(YEL)	
W019	6003-000108	BY731519	SCREW-TAPTITE;BH,+,B,M2.6,L6,ZPC(YEL),SW	

MEMO

8. Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
P001	AK92-00683D	BY630502	ASSY PCB-MAIN;D-VR30-S-TF,DVD Recorder C	Other models Only U.K Only
	AK92-00683C	BY630501	ASSY PCB-MAIN;D-VR15-S-TB,DVD Recorder C	
AC101	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AC104	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
AC105	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC816	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,C0G,TP,1608	
AC818	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,C0G,TP,1608	
AC820	2203-000783	BY130435	C-CER,CHIP;0.33nF,5%,50V,C0G,TP,1608	
AC821	2203-001554	BY130450	C-CER,CHIP;1.8nF,10%,50V,X7R,TP,1608	
AC822	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
AC823	2203-000783	BY130435	C-CER,CHIP;0.33nF,5%,50V,C0G,TP,1608	
AC824	2203-001554	BY130450	C-CER,CHIP;1.8nF,10%,50V,X7R,TP,1608	
AC831	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
AC891	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC892	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC908	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AC911	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
AC912	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AC913	2402-000007	BY130502	C-AL,SMD;22uF,20%,6.3V,GP,TP,4.3x4.3x5.4	
AC914	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AC915	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
AC917	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
AC918	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC919	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
AE2	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
AE3	2402-000179	BY130505	C-AL,SMD;47uF,20%,16V,GP,TP,6.6x6.6x5.4	
AIC1	1002-001294	BY631221	IC-D/A CONVERTER;PCM1742KE,24BIT,TSSOP,1	
AIC3	1203-002178	BY631234	IC-POS.FIXED REG.;1563,SOP,7P,173MIL,PL	
AIC81	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	
AIC82	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	
AIC9	1002-001387	BY631222	IC-A/D CONVERTER;PCM1802,24BIT,SSOP,20P,	
AR10	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR11	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR12	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR13	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR14	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR15	2007-000120	BY230350	R-CHIP;680ohm,5%,1/10W,TP,1608	
AR16	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
AR2	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
AR20	2007-000029	70795513	R-CHIP;0ohm,5%,1/8W,TP,2012	
AR3	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
AR4	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR5	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR51	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
AR52	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
AR6	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR7	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
AR8	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR801	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR802	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR803	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR804	2007-000087	BY230284	R-CHIP;6.8Kohm,5%,1/10W,TP,1608	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
AR805	2007-000126	BY230390	R-CHIP:4.3Kohm,5%,1/10W,TP,1608	
AR806	2007-000084	BY230282	R-CHIP:4.7Kohm,5%,1/10W,TP,1608	
AR807	2007-000126	BY230390	R-CHIP:4.3Kohm,5%,1/10W,TP,1608	
AR808	2007-000087	BY230284	R-CHIP:6.8Kohm,5%,1/10W,TP,1608	
AR809	2007-000080	BY230343	R-CHIP:2Kohm,5%,1/10W,TP,1608	
AR811	2007-000080	BY230343	R-CHIP:2Kohm,5%,1/10W,TP,1608	
AR812	2007-000080	BY230343	R-CHIP:2Kohm,5%,1/10W,TP,1608	
AR813	2007-000084	BY230282	R-CHIP:4.7Kohm,5%,1/10W,TP,1608	
AR814	2007-000084	BY230282	R-CHIP:4.7Kohm,5%,1/10W,TP,1608	
AR881	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
AR882	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
AR894	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
AR895	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
AR9	2007-000115	BY230348	R-CHIP:82ohm,5%,1/10W,TP,1608	
ATAR1	2011-000475	BY230366	R-NET:33OHM,5%,1/16W,L,CHIP,8P,TP,32	
ATAR2	2011-000475	BY230366	R-NET:33OHM,5%,1/16W,L,CHIP,8P,TP,32	
ATAR3	2011-000475	BY230366	R-NET:33OHM,5%,1/16W,L,CHIP,8P,TP,32	
ATAR4	2011-000475	BY230366	R-NET:33OHM,5%,1/16W,L,CHIP,8P,TP,32	
ATCN1	3708-001935	BY634823	CONNECTOR-FPC/FFC/PIC;40P,0.5mm,SMD-S,Sn	
C110	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C111	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C112	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C115	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C117	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C119	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C123	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
C124	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
C125	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C126	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C127	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C128	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C129	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C130	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C140	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C141	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C142	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C143	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C144	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C145	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C146	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C147	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C150	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C166	2203-000440	BY130462	C-CER,CHIP:1nF,10%,50V,X7R,TP,1608,-	
C167	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C168	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C169	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C171	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C173	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
C174	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
C177	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C178	2203-000440	BY130462	C-CER,CHIP:1nF,10%,50V,X7R,TP,1608,-	
C179	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C183	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C184	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C185	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C210	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C214	2203-000440	BY130462	C-CER,CHIP:1nF,10%,50V,X7R,TP,1608,-	
C215	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C217	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C218	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C219	2203-000440	BY130462	C-CER,CHIP:1nF,10%,50V,X7R,TP,1608,-	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C220	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C222	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C223	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C224	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C225	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C226	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C227	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C228	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C230	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C231	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C232	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C78	2203-000746	BY130517	C-CER,CHIP;0.03NF,5%,50V,COG,TP,1608	
C79	2203-000746	BY130517	C-CER,CHIP;0.03NF,5%,50V,COG,TP,1608	
CA1	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
CA2	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
CC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
CL1	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
CL2	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
CL3	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
CN1	3710-002075	BY634832	CONNECTOR-SOCKET;30P,2R,2MM,SMD,SnPb,BLK	
CN2	3710-002075	BY634832	CONNECTOR-SOCKET;30P,2R,2MM,SMD,SnPb,BLK	
CN3	3711-005595	BY634833	CONNECTOR-SOCKET;12P,2R,2MM,SMD,S,-,BLK	
CR1	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
CR2	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
CR3	2007-000083	BY230344	R-CHIP;3Kohm,5%,1/10W,TP,1608	
DC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC14	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC15	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC16	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC18	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC19	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC20	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC21	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC22	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC23	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC24	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC25	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC66	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC9	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DE1	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
DE2	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
DE3	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
DE4	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
DE6	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
DIC1	1205-002442	BY631249	IC-CODEC;DMN-8602,BGA,308P,27x27mm,PLAS	
DIC2	0801-002522	BY631215	IC-CMOS LOGIC;74VHC541,BUFFER/LINE DRIVE	
DIC3	1107-001273	BY631230	IC-FLASH MEMORY;29DL323,4Mx8/2Mx16,TSOP,	
DIC4	1106-001471	BY631229	IC-SRAM;K6X8016T3B,512Kx16Bit,TSOP2,44	
DIC5	0801-002741	BY631218	IC-CMOS LOGIC;BU4053BCFV,MUX,SSOP,16P,17	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
DIC6	0802-001115	BY631219	IC-CMOS LOGIC;74ALVCH16373,D LATCH,TSSOP	
DIC7	0801-002587	BY631216	IC-CMOS LOGIC;74LVX541,8BIT BUFFER/DRIVE	
DIC8	1103-001134	BY631225	IC-EEPROM;24C040,512x8,SOP,8P,5.13x3.95m	
DL1	2007-000029	70795513	R-CHIP;0ohm,5%,1/8W,TP,2012	
DR1	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR10	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR2	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR21	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR28	2007-007332	BY230364	R-CHIP;1.18Kohm,1%,1/8W,TP,2012	
DR29	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR3	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR30	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR31	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR32	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR33	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR34	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR35	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR36	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR37	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR38	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR39	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR4	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR40	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR41	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR42	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR43	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR44	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR45	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR46	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR47	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR48	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR49	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR5	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR50	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR51	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR52	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR53	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR54	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR55	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR56	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR57	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR58	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR59	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR6	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR60	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR61	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR62	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR63	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR64	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR65	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR66	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
DR67	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR68	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR69	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
DR7	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR71	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR72	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR74	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR75	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR76	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR77	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
DR78	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR79	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR8	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR80	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR81	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
DR82	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
DR84	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR85	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR86	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR87	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR88	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR89	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR9	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR90	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR91	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR92	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR95	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR96	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR97	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR98	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
FB23	2007-000029	70795513	R-CHIP;0ohm,5%,1/8W,TP,2012	
PC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC11	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC14	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC15	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC16	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC18	2203-001607	BY130451	C-CER,CHIP;0.22nF,5%,50V,NP0,-,1608	
PC19	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC20	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC21	2203-000332	BY130461	C-CER,CHIP;0.012NF,5%,50V,C0G,TP,1608	
PC3	2203-000384	BY130521	C-CER,CHIP;0.015NF,5%,50V,C0G,TP,1608	
PC4	2203-000384	BY130521	C-CER,CHIP;0.015NF,5%,50V,C0G,TP,1608	
PC5	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC7	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC9	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PE1	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
PE2	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
PE3	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
PE4	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
PE5	2402-000170	BY130503	C-AL,SMD;1uF,20%,50V,GP,TP,4.3x4.3x5.4,	
PIC1	1205-001988	BY631248	IC-DATA COMM./GEN.:TSB41AB1-PAP,QFP,64P,	
PL1	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
PL2	3301-000353	BY330075	BEAD-SMD;120ohm,2x1.25x0.9mm,-,TP,-,-,-	
PL3	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
PR1	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
PR10	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
PR12	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR13	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR14	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR15	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR16	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR17	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR18	2007-000965	BY230303	R-CHIP;5.1Kohm,5%,1/10W,TP,1608	
PR19	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
PR2	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR20	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
PR21	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
PR22	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
PR23	2007-001056	BY230273	R-CHIP;6.2Kohm,5%,1/10W,TP,1608	
PR24	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
PR4	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
PR5	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
PR60	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
PR9	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
PRA1	2011-000002	BY230365	R-NET;220HM,5%,1/16W,L,CHIP,8P,TP,32	
PRA2	2011-000002	BY230365	R-NET;220HM,5%,1/16W,L,CHIP,8P,TP,32	
PY1	2801-004021	BY633022	CRYSTAL-SMD;24.576MHz,20ppm,28-AAN,12pF,	
R1	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,TP,1608	
R213	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R214	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R215	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R216	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R217	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R218	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R219	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R220	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R221	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R222	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,TP,1608	
R223	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R224	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R225	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R226	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,TP,1608	
R227	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R228	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,TP,1608	
R229	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R230	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R232	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R234	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R237	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R238	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R239	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R240	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R241	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R242	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R243	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R246	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R247	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R248	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R254	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R256	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R257	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R67	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,TP,1608	
R68	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,TP,1608	
R69	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,TP,1608	
R70	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,TP,1608	
RC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC5	2203-001683	BY130486	C-CER,CHIP;0.068nF,5%,50V,NP0,TP,1608	
RE1	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
RE2	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
RE3	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
RE4	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
RIC1	1203-003182	BY631242	IC-POSIFIXED REG.;LP3965,TO-263,5P,10.1	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
RIC2	1203-002612	BY631236	IC-POS1.ADJUST REG.;3966,TO-263,5P,10.16	
RL1	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
RL2	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RL3	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RL5	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RL6	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RL7	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RP1	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP10	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP12	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP14	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP15	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP17	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP18	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP19	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP20	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP21	2011-000002	BY230365	R-NET;220HM,5%,1/16W,L,CHIP,8P,TP,32	
RP22	2011-000002	BY230365	R-NET;220HM,5%,1/16W,L,CHIP,8P,TP,32	
RP23	2011-000002	BY230365	R-NET;220HM,5%,1/16W,L,CHIP,8P,TP,32	
RP24	2011-000002	BY230365	R-NET;220HM,5%,1/16W,L,CHIP,8P,TP,32	
RP25	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP26	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP27	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP28	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP29	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP3	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP30	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP31	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP34	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP5	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RP7	2011-000686	BY230368	R-NET;560HM,5%,1/16W,L,CHIP,8P,TP	
RR3	2007-000962	BY230394	R-CHIP;5.1Kohm,1%,1/10W,TP,1608	
RR4	2007-000300	70795516	R-CHIP;10Kohm,5%,1/8W,TP,2012	
TC10	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,2012	
TC11	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,2012	
TC12	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,2012	
TC13	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,2012	
TC14	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,2012	
TC15	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,2012	
TC16	2203-000626	BY130444	C-CER,CHIP;0.022nF,5%,50V,C0G,TP,1608	
TC17	2203-000626	BY130444	C-CER,CHIP;0.022nF,5%,50V,C0G,TP,1608	
TC18	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC19	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC20	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC21	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC22	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC23	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC24	2203-002793	BY130032	C-CER,CHIP;1000nF,+80-20%,25V,Y5V,2012	
TC25	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC26	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC27	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC28	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC29	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC30	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC31	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC32	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC33	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC34	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC35	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC51	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC52	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
TD1	0402-000309	BY430128	DIODE-RECTIFIER;1SR154-400,400V,1A,SOD-1	
TE1	2402-000007	BY130502	C-AL,SMD;22uF,20%,6.3V,GP,TP,4.3x4.3x5.	
TE2	2402-000007	BY130502	C-AL,SMD;22uF,20%,6.3V,GP,TP,4.3x4.3x5.	
TE3	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
TE4	2402-001059	BY130556	C-AL,SMD;220UF,20%,6.3V,-,TP,6X6.6X6.6	
TIC1	1204-002436	BY631322	IC-VIDEO DECODER;TW9909,TQFP,80P,12x12mm	
TL1	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
TL2	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
TL3	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
TL4	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
TNR10	2011-000475	BY230366	R-NET;33OHM,5%,1/16W,L,CHIP,8P,TP,32	
TNR11	2011-000475	BY230366	R-NET;33OHM,5%,1/16W,L,CHIP,8P,TP,32	
TR10	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
TR11	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
TR12	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
TR13	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
TR14	2007-000109	BY130423	R-CHIP;1Mohm,5%,1/10W,TP,1608	
TR15	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
TR16	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
TR17	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
TR19	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
TR20	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
TR21	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
TR22	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
TR75	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
TX1	2801-004095	BY633031	CRYSTAL-SMD;27MHz,20ppm,28-ABY,14pF,30oh	
U23	1105-001530	BY631228	IC-DRAM;K4H561638,16Mx16Bit,TSOPII,66P	
U24	1105-001530	BY631228	IC-DRAM;K4H561638,16Mx16Bit,TSOPII,66P	
U25	1203-003038	BY631238	IC-POS.ADJUST REG.;LP2995,SO,8P,4.9x3.9	
U34	0401-000008	BY430108	DIODE-SWITCHING;DAN217,80V,100MA,SOT-23,	
Y3	2801-004182	BY633025	CRYSTAL-SMD;13.5MHZ,10PPM,28-AAN,24PF,60	
P001A	AK92-00666F	BY630496	ASSY PCB-VCR;D-VR4XTF/TSB,DVD Recorder C	D-VR30-S-TF Only Other models Only
	AK92-00666G	BY630497	ASSY PCB-VCR;D-VR4XTB/TSB,DVD Recorder C	
C315	2203-000975	BY130484	C-CER,CHIP;47nF,10%,25V,X7R,TP,1608,-	
C319	2203-000843	BY130518	C-CER,CHIP;39nF,10%,25V,X7R,TP,1608,-	
C320	2203-000975	BY130484	C-CER,CHIP;47nF,10%,25V,X7R,TP,1608,-	
C321	2203-002398	BY130454	C-CER,CHIP;22nF,10%,50V,X7R,TP,1608	
C324	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C327	2203-001211	BY130448	C-CER,CHIP;8.2nF,10%,50V,X7R,TP,1608	
C328	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C329	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C330	2203-000975	BY130484	C-CER,CHIP;47nF,10%,25V,X7R,TP,1608,-	
C331	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C332	2203-000975	BY130484	C-CER,CHIP;47nF,10%,25V,X7R,TP,1608,-	
C335	2203-001652	BY130452	C-CER,CHIP;470nF,+80-20%,16V,Y5V,TP,1608	
C337	2203-001652	BY130452	C-CER,CHIP;470nF,+80-20%,16V,Y5V,TP,1608	
C338	2203-002398	BY130454	C-CER,CHIP;22nF,10%,50V,X7R,TP,1608	
C343	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,1608	
C344	2203-000315	BY130441	C-CER,CHIP;0.12NF,5%,50V,COG,TP,1608	
C345	2203-001607	BY130451	C-CER,CHIP;0.22nF,5%,50V,NPO,-,1608	
C347	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,1608	
C348	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C349	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,1608	
C350	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C392	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C3A08	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C3A09	2203-001103	BY130447	C-CER,CHIP;6.8nF,10%,50V,X7R,TP,1608,-	
C3A10	2203-001211	BY130448	C-CER,CHIP;8.2nF,10%,50V,X7R,TP,1608,-	
C3A15	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C3A18	2203-001126	BY130478	C-CER,CHIP;0.68nF,10%,50V,X7R,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C3A21A	2203-001554	BY130450	C-CER,CHIP;1.8nF,10%,50V,X7R,TP,1608	
C3A24	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C3A29	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C3A70	2203-001126	BY130478	C-CER,CHIP;0.68nF,10%,50V,X7R,1608	
C3S03	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	D-VR30-S-TF Only
C3S05	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	D-VR30-S-TF Only
C3S07	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	D-VR30-S-TF Only
C3S08	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	D-VR30-S-TF Only
C3S11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	D-VR30-S-TF Only
C3S12A	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	D-VR30-S-TF Only
C3S14A	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	D-VR30-S-TF Only
C3S15	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	D-VR30-S-TF Only
C502	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C506	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C508	2203-000888	BY130483	C-CER,CHIP;4.7nF,10%,50V,X7R,TP,1608	
C511	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C513	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C517	2203-000888	BY130483	C-CER,CHIP;4.7nF,10%,50V,X7R,TP,1608	
C519	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C522	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C523	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C530	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C604	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C605	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C606	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C607	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C614	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C623	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C626	2203-000626	BY130444	C-CER,CHIP;0.022nF,5%,50V,COG,TP,1608	
C627	2203-000626	BY130444	C-CER,CHIP;0.022nF,5%,50V,COG,TP,1608	
C628	2203-000681	BY130445	C-CER,CHIP;0.027NF,5%,50V,COG,TP,1608	
C633	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C635	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
C636	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
C637	2203-002041	BY130477	C-CER,CHIP;0.47nF,10%,50V,X7R,TP,1608	
C639	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C640	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C645	2203-000357	BY130442	C-CER,CHIP;0.15NF,5%,50V,COG,TP,1608	
C646	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C657	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C658	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C659A	2203-001140	BY130526	C-CER,CHIP;68nF,10%,16V,X7R,TP,1608	
C691	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C695	2203-000357	BY130442	C-CER,CHIP;0.15NF,5%,50V,COG,TP,1608	
C696	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C6P02	2203-000315	BY130441	C-CER,CHIP;0.12NF,5%,50V,COG,TP,1608	
C6P04	2203-000681	BY130445	C-CER,CHIP;0.027NF,5%,50V,COG,TP,1608	
C6P05	2203-000681	BY130445	C-CER,CHIP;0.027NF,5%,50V,COG,TP,1608	
C6P08	2203-001071	BY130465	C-CER,CHIP;0.056NF,5%,50V,COG,TP,1608	
C6P10	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,1608	
C6P13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C702	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C703	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
C822A	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
IC301	1204-002140	BY631205	IC-VIDEO PROCESS;LA71750EM-MPB-E,QFP,100	
IC3S01	1204-001921	BY631190	IC-CHROMA;LA70100M,SOP,30P,375MIL,PLASTI	D-VR30-S-TF Only
IC501	1204-001920	BY631189	IC-AUDIO PROCESSOR;LA72646M,QFP,80P,14x1	
IC601	AC09-00274A	BY631286	IC MICOM;UPD78F4928GF-3BA,FRESH ROM,100	
IC6P01	1204-001796	BY631284	IC-OSD PROCESSOR;LC74759JM-9820,MFP,24P,	
IC701	1003-001561	BY631280	IC-LED DRIVER;PT6961,SOP,32P,300MIL,-,40	
J330	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
J905	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
J910	2007-000029	70795513	R-CHIP:0ohm,5%,1/8W,TP,2012	
J911	2007-000029	70795513	R-CHIP:0ohm,5%,1/8W,TP,2012	
J913	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
J914	2007-000029	70795513	R-CHIP:0ohm,5%,1/8W,TP,2012	
Q302	0501-000341	BY530073	TR-SMALL SIGNAL:KSC1623-L,NPN,200mW,SOT-	
Q601	0504-000129	70795815	TR-DIGITAL:KSR1104,NPN,200mW,47K/47K,SOT	
R1S36	2007-000490	BY230392	R-CHIP:2.2Kohm,1%,1/8W,TP,2012	
R315	2007-000122	BY230294	R-CHIP:1.2Kohm,5%,1/10W,TP,1608	
R316	2007-001179	BY230305	R-CHIP:8.2Kohm,5%,1/10W,TP,1608	
R320	2007-000458	BY230372	R-CHIP:18Kohm,5%,1/10W,TP,1608	
R321	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
R322	2007-000458	BY230372	R-CHIP:18Kohm,5%,1/10W,TP,1608	
R323	2007-000125	BY230296	R-CHIP:3.9Kohm,5%,1/10W,TP,1608	
R324	2007-000079	BY230280	R-CHIP:1.8Kohm,5%,1/10W,TP,1608	D-VR30-S-TF Only
R327	2007-000084	BY230282	R-CHIP:4.7Kohm,5%,1/10W,TP,1608	
R328	2007-000122	BY230294	R-CHIP:1.2Kohm,5%,1/10W,TP,1608	
R329	2007-000080	BY230343	R-CHIP:2Kohm,5%,1/10W,TP,1608	
R330	2007-000087	BY230284	R-CHIP:6.8Kohm,5%,1/10W,TP,1608	
R331	2007-000079	BY230280	R-CHIP:1.8Kohm,5%,1/10W,TP,1608	
R333	2007-001039	70795708	R-CHIP:56Kohm,5%,1/8W,TP,2012	
R334	2007-000123	BY230306	R-CHIP:1.5Kohm,5%,1/10W,TP,1608	
R336	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
R350	2007-000123	BY230306	R-CHIP:1.5Kohm,5%,1/10W,TP,1608	D-VR30-S-TF Only
R360	2007-001196	BY230309	R-CHIP:820Kohm,5%,1/10W,TP,1608	
R372	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	
R373	2007-000093	BY230308	R-CHIP:20Kohm,5%,1/10W,TP,1608	
R380	2007-000124	BY230295	R-CHIP:2.2Kohm,5%,1/10W,TP,1608	
R3A05	2007-000616	BY230300	R-CHIP:24Kohm,5%,1/10W,TP,1608	
R3A06	2007-000539	BY230357	R-CHIP:200ohm,5%,1/10W,TP,1608	
R3A07	2007-000133	BY230297	R-CHIP:330Kohm,5%,1/10W,TP,1608	
R3A08	2007-000091	BY230286	R-CHIP:12Kohm,5%,1/10W,TP,1608	
R3A09	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
R3A11	2007-000124	BY230295	R-CHIP:2.2Kohm,5%,1/10W,TP,1608	
R3A12	2007-000074	BY230276	R-CHIP:100ohm,5%,1/10W,TP,1608	
R3A13	2007-000097	BY230290	R-CHIP:47Kohm,5%,1/10W,TP,1608	
R3A14	2007-000094	BY230288	R-CHIP:22Kohm,5%,1/10W,TP,1608	
R3A16	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
R3A17	2007-000124	BY230295	R-CHIP:2.2Kohm,5%,1/10W,TP,1608	
R3A18	2007-000124	BY230295	R-CHIP:2.2Kohm,5%,1/10W,TP,1608	
R3A23	2007-000091	BY230286	R-CHIP:12Kohm,5%,1/10W,TP,1608	
R3A24	2007-000094	BY230288	R-CHIP:22Kohm,5%,1/10W,TP,1608	
R3A26	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
R3A28	2007-000124	BY230295	R-CHIP:2.2Kohm,5%,1/10W,TP,1608	
R3A51	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
R3A60	2007-000704	BY230374	R-CHIP:3.6Kohm,5%,1/10W,TP,1608	
R3A70	2007-000084	BY230282	R-CHIP:4.7Kohm,5%,1/10W,TP,1608	
R3S01	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	D-VR30-S-TF Only
R509	2007-000087	BY230284	R-CHIP:6.8Kohm,5%,1/10W,TP,1608	
R510	2007-000913	BY230302	R-CHIP:43Kohm,5%,1/10W,TP,1608	
R511	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
R517	2007-000087	BY230284	R-CHIP:6.8Kohm,5%,1/10W,TP,1608	
R518	2007-000913	BY230302	R-CHIP:43Kohm,5%,1/10W,TP,1608	
R545	2007-000512	BY230373	R-CHIP:2.4Kohm,5%,1/10W,TP,1608	
R546	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	
R547	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	
R570	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	
R571	2007-000098	BY230291	R-CHIP:56Kohm,5%,1/10W,TP,1608	
R610	2007-000074	BY230276	R-CHIP:100ohm,5%,1/10W,TP,1608	
R611	2007-000074	BY230276	R-CHIP:100ohm,5%,1/10W,TP,1608	
R614	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
R615	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R617	2007-001038	BY230376	R-CHIP;56Kohm,1%,1/10W,TP,1608	
R620	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R621	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R630	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R631	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R634	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R635	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R640	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R657	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R661	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
R666	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R667	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R670	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R671	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R672	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R678	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R679	2007-000572	70795525	R-CHIP;220ohm,5%,1/8W,TP,2012	
R682	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R685	2007-000086	BY230283	R-CHIP;5.6Kohm,5%,1/10W,TP,1608	
R688	2007-000129	BY230307	R-CHIP;27Kohm,5%,1/10W,TP,1608	
R691	2007-000572	70795525	R-CHIP;220ohm,5%,1/8W,TP,2012	
R698	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R6P05	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R6P07	2007-000539	BY230357	R-CHIP;200ohm,5%,1/10W,TP,1608	
R6P08	2007-000118	BY230293	R-CHIP;390ohm,5%,1/10W,TP,1608	
R6P09	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
R6P10	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
R703	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R704	2007-001010	BY230360	R-CHIP;51Kohm,5%,1/10W,TP,1608	
R711	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
BD1S01	AC27-92001M	70795644	COIL-INDUCTOR;RH3.5X6.5RS,BEAD(RADIAL).-	
C1P103	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C1P104	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C1P105	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C1P107	2401-003221	BY130499	C-AL;100uF,20%,16V,GP,TP,8X5,2.5	
C1P108	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
C1P109	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C1P110	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C1P111	2401-001249	BY130496	C-AL;4.7uF,20%,35V,GP,TP,4x5,2.5	
C1P120	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C1P121	2401-001250	70796211	C-AL;4.7uF,20%,35V,GP,TP,4x5,5	
C1P122	2401-001250	70796211	C-AL;4.7uF,20%,35V,GP,TP,4x5,5	
C1P123	2401-001730	70795625	C-AL;10uF,20%,50V,GP,TP,5X11,5	
C1P124	2401-001250	70796211	C-AL;4.7uF,20%,35V,GP,TP,4x5,5	
C1P125	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C1P126	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C1P127	2401-001250	70796211	C-AL;4.7uF,20%,35V,GP,TP,4x5,5	
C1P128	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C1P129	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C1S07	2201-000012	BY130519	C-CERAMIC,DISC;0.22nF,10%,1000V,Y5P,-.6.	
C1S08	2305-001029	BY130226	C-FILM,LEAD-PEF;10nF,10%,630V,TP,12x9x12	
C1S09	2401-001186	BY130551	C-AL;33uF,20%,35V,GP,TP,6.3x7,2.5	
C1S10	2401-001186	BY130551	C-AL;33uF,20%,35V,GP,TP,6.3x7,2.5	
C1S11	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	
C1S12	2301-000481	BY130555	C-FILM,LEAD-PEF;10nF,5%,100V,TP,6.5x3.4x	
C1S32	2401-000385	70795431	C-AL;10uF,20%,100V,GP,TP,6.3x11,5	
C1S34	2401-001126	BY130045	C-AL;330uF,20%,25V,WT,TP,10x12.5,5	
C1S37	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
C1S38	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
C1S39	2301-000129	70796098	C-FILM,LEAD-PEF;100nF,5%,50V,TP,10X9X4.3	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C1S41	2401-003059	BY130050	C-AL;1000UF,20%,16V,WT,TP,10X16,5	
C317	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C318	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C322	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C325	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C326	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C333	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C339	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C340	2401-004014	BY130554	C-AL;4.7uF,20%,16V,-,TP,4x5,2.5	
C341	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C342	2202-002037	BY130027	C-CERAMIC,MLC-AXIAL;100nF,80-20%,50V,Y5V	
C351	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C352	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C353	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C354	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C3A01	2401-003122	70795626	C-AL;4.7uF,20%,50V,LL,TP,5X7,5	
C3A02	2401-000922	BY130044	C-AL;22uF,20%,16V,GP,TP,5x5,5	
C3A11	2301-000174	BY130375	C-FILM,LEAD-PEF;15nF,5%,100V,TP,7.2x4.0x	
C3A12	2401-000922	BY130044	C-AL;22uF,20%,16V,GP,TP,5x5,5	
C3A14	2202-000263	BY130172	C-CERAMIC,MLC-AXIAL;470pF,10%,50V,Y5P,TP	
C3A16	2401-003122	70795626	C-AL;4.7uF,20%,50V,LL,TP,5X7,5	
C3A17	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C3A23	2401-002069	BY130245	C-AL;33uF,20%,16V,GP,TP,6.3x5,5	
C3A30	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C3A40	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C3A41	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C3S01	2202-000797	70795075	C-CERAMIC,MLC-AXIAL;10NF,30%,16V,Y5S,TP,	
C3S02	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	
C3S04	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	
C3S06	2401-001324	BY130534	C-AL;0.47UF,20%,50V,GP,BK,3X5,2.5	
C3S09	2401-001324	BY130534	C-AL;0.47UF,20%,50V,GP,BK,3X5,2.5	
C3S10	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C3S14	2401-000665	BY130424	C-AL;2.2uF,20%,50V,GP,TP,3.5x5,5	
C501	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C503	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
C504	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C505	2401-001249	BY130496	C-AL;4.7uF,20%,35V,GP,TP,4x5,2.5	
C507	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
C510	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C518	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
C520	2401-001249	BY130496	C-AL;4.7uF,20%,35V,GP,TP,4x5,2.5	
C521	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C524	2401-001249	BY130496	C-AL;4.7uF,20%,35V,GP,TP,4x5,2.5	
C525	2401-001249	BY130496	C-AL;4.7uF,20%,35V,GP,TP,4x5,2.5	
C526	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
C527	2202-000797	70795075	C-CERAMIC,MLC-AXIAL;10NF,30%,16V,Y5S,TP,	
C529	2401-001250	70796211	C-AL;4.7uF,20%,35V,GP,TP,4x5,5	
C537	2401-000665	BY130424	C-AL;2.2uF,20%,50V,GP,TP,3.5x5,5	
C538	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
C541	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C603	2401-000360	BY130317	C-AL;100uF,20%,50V,GP,TP,8x11.5,5	
C607A	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C609	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C610	2202-002037	BY130027	C-CERAMIC,MLC-AXIAL;100nF,80-20%,50V,Y5V	
C613	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C638	2401-001250	70796211	C-AL;4.7uF,20%,35V,GP,TP,4x5,5	
C641	2401-003221	BY130499	C-AL;100uF,20%,16V,GP,TP,8X5,2.5	
C642	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C661	2202-002055	BY130286	C-CERAMIC,MLC-AXIAL;47nF,+80-20%,50V,Y5V	
C662	2401-002095	BY130048	C-AL;47uF,20%,25V,GP,TP,6.3x5,5	
C663	2401-000118	70796210	C-AL;1000uF,20%,10V,GP,TP,10x12.5,5	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C688	2401-001507	70795621	C-AL;47uF,20%,16V,GP,TP,6.3x5,5	
C6P01	2202-000797	70795075	C-CERAMIC,MLC-AXIAL;10NF,30%,16V,Y5S,TP,	
C6P11	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	
C6P12	2401-002095	BY130048	C-AL;47uF,20%,25V,GP,TP,6.3x5,5	
C6P15	2202-000797	70795075	C-CERAMIC,MLC-AXIAL;10NF,30%,16V,Y5S,TP,	
C704	2401-000118	70796210	C-AL;1000uF,20%,10V,GP,TP,10x12.5,5	
C706	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C708A	2202-000797	70795075	C-CERAMIC,MLC-AXIAL;10NF,30%,16V,Y5S,TP,	
D1	0402-001111	BY430129	DIODE-RECTIFIER;1N5397GP,600V,1.5A,-,TP	
D1P101	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D1P102	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D1P103	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D1P106	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1P107	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1P108	0402-000165	BY430121	DIODE-RECTIFIER;1N5819,40V,1A,DO-41,TP	
D1P111	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1P112	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D1P130	0402-000165	BY430121	DIODE-RECTIFIER;1N5819,40V,1A,DO-41,TP	
D1S05	0402-000012	BY430047	DIODE-RECTIFIER;UF4007,1KV,1A,DO-41,TP	
D1S06	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D1S07	0402-001195	BY430011	DIODE-RECTIFIER;F1T4,400V,1A,DO-204AC,TP	
D1S34	0402-001195	BY430011	DIODE-RECTIFIER;F1T4,400V,1A,DO-204AC,TP	
D1S35	0402-001194	BY430010	DIODE-RECTIFIER;SHG2D,200V,2A,-,TP	
D1S37	0402-001195	BY430011	DIODE-RECTIFIER;F1T4,400V,1A,DO-204AC,TP	
D1S39	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D2	0402-001111	BY430129	DIODE-RECTIFIER;1N5397GP,600V,1.5A,-,TP	
D3	0402-001111	BY430129	DIODE-RECTIFIER;1N5397GP,600V,1.5A,-,TP	
D301	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D302	0402-000165	BY430121	DIODE-RECTIFIER;1N5819,40V,1A,DO-41,TP	
D4	0402-001111	BY430129	DIODE-RECTIFIER;1N5397GP,600V,1.5A,-,TP	
D502	0402-000165	BY430121	DIODE-RECTIFIER;1N5819,40V,1A,DO-41,TP	
D603	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D604	0402-000165	BY430121	DIODE-RECTIFIER;1N5819,40V,1A,DO-41,TP	
D620	0402-000165	BY430121	DIODE-RECTIFIER;1N5819,40V,1A,DO-41,TP	
D688	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D701	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D702	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D703	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D704	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D706	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D707	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D708	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D709	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
FL3A01	2702-000166	70795862	INDUCTOR-RADIAL;47uH,5%,6.0x6.4mm	
IC1S03	AC14-12006D	70795271	IC;KA431Z,TO-92,TAPING	
IC604	AC14-12006C	70795269	IC;KA7533,DIP,-	
L1P02	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L1P101	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L1S32	AC27-12001N	70796213	COIL CHOKE;10UH-15%,RA,K-30,Q80,150KHZ,-	
L301	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L301A	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L302	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L304	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,-,TP,-,-,	
L370	2701-000113	70795159	INDUCTOR-AXIAL;100UH,5%,2534	
L3A01	2702-000120	70795171	INDUCTOR-RADIAL;15000uH,5%,6.2x7.4mm	
L3A02	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L3A03	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L3A70	2702-000120	70795171	INDUCTOR-RADIAL;15000uH,5%,6.2x7.4mm	
L3S01	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L501	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L502	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
L602	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L603	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L605	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L6P01	2702-000108	70795168	INDUCTOR-RADIAL;100uH,5%,6.0x6.4mm	
L6P03	2701-000160	70795162	INDUCTOR-AXIAL;22uH,5%,2434	
L6P05	2701-000165	BY330052	INDUCTOR-AXIAL;27uH,5%,2434	
L702	2702-000108	70795168	INDUCTOR-RADIAL;100uH,5%,6.0x6.4mm	
Q1P101	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO	
Q1P102	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO	
Q1P103	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO	
Q1P104	0501-000398	70795136	TR-SMALL SIGNAL;KSC945,NPN,250mW,TO-92,T	
Q1P105	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO	
Q1P106	0504-000142	70693084	TR-DIGITAL;KSR2001,PNP,300MW,4.7K/4.7K,T	
Q1P107	0501-000398	70795136	TR-SMALL SIGNAL;KSC945,NPN,250mW,TO-92,T	
Q1P108	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO	
Q1P109	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO	
Q1P110	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO	
Q1P111	0501-000610	70693410	TR-SMALL SIGNAL;KSA928A-Y,PNP,1W,TO-92L,	
Q1P112	0501-000610	70693410	TR-SMALL SIGNAL;KSA928A-Y,PNP,1W,TO-92L,	
Q1P113	0501-000610	70693410	TR-SMALL SIGNAL;KSA928A-Y,PNP,1W,TO-92L,	
Q3A01	0501-000398	70795136	TR-SMALL SIGNAL;KSC945,NPN,250mW,TO-92,T	
Q3A02	0501-000303	70795134	TR-SMALL SIGNAL;KSA733,PNP,250mW,TO-92,T	
Q3A03	0501-000442	70795142	TR-SMALL SIGNAL;KTC3203-Y,NPN,400mW,TO-9	
Q3A04	0501-000442	70795142	TR-SMALL SIGNAL;KTC3203-Y,NPN,400mW,TO-9	
Q3A05	0501-000442	70795142	TR-SMALL SIGNAL;KTC3203-Y,NPN,400mW,TO-9	
Q3A06	0501-000303	70795134	TR-SMALL SIGNAL;KSA733,PNP,250mW,TO-92,T	
Q6P01	0501-000303	70795134	TR-SMALL SIGNAL;KSA733,PNP,250mW,TO-92,T	
Q6P02	0501-000303	70795134	TR-SMALL SIGNAL;KSA733,PNP,250mW,TO-92,T	
R1P102	2001-000008	70795014	R-CARBON;15KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1P104	2001-000027	70795659	R-CARBON;100OHM,5%,1/4W,AA,TP,2.4X6.4MM	
R1P105	2001-000605	70795609	R-CARBON;3.6KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P107	2001-000734	70795040	R-CARBON;4.7KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P108	2001-000812	BY230038	R-CARBON;5.6KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P109	2001-000812	BY230038	R-CARBON;5.6KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P110	2001-000449	70795020	R-CARBON;2.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P121	2001-000062	70796173	R-CARBON;470OHM,5%,1/4W,AA,TP,2.4X6.4MM	
R1P122	2001-000449	70795020	R-CARBON;2.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P123	2001-000613	70795036	R-CARBON;3.9KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P125	2001-000449	70795020	R-CARBON;2.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P131	2001-000855	BY230025	R-CARBON;560OHM,5%,1/4W,AA,TP,2.4X6.4MM	
R1S05	2001-000546	BY230318	R-CARBON;270KOHM,5%,1/4W,AA,TP,2.4X6.4M	
R1S06	2001-000869	BZ230057	R-CARBON;56OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S07	2001-000546	BY230318	R-CARBON;270KOHM,5%,1/4W,AA,TP,2.4X6.4M	
R1S08	2001-000546	BY230318	R-CARBON;270KOHM,5%,1/4W,AA,TP,2.4X6.4M	
R1S09	2001-000598	70795320	R-CARBON;3.3OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S10	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S11	2001-000449	70795020	R-CARBON;2.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S12	2001-000527	70795018	R-CARBON;22OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S13	2005-001198	BY230337	R-WIRE WOUND,NON;0.18ohm,1%,1W,AA,TP,4.3	
R1S14	2001-000290	70795006	R-CARBON;10KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S15	2001-000096	BY230036	R-CARBON(S);1MOHM,5%,1/2W,AA,TP,2.4X6.4M	
R1S31	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S32	2001-000221	BY230019	R-CARBON;1.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S33	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S35	2004-000500	BY230388	R-METAL;2.7Kohm,1%,1/8W,AA,TP,1.8x3.2m	
R1S37	2003-000148	BY230003	R-METAL OXIDE;100ohm,5%,2W,AE,TP,6x16mm	
R325	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R326	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R335	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R374	2001-000290	70795006	R-CARBON;10KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R3A04	2001-000221	BY230019	R-CARBON;1.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
R3A25	2001-000221	BY230019	R-CARBON;1.2KOHM,5%,1/8W,AA,TP,1.8X3.2MM	D-VR30-S-TF Only
R3A50	2001-000800	70795044	R-CARBON;5.1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R3S02	2001-000435	70795008	R-CARBON;1MOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R501	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R503	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R512	2001-000660	70795032	R-CARBON;33KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R608	2001-000864	70795047	R-CARBON;56KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R609	2001-000864	70795047	R-CARBON;56KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R632	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R633	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R636	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R637	2001-000290	70795006	R-CARBON;10KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R641	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R642	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R643	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R644	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R647	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R651	2001-000010	70795052	R-CARBON;68KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R658	2001-000633	70795029	R-CARBON;30KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R660	2001-000786	70795041	R-CARBON;47KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R663	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R664	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R668	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R669	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R673	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R674	2001-000290	70795006	R-CARBON;10KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R676	2001-000633	70795029	R-CARBON;30KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R701	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R702	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
SW713	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW714	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW715	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW716	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW717	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW718	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW719	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW720	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW721	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW722	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
VA1S01	1405-001026	BY634022	VARISTOR;470V,600A,9x7mm,TP	
W002	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,-,TP,-,-	
W022	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,-,TP,-,-	
W074	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,-,TP,-,-	
W165	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,-,TP,-,-	
W237	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,-,TP,-,-	
XT301	2801-001397	BY633009	CRYSTAL-UNIT;4.433619MHz,20ppm,28-AAA,S	
XT602	2801-003139	BY633010	CRYSTAL-UNIT;8MHz,50ppm,28-AAA,22pF,80oh	
ZD1P02	0403-001211	BY430015	DIODE-ZENER;MTZJ12B,11.8-12.3V,500MW,DO	
ZD1P03	0403-000720	BY430013	DIODE-ZENER;MTZJ9.1B,8.57-9.01V,500MW,DO	
ZD1P04	0403-000717	BY430005	DIODE-ZENER;MTZJ5.1B,4.94-5.2V,500MW,DO	
ZD1S01	0403-001318	BY430107	DIODE-ZENER;MTZJ4.3B,4.17-4.43V,500MW,DO	
ZD1S02	0403-000713	BY430110	DIODE-ZENER;MTZJ20B,18.63-17.7V,500MW,DO	
C1P130	2401-001992	70796291	C-AL;2200uF,20%,10V,WT,TP,10X20MM,5	
C1S01	2401-000342	BY130532	C-AL;100uF,20%,400V,WT,-,20x30,10	
C1S02	2201-000963	BY130161	C-CERAMIC,DISC;1NF,20%,400V,Y5U,TP,9.5X6	
C1S03	2201-000963	BY130161	C-CERAMIC,DISC;1NF,20%,400V,Y5U,TP,9.5X6	
C1S04	2301-001711	BY130491	C-FILM,LEAD;220nF,##20%,275V,BK,17.5*10*	
C1S05	2301-001711	BY130491	C-FILM,LEAD;220nF,##20%,275V,BK,17.5*10*	
C1S06	2201-000987	BY130164	C-CERAMIC,DISC;2.2NF,20%,400V,Y5U,BK,12.	
C1S30	2401-003390	BY130501	C-AL;2200uF,20%,16V,LZ,TP,13x31.5.5	
C1S31	2401-003390	BY130501	C-AL;2200uF,20%,16V,LZ,TP,13x31.5.5	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C1S33	2401-000717	BY130493	C-AL;2200uF,20%,25V,WT,TP,12.5x25,5	
CN01	3708-000270	70795501	CONNECTOR-FPC/FFC/PIC;33P,1.25MM,STRAIGH	
FL282	3809-001581	BY634835	FFC CABLE-FLAT;30V,80C,60mm,33P,1.25mm,U	
CN02	3708-000270	70795501	CONNECTOR-FPC/FFC/PIC;33P,1.25MM,STRAIGH	
FL282	3809-001581	BY634835	FFC CABLE-FLAT;30V,80C,60mm,33P,1.25mm,U	
CN03	3711-004379	BY634830	CONNECTOR-HEADER;BOX,4P,1R,2MM,STRAIGHT,	
CN04	3711-000827	BY634827	CONNECTOR-HEADER;BOX,2P,1R,2mm,STRAIGHT,	
CN1S01	3711-000203	BY634858	CONNECTOR-HEADER;1WALL,2P,1R,7.92MM,STRA	
CN301	3708-000391	70796387	CONNECTOR-FPC/FFC/PIC;10P,1.25mm,STRAIGH	
CN303	3708-001165	BY634023	CONNECTOR-FPC/FFC/PIC;6P,1.25MM,STRAIGHT	
FL042	3809-001206	BY634415	CABLE-FLAT;30V,-20to+80C,140mm,6P,1.25mm	
CN3A02	AC37-00028A	BY634831	CONNECTOR-SOCKET;-X-11,T9.0,W8.5,PBT NT	
CN604	AC37-00027A	BY634826	CONNECTOR-HEADER;20045WS,X-11,T8.5,W17.4	
D1S30	0404-001225	BY430112	DIODE-SCHOTTKY;SRAF560,60V,5000mA,ITO-22	
D1S31	0404-001225	BY430112	DIODE-SCHOTTKY;SRAF560,60V,5000mA,ITO-22	
D1S32	0402-001643	BY430126	DIODE-RECTIFIER;MBRF10A0,100V,10A,ITO-22	
D1S33	0402-001643	BY430126	DIODE-RECTIFIER;MBRF10A0,100V,10A,ITO-22	
DT701	AK07-00031A	BY634958	LED DISPLAY;BCD-9033A,DVD-VR320,70,10,7,	
F1S01	3601-000237	BY634950	FUSE-CARTRIDGE;250V,2A,SLOW-BLOW,CERAMIC	
GP601	AC63-00043A	BY730731	SHIELD CASE-GROUND PCB;SV-643F,STPE,T0.3	
HSD11A	AH62-30122A	BY731633	HEAT SINK-POWER;1,AL,VO,T1.3,ANODIZING,W	
IC1P01	AC14-12006N	70796345	IC-VOLT REGU;KA78R12,SIP,STICK	
IC1P02	AC14-12006N	70796345	IC-VOLT REGU;KA78R12,SIP,STICK	
IC1P03	1203-003216	BY631290	IC-POS.FIXED REG.;G9133,TO-220F,4P,10.1	
IC1S01	1203-002805	BY631237	IC-PWM CONTROLLER;ICE2BS01,PDIP,8P,9.52X	
IC1S02	0604-001028	BY530004	PHOTO-COUPLER;TR,50-600%,250mW,DIP-4,ST	
IC605	1103-001331	BY631281	IC-EEPROM;S524A60X51,2Kx8Bit,DIP,8P,9.2x	
L1S01	AC29-30050B	BY330056	FILTER LINE NOISE;-400uH,-AC250V,TR12.	
L1S02	AK29-00002A	BY330083	FILTER EMI;RECORDER,SQ2222,0.420hm Max,1	
L1S30	AH27-00039A	BY330081	COIL CHOKE;DR CHOKE(8*6),DVD-R2000,22uH,	
L1S31	AH27-00039A	BY330081	COIL CHOKE;DR CHOKE(8*6),DVD-R2000,22uH,	
PT1SD1	AC26-00014C	BY330096	TRANS SWITCHING;EER-3534,RAM COMBO,-FRE	
PT601	0604-001275	BY631213	PHOTO-INTERRUPTER;-,-,0MW,SNAP(STOPPER),	
PT602	0604-001275	BY631213	PHOTO-INTERRUPTER;-,-,0MW,SNAP(STOPPER),	
Q1S01	0505-001729	BY530077	FET-SILICON;SPA04N60C3,N,600V,4.5A,0.850	
R1S02	2006-000273	70796087	R-CEMENT;27KOHM,5%,2W,CA,BK,6.4X6.5X18M	
R1S03	2006-000273	70796087	R-CEMENT;27KOHM,5%,2W,CA,BK,6.4X6.5X18M	
R1S04	2006-000262	BY230170	R-CEMENT;2.7ohm,10%,2W,CB,TP,7.5x11x20.	
RM701	AC32-00006A	BY630162	MODULE REMOCON;TSOP2238WE1,38KHZ,-,5.08m	
SMPS_C	AK63-00131A	BY731649	SHIELD-CASE SMPS;DVD-VR300,SPTE,T0.3,W15	
SW602	AC34-00006A	BY634846	SWITCH-REC;-,-,-,-,-,-,-,-,-,-,-,-,-,-,-,-,-,-	
SW603	AC34-00005A	BY634845	SWITCH MODE;-,-,-,-,-,-,-,-,-,-,-,-,-,-,-,-,-,-	
SW604	3409-001165	BY634901	SWITCH-DETECTOR;5V,1mA,-,50gf,ON-OFF	
W234	0402-001533	BY430120	DIODE-RECTIFIER;1N5408,1000V,3A,-,BK	
P022	AK92-00667E	BY630498	ASSY PCB-JACK;D-VR4TB/TSB,DVD Recorder C	D-VR15-S-TB Only
	AK92-00667E	BY630498	ASSY PCB-JACK;D-VR4TB/TSB,DVD Recorder C	D-VR35-S-TB Only
	AK92-00667H	BY630505	ASSY PCB-JACK;D-VR4XTG/TSB,DVD Recorder	D-VR30-S-TG Only
	AK92-00667F	BY630499	ASSY PCB-JACK;D-VR4XTF/TSB,DVD Recorder	D-VR30-S-TF Only
	AK92-00667G	BY630500	ASSY PCB-JACK;D-VR4XTB/TSB,DVD Recorder	D-VR25-S-TB Only
AC14	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AC15	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC18	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AC19	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AC21	2203-000357	BY130442	C-CER,CHIP;0.15NF,5%,50V,C0G,TP,1608	
AC22	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC23	2203-000125	BY130520	C-CER,CHIP;1.2nF,10%,50V,X7R,TP,1608,-	
AC24	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC25	2203-000357	BY130442	C-CER,CHIP;0.15NF,5%,50V,C0G,TP,1608	
AC26	2203-000125	BY130520	C-CER,CHIP;1.2nF,10%,50V,X7R,TP,1608,-	
AC27	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
AC9	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AD1	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
AD2	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
AD3	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
AD4	0401-000008	BY430108	DIODE-SWITCHING;DAN217,80V,100MA,SOT-23,	
AD5	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
AE11	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
AE12	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
AE13	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
AE14	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
AE15	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
AE16	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
AE3	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
AE5	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
AE6	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
AE7	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
AIC4	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	
AIC5	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	
AQ1	0504-000128	BY530074	TR-DIGITAL;- ,NPN,200MW,22K/22K,SOT-23,TP	
AQ2	0504-000156	BY530075	TR-DIGITAL;KSR2103,PNP,200MW,22K/22K,SOT	
AQ3	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
AQ4	0504-000128	BY530074	TR-DIGITAL;- ,NPN,200MW,22K/22K,SOT-23,TP	
AQ5	0504-000156	BY530075	TR-DIGITAL;KSR2103,PNP,200MW,22K/22K,SOT	
AQ6	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
AQ7	0504-000128	BY530074	TR-DIGITAL;- ,NPN,200MW,22K/22K,SOT-23,TP	
AQ8	0504-000156	BY530075	TR-DIGITAL;KSR2103,PNP,200MW,22K/22K,SOT	
AQ9	0501-000002	BY430105	TR-SMALL SIGNAL;KSA812,PNP,150MW,SOT-23,	
AR10	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
AR11	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
AR12	2007-000076	BY230310	R-CHIP;330ohm,5%,1/10W,TP,1608	
AR13	2007-000076	BY230310	R-CHIP;330ohm,5%,1/10W,TP,1608	
AR14	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
AR15	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
AR16	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
AR17	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
AR18	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
AR28	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
AR29	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
AR30	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
AR31	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
AR32	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
AR33	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
AR35	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
AR36	2001-000515	70795019	R-CARBON;2200HM,5%,1/8W,AA,TP,1.8X3.2MM	
AR37	2001-000273	70795007	R-CARBON;100KOHM,5%,1/8W,AA,TP,1.8X3.2M	
AR39	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
AR40	2001-000515	70795019	R-CARBON;2200HM,5%,1/8W,AA,TP,1.8X3.2MM	
AR41	2007-001179	BY230305	R-CHIP;8.2Kohm,5%,1/10W,TP,1608	
AR42	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR43	2007-000092	BY230287	R-CHIP;15Kohm,5%,1/10W,TP,1608	
AR44	2007-001010	BY230360	R-CHIP;51Kohm,5%,1/10W,TP,1608	
AR45	2007-001010	BY230360	R-CHIP;51Kohm,5%,1/10W,TP,1608	
AR46	2007-001179	BY230305	R-CHIP;8.2Kohm,5%,1/10W,TP,1608	
AR47	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR48	2007-000092	BY230287	R-CHIP;15Kohm,5%,1/10W,TP,1608	
AR49	2001-000837	70795045	R-CARBON;51KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
AR50	2007-001010	BY230360	R-CHIP;51Kohm,5%,1/10W,TP,1608	
AR52	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
AR54	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
AR55	2007-000077	BY230278	R-CHIP;470ohm,5%,1/10W,TP,1608	
AZ1	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
AZ2	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
AZ3	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
AZ4	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
AZ5	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
AZ6	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
AZ7	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
AZ8	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
C401	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	
C402	2203-000604	BY130525	C-CER,CHIP:22nF,10%,25V,X7R,TP,1608	
C403	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	
C404	2401-001324	BY130534	C-AL:0.47uF,20%,50V,GP,BK,3X5,2.5	
C404A	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C405	2401-001573	BY130288	C-AL:47uF,20%,50V,GP,TP,6.3x11,2.5	
C406	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C407	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	Not Used D-VR30-S-TF
C410	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C4N01	2203-000140	BY130459	C-CER,CHIP:1.5nF,10%,50V,X7R,TP,1608,-	
C4N02	2401-000408	BY130395	C-AL:10uF,20%,16V,GP,TP,3.5x5,2.5	
C4N03	2203-001607	BY130451	C-CER,CHIP:0.22nF,5%,50V,NP0,-,1608	
C4N04	2401-002569	BY130537	C-AL:2.2uF,20%,50V,GP,TP,4x5,2.5	
C4N05	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C4N06	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C4N07	2203-002041	BY130477	C-CER,CHIP:0.47nF,10%,50V,X7R,TP,1608	
C4N08	2203-000140	BY130459	C-CER,CHIP:1.5nF,10%,50V,X7R,TP,1608,-	
C4N09	2401-000408	BY130395	C-AL:10uF,20%,16V,GP,TP,3.5x5,2.5	
C4N10	2401-000408	BY130395	C-AL:10uF,20%,16V,GP,TP,3.5x5,2.5	
C4N11	2401-002186	BY130536	C-AL:3.3uF,20%,50V,GP,BK,4x5,2.5	
C4N12	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C4N13	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C4N14	2401-000408	BY130395	C-AL:10uF,20%,16V,GP,TP,3.5x5,2.5	
C4N15	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C4N16	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	
C4N17	2203-002041	BY130477	C-CER,CHIP:0.47nF,10%,50V,X7R,TP,1608	
C4N18	2203-002041	BY130477	C-CER,CHIP:0.47nF,10%,50V,X7R,TP,1608	
C4N19	2202-000279	70693047	C-CERAMIC,MLC-AXIAL:47pF,5%,50V,SL,TP,3.	
C4N21	2203-000160	BY130524	C-CER,CHIP:0.0015NF,0.25PF,50V,COG,TP,16	
C4N22	2203-000160	BY130524	C-CER,CHIP:0.0015NF,0.25PF,50V,COG,TP,16	
C4N23	2401-000588	BY130533	C-AL:1uF,20%,50V,GP,TP,3x5,2.5	
C4N24	2401-000588	BY130533	C-AL:1uF,20%,50V,GP,TP,3x5,2.5	
C4N25	2202-002037	BY130027	C-CERAMIC,MLC-AXIAL:100nF,80-20%,50V,Y5V	
C4N30	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C6P01	2202-000797	70795075	C-CERAMIC,MLC-AXIAL:10NF,30%,16V,Y5S,TP,	
C6P04	2203-000681	BY130445	C-CER,CHIP:0.027NF,5%,50V,COG,TP,1608	
C6P05	2203-000681	BY130445	C-CER,CHIP:0.027NF,5%,50V,COG,TP,1608	
C6P06	2203-000440	BY130462	C-CER,CHIP:1nF,10%,50V,X7R,TP,1608,-	
C6P07	2401-003336	BY130545	C-AL:4.7uF,20%,50V,GP,TP,5X5,2	
C6P08	2203-001071	BY130465	C-CER,CHIP:0.056NF,5%,50V,COG,TP,1608	
C6P10	2401-000598	BY130042	C-AL:1uF,20%,50V,GP,TP,4x7,5	
C6P11	2401-000588	BY130533	C-AL:1uF,20%,50V,GP,TP,3x5,2.5	
C6P12	2401-002165	BY130280	C-AL:100uF,20%,16V,GP,TP,6.3x7,5	
C6P13	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C6P15	2203-001140	BY130526	C-CER,CHIP:68nF,10%,16V,X7R,TP,1608	
C701	2301-001679	BY130530	C-FILM,PEF:2.2nF,5%,50V,TP,5.8x3x7mm,-	
C702	2301-001679	BY130530	C-FILM,PEF:2.2nF,5%,50V,TP,5.8x3x7mm,-	
C703	2401-000408	BY130395	C-AL:10uF,20%,16V,GP,TP,3.5x5,2.5	
C704	2401-000408	BY130395	C-AL:10uF,20%,16V,GP,TP,3.5x5,2.5	
C800	2203-005918	BY130489	C-CER,CHIP:1000NF,10%,6.3V,X7R,TP,1608	
C801	2401-001543	BY130543	C-AL:47uF,20%,25V,GP,TP,6.3x5mm,2.5	
C802	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C803	2401-001543	BY130543	C-AL:47uF,20%,25V,GP,TP,6.3x5mm,2.5	
C805	2203-005918	BY130489	C-CER,CHIP:1000NF,10%,6.3V,X7R,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C805B	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C806	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C806B	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C807	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C808	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C810	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C813	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C817	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C818	2203-000815	BY130476	C-CER,CHIP;0.033NF,5%,50V,COG,TP,1608	
C819	2203-000815	BY130476	C-CER,CHIP;0.033NF,5%,50V,COG,TP,1608	
C819B	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C820	2203-000815	BY130476	C-CER,CHIP;0.033NF,5%,50V,COG,TP,1608	
C820B	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C821	2203-000815	BY130476	C-CER,CHIP;0.033NF,5%,50V,COG,TP,1608	
C822	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C824	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C824B	2203-001697	BY130487	C-CER,CHIP;0.082nF,5%,50V,NP0,1608	
C825	2203-000815	BY130476	C-CER,CHIP;0.033NF,5%,50V,COG,TP,1608	
C825A	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C825B	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C826	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C826A	2203-000815	BY130476	C-CER,CHIP;0.033NF,5%,50V,COG,TP,1608	
C826B	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C827	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
C828A	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
C829	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C830	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C831	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C832	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C833	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C833A	2203-000998	BY130446	C-CER,CHIP;0.047NF,5%,50V,COG,TP,1608	
C835	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
C835A	2401-003336	BY130545	C-AL;4.7UF,20%,50V,GP,TP,5X5,2	
C835J	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
C836	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C836A	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C836J	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C837	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C838	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C839	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C841	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C842	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C843	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C844	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C845	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C846	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C847	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C848	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C853	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
C854	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
C891A	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	Not Used D-VR30-S-TF
C891B	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	Not Used D-VR30-S-TF
C901	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C902	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
CE76	2401-003480	BY130339	C-AL;1000UF,20%,10V,LZ,TP,10X16MM,5	
CN3	3711-005612	BY634828	CONNECTOR-HEADER;BOX,30P,2R,2mm,STRAIGHT	
CN4	3711-005612	BY634828	CONNECTOR-HEADER;BOX,30P,2R,2mm,STRAIGHT	
CN5	AC37-00027A	BY634826	CONNECTOR-HEADER;20045WS,X-11,T8.5,W17.4	
CN7	3722-002118	BY634839	JACK-IEEE1394;4P,NL,BLK,ANGLE,IEEE1394	Not Used D-VR30-S-TF
CNC1	2203-001697	BY130487	C-CER,CHIP;0.082nF,5%,50V,NP0,1608	
CNR37	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,-,TP,-,-,	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
CNR37A	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
CNR38	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
CS01	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
CS02	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
CS04	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
D1P105	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1P110	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D4N01	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D4N02	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D501	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
D6P01	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
D801	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D805	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
DOC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DOL1	2901-001273	BY330077	FILTER-EMI SMD;50V,2A,-,220pF,3.2x1.6x0.	
DOL3	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,-,TP,-,-,	
DOL4	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DOR1	2001-000515	70795019	R-CARBON;220OHM,5%,1/8W,AA,TP,1.8X3.2MM	
DOR2	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
DOR3	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
DOR4	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
DOZ1	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
DOZ2	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
DVR1	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	Not Used D-VR15-S-TB, D-VR35-S-TB
DVR2	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	Not Used D-VR15-S-TB, D-VR35-S-TB
DVR3	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	Not Used D-VR15-S-TB, D-VR35-S-TB
DVR4	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	Not Used D-VR15-S-TB, D-VR35-S-TB
FVR6	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
FVR7	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
FZD1	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
FZD2	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
FZD3	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
FZD4	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
FZD5	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
IC4N01	1204-001765	BY631149	IC-AUDIO PROCESSOR;MSP3417D(PQFP),PQFP,4	
IC6P01	1204-001794	BY631157	IC-AUDIO PROCESSOR;LC74775NM-9808,MPF,30	
IC801	1001-001177	BY631316	IC-VIDEO SWITCH;TEA6425D,VIDEO SWITCH ,S	
IC802	1204-002418	BY631321	IC-CHANNEL SELECTOR;SPACE	
J881	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
JACK1	3722-002314	BY634956	JACK-PIN;6P,SN/NI,WH/RD/BL,YE/WH/RD,ANG	
JACK2	3722-002022	BY634955	JACK-PIN;3P,NI,GRN/BLU/RED,ANGLE	
JACK3	3722-002106	BY634840	JACK-PIN;3P+1P,SN/NI,BLK,ANGLE	
L401	AC27-12001N	70796213	COIL CHOKE;10UH-15%,RA,K-30,Q80,150KHZ,-	
L4N01	2701-000188	70796075	INDUCTOR-AXIAL;4.7uH,5%,2434	
L4N02	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L4N03	2701-000188	70796075	INDUCTOR-AXIAL;4.7uH,5%,2434	
L4N04	2701-000119	70796361	INDUCTOR-AXIAL;120uH,5%,2434	
L6P01	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L6P03	2701-000160	70795162	INDUCTOR-AXIAL;22uH,5%,2434	
L6P05	2701-000165	BY330052	INDUCTOR-AXIAL;27uH,5%,2434	
L701	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L702	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L801	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L802	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L803	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L804	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L805	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L806	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L809	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L810	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L811	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
L812	2701-000181	BY330053	INDUCTOR-AXIAL;33uH,5%,2434	
L814	AC27-92001M	70795644	COIL-INDUCTOR;RH3.5X6.5RS,BEAD(RADIAL),-	
LS01	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
MCON1	3708-000270	70795501	CONNECTOR-FPC/FFC/PIC;33P,1.25MM,STRAIGH	
MCON2	3708-000270	70795501	CONNECTOR-FPC/FFC/PIC;33P,1.25MM,STRAIGH	
PC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PE3	2401-003221	BY130499	C-AL;100uF,20%,16V,GP,TP,8X5,2.5	
PE4	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
PE5	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
PE6	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
PE7	2401-003221	BY130499	C-AL;100uF,20%,16V,GP,TP,8X5,2.5	
PL3	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
PL6	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
Q401	0501-000002	BY430105	TR-SMALL SIGNAL;KSA812,PNP,150MW,SOT-23,	
Q6P02	0501-000002	BY430105	TR-SMALL SIGNAL;KSA812,PNP,150MW,SOT-23,	
Q6P04	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
Q802	0504-000129	70795815	TR-DIGITAL;KSR1104,NPN,200mW,47K/47K,SOT	
Q803	0504-000129	70795815	TR-DIGITAL;KSR1104,NPN,200mW,47K/47K,SOT	
Q804	0504-000156	BY530075	TR-DIGITAL;KSR2103,PNP,200MW,22K/22K,SOT	
Q806	0504-000152	BY530078	TR-DIGITAL;KSR2101,PNP,200mW,4.7K/4.7K,S	
Q809	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
Q810	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
Q810J	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
Q891A	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	Not Used D-VR30-S-TF
Q891B	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	Not Used D-VR30-S-TF
QS01	0501-000002	BY430105	TR-SMALL SIGNAL;KSA812,PNP,150MW,SOT-23,	
QS02	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
QS03	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
R201	2001-000977	70795058	R-CARBON;8.2KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R202	2001-000977	70795058	R-CARBON;8.2KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R301	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R302	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R401	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R401A	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R402	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R402A	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R403	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R404	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R406	2007-001010	BY230360	R-CHIP;51Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R408	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	Not Used D-VR30-S-TF
R440	2001-000362	70796067	R-CARBON;150OHM,5%,1/8W,AA,TP,1.8X3.2MM	Not Used D-VR30-S-TF
R441	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	Not Used D-VR30-S-TF
R4N01	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R4N02	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R4N03	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R4N04	2007-000129	BY230307	R-CHIP;27Kohm,5%,1/10W,TP,1608	
R4N05	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R4N06	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R6P01	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R6P02	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R6P03	2007-000081	BY230281	R-CHIP;2.7Kohm,5%,1/10W,TP,1608	
R6P04	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R6P05	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R6P06	2007-000086	BY230283	R-CHIP;5.6Kohm,5%,1/10W,TP,1608	
R6P08	2007-000118	BY230293	R-CHIP;390ohm,5%,1/10W,TP,1608	
R6P12	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R6P13	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	

Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
R6P14	2007-000123	BY230306	R-CHIP;1.5Kohm,5%,1/10W,TP,1608	
R801	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R801A	2007-000116	BY230349	R-CHIP;120ohm,5%,1/10W,TP,1608	
R802A	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R802B	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R803	2007-000122	BY230294	R-CHIP;1.2Kohm,5%,1/10W,TP,1608	
R805	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R805B	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	D-VR30-S-TG, D-VR30-S-TF Only
R805G	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	D-VR30-S-TG, D-VR30-S-TF Only
R805R	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	D-VR30-S-TG, D-VR30-S-TF Only
R806	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R807	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R807A	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
R807J	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R808	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R808A	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
R809	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R810	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R811	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R812	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R813	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R813A	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
R814	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R814B	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
R815	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R816	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R817	2001-000405	70795607	R-CARBON;1800HM,5%,1/8W,AA,TP,1.8X3.2MM	
R818	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
R818A	2007-000450	BY230299	R-CHIP;180ohm,5%,1/10W,TP,1608	
R819	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
R819A	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R820	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R821	2007-000098	BY230291	R-CHIP;56Kohm,5%,1/10W,TP,1608	
R821A	2001-000660	70795032	R-CARBON;33KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R822	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R822A	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R822B	2007-000098	BY230291	R-CHIP;56Kohm,5%,1/10W,TP,1608	
R830	2007-000098	BY230291	R-CHIP;56Kohm,5%,1/10W,TP,1608	
R831	2007-000098	BY230291	R-CHIP;56Kohm,5%,1/10W,TP,1608	
R832	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
R833	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
R839	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
R841	2007-000119	BY230332	R-CHIP;560ohm,5%,1/10W,TP,1608	
R842	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R842J	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R843	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R843A	2007-000965	BY230303	R-CHIP;5.1Kohm,5%,1/10W,TP,1608	
R844	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R845	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R846	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R847	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R853	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R854	2007-000098	BY230291	R-CHIP;56Kohm,5%,1/10W,TP,1608	
R855	2007-000098	BY230291	R-CHIP;56Kohm,5%,1/10W,TP,1608	
R856	2007-000965	BY230303	R-CHIP;5.1Kohm,5%,1/10W,TP,1608	
R891A	2007-000100	70795719	R-CHIP;68Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R891B	2007-000100	70795719	R-CHIP;68Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R892A	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R892B	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R893A	2007-000122	BY230294	R-CHIP;1.2Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R893B	2007-000122	BY230294	R-CHIP;1.2Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
R894A	2007-000129	BY230307	R-CHIP;27Kohm,5%,1/10W,TP,1608	Not Used D-VR30-S-TF
R894B	2007-000129	BY230307	R-CHIP;27Kohm,5%,1/10W,TP,1608	
R900	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	Not Used D-VR30-S-TF
R901	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
RS01	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
RS02	2007-000125	BY230296	R-CHIP;3.9Kohm,5%,1/10W,TP,1608	
RS03	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
RS04	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
RS05	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
RS06	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
RS07	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
RS08	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
RS09	2007-000125	BY230296	R-CHIP;3.9Kohm,5%,1/10W,TP,1608	
RS10	2007-000077	BY230278	R-CHIP;470ohm,5%,1/10W,TP,1608	
SCART	3722-001372	BY634954	JACK-SCART;42P/2R,-,SN,BLK,-	
SJACK	3722-001375	BY634838	JACK-DIN;4P,-,NI,BLK,-	
SVSEL1	1204-001748	BY631283	IC-SELECTOR;MM1503XN,SOP,6P,63MIL,PLASTI	
SW709	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW710	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW711	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW712	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW713A	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
TM401	AC40-00029A	BY633021	TM BLOCK;TCMK0601PD20A,PAL B/G + I + D/	Other Only D-VR30-S-TF Only
	AC40-00038A	BY630493	TM BLOCK-SECAM-L/L',PAL-B/G;TCPL0601PD20	
VC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC13	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,C0G,TP,1608	
VC14	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,C0G,TP,1608	
VC15	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,C0G,TP,1608	
VC16	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,C0G,TP,1608	
VC17	2202-002037	BY130027	C-CERAMIC,MLC-AXIAL;100nF,80-20%,50V,Y5V	
VC18	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,C0G,TP,1608	
VC19	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,C0G,TP,1608	
VC50	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC9	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VDR1	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR2	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR3	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR4	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR5	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR6	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VE1	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7.5	
VE2	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
VE4	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
VE5	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
VE6	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
VE7	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
VIC1	1204-001978	BY631245	IC-VIDEO PROCESS;LA73054,-,36P,-,SSOP,7V	
VIC2	1204-001748	BY631283	IC-SELECTOR;MM1503XN,SOP,6P,63MIL,PLASTI	
VL1	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
VL2	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
VL3	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
VL6	2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
VO1	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
VR10	2007-000119	BY230332	R-CHIP;560ohm,5%,1/10W,TP,1608	
VR11	2001-000969	70795054	R-CARBON;750HM,5%,1/8W,AA,TP,1.8X3.2MM	
VR12	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	


Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
VR13	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
VR14	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
VR30	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
VR31	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
VR33	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
VR34	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
VR49	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
VR51	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR53	2001-000969	70795054	R-CARBON;75OHM,5%,1/8W,AA,TP,1.8X3.2MM	
VR54	2001-000969	70795054	R-CARBON;75OHM,5%,1/8W,AA,TP,1.8X3.2MM	
VR55	2001-000969	70795054	R-CARBON;75OHM,5%,1/8W,AA,TP,1.8X3.2MM	
VSEL1	1204-001748	BY631283	IC-SELECTOR;MM1503XN,SOP,6P,63MIL,PLASTI	
VZ1	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ10	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ11	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ12	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ2	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ3	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ4	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ5	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ6	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ7	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ8	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ9	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
W205	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
W206	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
XT4N01	2801-004096	BY631285	CRYSTAL-UNIT;18.432MHZ,20PPM,28-AAA,16PF	
ZD401	0403-000390	70795272	DIODE-ZENER;UZP33B,31.4-34.6V,1000MW,DO-	
ZD801	0403-000297	BY430024	DIODE-ZENER;MTZ6.2B,5.96-6.27V,500mW,DO-	
ZD805	0403-001211	BY430015	DIODE-ZENER;MTZJ12B,11.8-12.3V,500MW,DO-	
ZD807	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD809	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD811	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD851	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD852	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD853	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD854	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD863	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZDS806	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZDS810	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	

13. Operating Instructions


Description

Front Panel




- | | |
|--|--------------------------------|
| 1. DVD DECK | 11. FRONT PANEL DISPLAY |
| 2. DVD OPEN/CLOSE BUTTON | 12. DVD/VCR SELECT BUTTON |
| 3. VCR DECK | 13. TIME SLIP BUTTON |
| 4. VCR EJECT BUTTON | 14. RECORD BUTTON |
| 5. ON/STANDBY BUTTON | 15. REW(VCR)/SKIP BUTTON (DVD) |
| 6. P-SCAN BUTTON | 16. STOP BUTTON |
| 7. S-VIDEO INPUT JACK | 17. PLAY/STILL BUTTON |
| 8. VIDEO INPUT JACK | 18. F.F(VCR)/SKIP BUTTON (DVD) |
| 9. AUDIO L.R INPUT JACK | 19. TO DVD COPY BUTTON |
| 10. PROGRAM Δ / ∇ BUTTON | 20. TO VCR COPY BUTTON |

Front Panel Display




- | | |
|--|--|
| 1. DVD is activated. | 7. DVD or CD media is loaded. |
| 2. DVD-RAM is activated. | 8. The time, counter position or current deck status is indicated. |
| 3. DVD-R or DVD-RW is activated. | 9. When you set a Timer recording, this indicator will light up. |
| 4. Progressive Scan mode is activated. | 10. VHS Videotape is loaded. |
| 5. Record function is activated. | |
| 6. VCR is activated. | |

Rear Panel



Tour of the Remote Control



1. ON/STANDBY Button

2. NUMBER Button

3. IPC Button

4. VCR Button

Press this when you use a VCR.

5. DVD Button

Press this when you use a DVD.

6. TV Control Buttons

- VOLUME Button
TV volume adjustment
- PROG Button
Press this to select a TV programme.
- TRK Button
Press this to remove the white line.

7. OPEN/CLOSE Button

To open and close the disc tray.

8. VIDEO Plus+ Button

Press this when you use video plus+.

9. Playback-related Buttons

Forward/Rewind, Search, Skip, Stop, Play/Still

10. MENU Button

Brings up the DVD Recorder & VCR's setup menu.

11. TITLE LIST/DISC MENU Button

Press this to enter the TITLE list/Disc menu.

12. OK/DIRECTION Buttons (▲/▼, ◀/▶)

13. RETURN Button

Returns to previous menu.

14. TV/VCR Button

15. DISPLAY Button

This will display current setting or disc status.

16. REC Button

Press this to make a recording on DVD-RAM/-RW/-R discs and VHS Video tape.

17. ZOOM Button

Zooms in on screen.

18. TO DVD copy Button

Press this when you copy from the VCR to the DVD.

19. TV ON/STANDBY Button

20. AUDIO Button

Press this to access various audio functions.

21. TV Button

Press this to operate TV.

22. INPUT SEL Button

Select input signal in external input mode (Tuner or AV1, AV2 or AUX input).

23. F.ADV/SKIP Button

24. MARKER Button

Press this to bookmark or mark a position while playing a disc.

25. QUICK Button

Press this to view the status of the disc that is being played.

26. PLAY LIST/TOP MENU Button

Use this to return to the TOP MENU, or to view the recorded files list.

27. CLEAR Button

28. SUBTITLE Button

Press this to switch the DVD's subtitle language.

29. REC SPEED Button

Press this to set the desired recording time and picture quality.


30. REC PAUSE Button

Press this to pause during recording.

31. TIME SLIP Button

32. TO VCR copy Button

Press this when you copy from the DVD to the VCR.



Connecting & Setting Up

- Quick Overview 17
- Connecting DVD Recorder & VCR to the TV using the RF Cable18
- Connecting the SCART Cable18
- Connecting the Audio/Video Cable20
- Connecting the S-Video Cable20
- Connecting the Component Video Cable .21
- AV Receiver Connections22
- Connecting an external devices to the AUX jacks22

Quick Overview



A Quick overview presented in this guide will give you enough information to start using the DVD Recorder & VCR.

Connections

Connecting DVD Recorder & VCR to the TV using the RF Cable

Connecting the SCART Cable

Connecting the Audio/Video Cable

Connecting the S-Video Cable

Connecting the Component Video Cable



AV Receiver Connections

Connecting an external devices to the AUX jacks

Connecting DVD Recorder & VCR to the TV using the RF Cable




- Make sure that both the television and the DVD Recorder & VCR are switched off before connecting the cables.

- 1 Remove the aerial or network input cable from the television.
- 2 Connect this cable to the 75Ω aerial jack marked  on the rear of your DVD Recorder & VCR.
- 3 Plug the RF Cable supplied into the  jack on your DVD Recorder & VCR.
- 4 Plug the other end of the RF Cable into the connector previously used for the aerial on the television.



- To obtain better quality pictures and sound on your television, you can also connect your DVD Recorder & VCR to the television via the SCART cable if your television equipped with a [scart](#) type of connection.



Connecting the SCART Cable

Case 1 : Connecting DVD Recorder & VCR to the TV using the SCART Cable

You can connect your DVD Recorder & VCR to the television using the SCART cable if the appropriate input is available on the television. You thus:

- Obtain better quality sound and pictures
- Simplify the setting up procedure of your DVD Recorder & VCR




- Regardless of the type of connection chosen, you must always connect the RF Cable.

Otherwise, no picture will be visible on the screen when the DVD Recorder & VCR is switched off.

- Make sure that both the television and the DVD Recorder & VCR are switched off before connecting the cables.

- 1 Connect the Aerial Cable.
- 2 Connect one end of the SCART cable to the AV1 (TV) (TV) jack on the rear of the DVD Recorder & VCR.
- 3 Plug the other end into the appropriate connector on the television.



■ Case 2 : Connecting DVD Recorder & VCR to a Satellite Receiver or Other Equipment

You can connect your DVD Recorder & VCR to a Satellite receiver or other DVD Recorder & VCR using the SCART cable if the appropriate outputs are available on the equipment chosen.

The following illustrations give a few examples of the connection possibilities.

1 AV1 (TV): By means of 21-pin Scart Cable


Plug the SCART Cable with satellite receiver or other equipment into the AV1 (TV) jack on the rear of the DVD Recorder & VCR.

After making this connection, select the source by pressing the **INPUT SEL.** button for the **AV1** input sources.

2 By means of RF Cable

After making this connection, you must preset the station received through the satellite tuner.

RF output channel of the satellite receiver should be adjusted away from channel 60, which is used by the DVD Recorder & VCR, e.g. re-adjust to channel 59.



1 AV2 IN (EXT): By means of 21-pin Scart Cable

Plug the SCART Cable with satellite receiver or other equipment into the AV2 (EXT) jack on the rear of the DVD Recorder & VCR.

After making this connection, select the source by pressing the **INPUT SEL.** button for the **AV2** input sources.


2 By means of RF Cable

After making this connection, you must preset the station received through the satellite tuner.

RF output channel of the satellite receiver should be adjusted away from channel 60, which is used by the DVD Recorder & VCR, e.g. re-adjust to channel 57.

3 AV1(TV) : By means of 21-pin Scart Cable


Connect the end of the SCART cable to the AV1(TV) jack on the rear of the DVD Recorder & VCR. Plug the other end into the appropriate connector on the television.



Connecting the Audio/Video Cable

You can connect your DVD Recorder & VCR to the television using the audio/video cable if the appropriate input is available on the television.


- 1** Connect one end of the video cable into the **VIDEO** output jack on the rear of the DVD Recorder & VCR.
- 2** Plug the other end of the video cable into the appropriate input connector on the television.
- 3** Connect one end of the audio cables supplied into the **AUDIO** output jacks on the rear of the DVD Recorder & VCR.
•Take care to respect the colour coding of the left and right channels.
- 4** Plug the other end of the audio cables into the appropriate input connectors on the television.



Connecting the S-Video Cable

You will enjoy high quality images. S-Video separates the picture element into black and white(Y) and colour(C) signals to present clearer images than composite video output mode.


- 1** Connect one end of the S-Video cable into the **S-VIDEO** output jack on the rear of the DVD Recorder & VCR.
- 2** Plug the other end of the S-Video cable into the appropriate input connector on the television.
- 3** Connect one end of the audio cable supplied into the **AUDIO** output jacks on the rear of the DVD Recorder & VCR.
•Take care to respect the colour coding of the left and right channels.
- 4** Plug the other end of the audio cables into the appropriate input connectors on the television.



Connecting the Component Video Cable


You will enjoy high quality accurate colour reproduction images. Component video separates the picture element into black and white(Y), blue(P_B), red(P_R) signals to present most clear and clean images.

- 1** Connect Component video cables between the **COMPONENT VIDEO OUT** jacks on the rear of the DVD Recorder & VCR and **COMPONENT VIDEO IN** jacks on the rear of the TV.
- 2** Connect audio cables between the audio output jacks on the rear of the DVD Recorder & VCR and **AUDIO IN** jacks on the rear of the TV.
 - Take care to respect the colour coding of the up and down channels.



Progressive Scan

Your TV must support PAL progressive scan input to allow to watch progressive scan component video out. (See page 39)



- For more information about Progressive setting, refer to the page 39~40.
- Make sure that the colour coded connections match. That is, the Y, P_B and P_R component output jacks of your DVD Recorder & VCR should be connected to the exact corresponding component input jacks on your TV. Otherwise, red or blue images will be displayed on the TV screen.
- Consumers should note that not all high definition television sets are fully compatible with this product and may cause artifacts to be displayed in the picture. In case of progressive scan picture problems, it is recommended that you switch the connection to the standard definition output. If there are questions regarding your Toshiba TV set's compatibility with this DVD Recorder & VCR, please contact our customer service centre.



Note

- See your TV User's Manual to find out if your TV supports Progressive Scan. If Progressive Scan is supported, follow the TV User's instructions regarding Progressive Scan settings in the TV's menu system.
- Depending on your TV, the method of connection may differ from the illustration above.
- What is "Progressive Scan"? Progressive scan has twice as many scanning lines as the interlace output method has. Progressive scanning method can provide better and clearer picture quality.
- You must connect the DVD Recorder & VCR to the component(s) before using the Progressive Scan feature.

AV Receiver Connections


To take full advantage of the movie theatre experience that DVD offers, you may want to connect your DVD Recorder & VCR to a complete Surround Sound system, including an A/V Receiver and six Surround Sound speakers.

If your A/V receiver is equipped with a Dolby Digital Decoder, you have the option to bypass the DVD Recorder & VCR's built-in Dolby Digital Decoder.

Use the Digital Audio Out connection below.

To enjoy Dolby digital or DTS sound, you must set up the audio settings (see page 31).

- 1 Connect a Digital Audio coaxial cable from the Digital Audio Out jacks on the rear panel of the DVD Recorder & VCR to their corresponding Digital Audio Input jack on your A/V Receiver:




Connecting an external devices to the AUX jacks

You can connect other audio/video equipment to your DVD Recorder & VCR using audio/video cables if the appropriate outputs are available on the equipment chosen.

- You wish to copy a video cassette with the help of a second VCR.
- You wish to play back and/or copy pictures taken with a camcorder.
- Make sure that both the external devices and the DVD Recorder & VCR are switched off before connecting the cables.


- 1 Connect one end of the video cable into the **VIDEO** input jack on the front of the DVD Recorder & VCR.
- 2 Plug the other end of the video cable into the appropriate output connector on the other system (VCR or Camcorder, etc).
- 3 Connect one end of the audio cable supplied into the **AUDIO** input jacks on the front of the DVD Recorder & VCR.
 - Take care to respect the colour coding of the up and down channels.
- 4 Plug the other end of the audio cable into the appropriate output connectors on the other system (VCR or Camcorder, etc).



<h1>System Setup</h1>	
<ul style="list-style-type: none">• On-Screen Menu Navigation23• Plug & Auto Setup24• Setting the Date and Time25• Auto Setup26• Manual Setup27• Clearing a Preset Station28• Changing the Preset Manual Setup Table ...29• VIDEO Output CH30• Setting Up the Language Options30• Setting Up the Audio Options31• Setting Up the Display(Video) Options ...32• Setting Up the Parental Control33• VCR Setting34• DVD EP Mode Time36• Automatic Chapter Creator36• Front Display37• NICAM38• Video Output38• Setting up the Progressive scan39• Canceling the Progressive scan40	

On-Screen Menu Navigation

The on-screen menus allow you to enable or disable various functions on your DVD Recorder & VCR. Use the following buttons to open and navigate through the on-screen menus.



- 1 MENU Button**
Press this button on the remote control to open the on-screen MENU.
Press again to exit the on-screen MENU.

- 2 ▲/▼,◀/▶ Buttons**
Press these buttons on the remote control to move the selection bar ▲/▼,◀/▶ to cycle through the menu options.

- 3 OK Button**
Press this button on the remote control to confirm any new settings.


- 4 RETURN Button**
Press this button on the remote control to return to the previous MENU screen displayed or to exit the on-screen MENU.

Plug & Auto Setup


The DVD Recorder & VCR will automatically set itself up when it is plugged into the mains for the first time. TV stations will be stored in memory. The process takes a few minutes. The DVD Recorder & VCR will then be ready for use.

- 1** Connect the RF cable as indicated on page 18.
 - Connecting Your DVD Recorder & VCR to the TV using the RF Cable.


- 2** Plug the DVD Recorder & VCR into the mains.
 - “Auto” in the front panel display flickers.




- 3** Start the auto setup.



- 4** Start the auto scanning.



- 5** When the auto scanning is complete, the current time and date will be displayed automatically.



- 6** Check the date and time.
 - if it is: Correct
 - Press **OK** button then the data and time will be saved.
 - if it is: Incorrect
 - Refer to “Setting the Date and Time” (see page 25) menu, when you want to change the date and time.

Auto Setup



- If your clock is set to the wrong time zone or daylight saving, you can adjust these settings without turning off the Auto Clock Set function.

You do not need to preset the stations if you have already set them automatically (see Plug & Auto Setup on page 24).


Your DVD Recorder & VCR contains a built-in tuner used to receive television broadcasts.

You must preset the stations received through the tuner. This can be done:


- Plug & Auto Setup (see page 24)
- Auto Setup
- Manual Setup (see page 27~28)

1 With the unit in Stop mode/No Disc mode, press the **MENU** button.


2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.




3 Press the **▲▼** buttons to select **Install**, then press the **OK** or **▶** button.



4 Press the **▲▼** buttons to select **Auto Setup**, then press the **OK** or **▶** button. The message “Your data will be lost. Press [OK] to continue, [MENU] to exit.” is displayed.



5 Press the **OK** button to start the auto scanning.



- The first frequency band is scanned and the first station found is displayed and stored. And the DVD Recorder & VCR searches for the second station and so on.
- When the automatic scanning procedure has finished, the DVD Recorder & VCR switches automatically to programme 1.
- The number of stations automatically stored by the DVD Recorder & VCR depends on the number of stations that it has found.

6 If you wish to cancel the auto scanning before the end, press the **OK** button.


- The time and date are set automatically from the broadcast signal. If the signal is weak or ghosting occurs, the time and date may not be set automatically.
- Once the auto scanning procedure has finished, some stations may have been stored more than once; select the stations with the best reception and delete the ones no longer required.

Manual Setup


If you have already set them automatically, you do not need to preset the stations manually.

- 1 With the unit in Stop mode/No Disc mode, press the **MENU** button.

- 2 Press the $\blacktriangle/\blacktriangledown$ buttons to select **Setup**, then press the **OK** or \blacktriangleright button.




- 3 Press the $\blacktriangle/\blacktriangledown$ buttons to select **Install**, then press the **OK** or \blacktriangleright button.




- 4 Press the $\blacktriangle/\blacktriangledown$ buttons to select **Manual Setup**, then press the **OK** or \blacktriangleright button.

- 5 Press the $\blacktriangle/\blacktriangledown$ buttons to select the desired PR number, then press the **OK** or \blacktriangleright button.




- 6 Press the $\blacktriangle/\blacktriangledown$ buttons to select **Edit**, then press the **OK** or \blacktriangleright button. **Manual Setup** menu is displayed.



- 7 Press the $\blacktriangleleft/\blacktriangleright$ buttons to start scanning the channels. The frequency band is scanned and the first station found is displayed.

- 8 Press the $\blacktriangle/\blacktriangledown$ buttons to select **Name**. The station name is set automatically from the broadcast signal.


- 9 To change the programme's name, press the \blacktriangleright button.



- | | | |
|----|--|--|
| 10 | To... | Then.... |
| | Select a Character | Press the $\blacktriangle/\blacktriangledown$ buttons until the required name character is displayed (letters, numbers or " - " character) |
| | Move to the next or previous character | Press the $\blacktriangleleft/\blacktriangleright$ buttons respectively. |

Press the **OK** button to save the name.

- 11** Press the ▲▼ buttons to select **Decoder**.
Press the ◀▶ buttons to select **On** or **Off**.
Indicate whether you wish to use a decoder On or Off.



12	If you..	Then....
	Wish to store the station displayed	<ul style="list-style-type: none">• Press the ▲▼ buttons to select MFT.• Press the ◀▶ buttons to adjust the picture, if necessary.• Select Save to store the station.
	Do not wish to store the station displayed	<ul style="list-style-type: none">• Press the ▲▼ buttons to select CH.• Press the ◀▶ buttons to go on scanning the frequency band and display the next station.• Go back to the beginning of step.


- 13** Press the ▲▼ buttons to select **Save**, then press the **OK** button to confirm manual setting.
- Repeat this procedure from step 5 onwards, until all the required stations have been stored.

- 14** Press the **MENU** button to exit the menu.


Clearing a Preset Station

- If you have stored a TV station:
- That you do not require
 - At the wrong programme position you can cancel it.


- 1** With the unit in Stop mode/No Disc mode, press the **MENU** button.
- 2** Press the ▲▼ buttons to select **Setup**, then press the **OK** or ▶ button.



- 3** Press the ▲▼ buttons to select **Install**, then press the **OK** or ▶ button.



- 4** Press the ▲▼ buttons to select **Manual Setup**, then press the **OK** or ▶ button.
- 5** Press the ▲▼ buttons to select the desired PR number, then press the **OK** or ▶ button.



6 Press the ▲▼ buttons to select **Delete**, then press the **OK** or ► button.

7 Repeat the same procedure from Step 5 onwards until all the required stations have been cleared.


8 Press the **MENU** button to exit the menu.

Changing the Preset Manual Setup Table


You can rearrange the Manual Setup Table and give different programme numbers to the manual setup listed according to your own preferences.

1 With the unit in Stop mode/No Disc mode, press the **MENU** button.

2 Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.




3 Press the ▲▼ buttons to select **Install**, then press the **OK** or ► button.



4 Press the ▲▼ buttons to select **Manual Setup**, then press the **OK** or ► button.


5 Press the ▲▼ buttons to select the desired **PR** number, then press the **OK** or ► button.



6 Press the ▲▼ buttons to select **Swap**, then press the **OK** button.

• For example, to move a TV station in programme 1 to programme 3.

7 Press the ▲▼ buttons to select required position, then press the **OK** button again to swap the position.




8 Press the **MENU** button to exit the menu.


VIDEO Output CH

Your DVD Recorder & VCR output channel may need to be changed if the pictures suffer from interference or if your TV cannot find the pictures.

- 1 With the unit in Stop mode/No Disc mode, press the **MENU** button.
- 2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.




- 3 Press the **▲▼** buttons to select **Install**, then press the **OK** or **▶** button.



- 4 Press the **▲▼** buttons to select **VIDEO Output CH**, then press the **OK** or **▶** button.

- 5 Press the **▲▼** buttons to select the desired VIDEO Output channel, then press the **OK** or **▶** button.




Setting Up the Language Options


If you set audio, subtitle, disc menu and on-screen menu language in advance, they will come up automatically every time you watch a movie.

If the selected language is not recorded on the disc, the original pre-recorded language is selected.


- 1 With the unit in Stop mode/No Disc mode, press the **MENU** button.
- 2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.



- 3 Press the **▲▼** buttons to select **Language**, then press the **OK** or **▶** button. Language setup menu will be displayed.



- 4 Press the **▲▼** buttons to select the desired language option, press the **OK** or **▶** button.



- **Audio** : For the disc audio language.
- **Subtitle** : For the disc subtitles.
- **Disc Menu** : For the disc menu contained on the disc.
- **On-Screen Menu** : For the on-screen menu of your DVD Recorder & VCR.

- 5** Press the ▲▼ buttons to select the desired language, then press the **OK** or ► button.




Note

- Press the **RETURN** or ◀ button to return to the previous menu. Press the **MENU** button to exit the menu.
- The selected language will only appear if it is supported on the disc.


Setting Up the Audio Options

Allows you to setup the audio device and sound status settings depending on the audio system in use.

- 1** With the unit in Stop mode/No Disc mode, press the **MENU** button.
- 2** Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.



- 3** Press the ▲▼ buttons to select **Audio**, then press the **OK** or ► button. Audio setup menu will be displayed.



- 4** Press the ▲▼ buttons to select the desired audio option, then press the **OK** or ► button.
- 5** Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.



Note

- Press the **RETURN** or ◀ button to return to the previous menu. Press the **MENU** button to exit the menu.

Digital Output

- **PCM** : Converts to PCM(2CH) 48kHz audio. Select PCM when using the Analog Audio Outputs.
- **Bitstream** : Converts to Dolby Digital Bitstream (5.1CH). Select Bitstream when using the Digital Audio Output.



Note

- Be sure to select the correct Digital Output or no audio will be heard.

DTS

- **Off** : Doesn't output digital signal.
- **On** : Outputs DTS Bitstream via digital output only. Select DTS when connecting to a DTS Decoder.



Note

- When DTS soundtrack is played, sound is not output from Analog Audio Output.

Dynamic Compression

This is only active when a Dolby Digital signal is detected.


- **On** : When Movie soundtracks are played at low volume or from smaller speakers, the system can apply appropriate compression to make low-level content more intelligible and prevent dramatic passages from getting too loud.
- **Off** : You can enjoy the movie with the standard Dynamic Range.

Setting Up the Display (Video) Options


This function allows you to setup the TV screen settings.

- 1 With the unit in Stop mode/No Disc mode, press the **MENU** button.

- 2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.




- 3 Press the **▲▼** buttons to select **Video**, then press the **OK** or **▶** button. Video option menu will be displayed.



- 4 Press the **▲▼** buttons to select the desired video option, then press the **OK** or **▶** button.

- 5 Press the **▲▼** buttons to select the desired item, then press the **OK** or **▶** button.

-  ■ Press the **RETURN** or **◀** button to return to the previous menu. Press the **MENU** button to exit the menu.

TV Aspect

Depending on the type of television you have, you may want to adjust the screen setting. (aspect ratio)

- **4:3 Letter Box** : Select when you want to see the total 16:9 ratio screen DVD supplies, even though you have a TV with a 4:3 ratio screen. Black bars will appear at the top and bottom of the screen.
- **4:3 Pan - Scan** : Select this for conventional size TV when you want to see the central portion of the 16:9 screen. (Extreme left and right side of movie picture will be cut off.)
- **16:9 Wide** : You can view the full 16:9 picture on your widescreen TV.

3D Noise Reduction (motion adaptive noise reduction)

- **Off** : Normal
- **On** : Provides a cleaner picture through noise reduction (for recording).



- This function depends on disc type. It may not work for some disc types.


Setting Up the Parental Control

The Parental Control function works in conjunction with DVDs that have been assigned a rating - which helps you control the types of DVDs that your family watches. There are up to 8 rating levels on a disc.




- 1 With the unit in Stop mode/No Disc mode, press the **MENU** button on the remote control.


- 2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.




- 3 Press the **▲▼** buttons to select **Parental Control**, then press the **OK** or **▶** button.
 - The 'Create the password' message will be displayed.



- 4 Enter the 4-digit password using the 0 to 9 buttons on the remote control.
 - The 'Confirm the password' message will be displayed.



- 5 Enter your password again, and then press the **OK** or **▶** button.





- 6 Press the **▲▼** buttons to select **On**, then press the **OK** or **▶** button. The Parental Control screen appears.



- Press the **RETURN** or **◀** button to return to the previous menu. Press the **MENU** button to exit the menu.
- Refer to Troubleshooting if you forgot your password. (See page 90)

About the Rating Level



- 1 Press the **▲▼** buttons to select **Rating Level**, then press the **OK** or **▶** button.




- 2 Press the **▲▼** buttons to select the rating level you want, then press the **OK** or **▶** button. For example, if you select up to Level 6, discs that contain Level 7, 8 will not play. A larger number indicates that the programme is intended for adult use only.

About the Change Level

- 1 Press the ▲▼ buttons to select **Change Password**, then press the **OK** or ► button.



- 2 Enter the 4-digit password using the 0 to 9 buttons on the remote control.
• The 'Confirm the password.' message will be displayed.



- 3 Enter your password again using the 0 to 9 buttons on the remote control.



- Press the **RETURN** or ◀ button to return to the previous menu. Press the **MENU** button to exit the menu.

VCR Setting




If you want your videotapes to play automatically when you insert them, turn on Auto Play.




- Only tapes that are missing the Record Safety Tab will play automatically when inserted.


- 1 With the unit in Stop mode/No Disc mode, press the **MENU** button.
- 2 Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.



- 3 Press the ▲▼ buttons to select **System**, then press the **OK** or ► button.



- 4 Press the ▲▼ buttons to select **VCR**, then press the **OK** or ► button.




- 5** Press the ▲▼ buttons to select the desired VCR option, then press the **OK** or ► button.

- 6** Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.


Tape Length

This information is usually printed on the tape box. The menu cycles through: E180, E240, E280, E300. Once the type of cassette is set, the VCR can display the amount of time remaining on the tape when you press the **DISPLAY** button.




Auto Play

- **On** - The VCR will automatically begin playing a video tape when it is inserted, as long as the safety tab of the cassette has been removed.
- **Off** - Auto play is disabled.



Auto Repeat


It sets the VCR to play a tape repeatedly (unless a tape control is activated :Stop, Fast Forward or Rewind).



IPC (Intelligent Picture Control)

The Intelligent Picture Control Feature allows you to adjust the sharpness of the image automatically, according to your own preferences.

- **On** - the sharpness of the image is adjusted automatically.
- **Off** - To adjust the sharpness manually.




The Intelligent Picture Control Feature can also be turned on by pressing the IPC button.

Colour System

Before recording or playing back a tape, you can select the required system standard.

Otherwise, the system automatically selects the reception standard when you select Automatic.

- When playing back a tape, the standard is automatically selected by the DVD Recorder & VCR.
- **Automatic** : When playing back a tape, the system standard is automatically selected by the DVD Recorder & VCR.
- **PAL** : PAL video system
- **B/W** : Black and White.




DVD EP Mode Time

You can set the EP (Extended Play) mode's time setting to 6 or 8 hours.


1 With the unit in Stop mode/No Disc mode, press the **MENU** button.

2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.



3 Press the **▲▼** buttons to select **System**, then press the **OK** or **▶** button.

4 Press the **▲▼** buttons to select **DVD EP Mode Time**, then press the **OK** or **▶** button.



5 Press the **▲▼** buttons to select **6 Hours** or **8 Hours**, then press the **OK** or **▶** button.


Automatic Chapter Creator

This function only works with DVD-RW (V mode) and DVD-R discs.

A DVD-Video consists of 'Titles' and 'Chapters'. When you record one program, it makes one Title. If you use this function, the Title will be divided into Chapters.


1 With the unit in Stop mode, press the **MENU** button.

2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.



3 Press the **▲▼** buttons to select **System**, then press the **OK** or **▶** button.


4 Press the **▲▼** buttons to select **Chapter Creator**, then press the **OK** or **▶** button.



5 Press the **▲▼** buttons to select **On**, then press the **OK** or **▶** button.
Press the **MENU** button to exit the menu.

6 Set the recording speed by pressing the **REC SPEED** button on the remote (see page 58 for more information on recording speeds).


- 7** Press the **REC** button to start recording.
The message "Do you want to create the chapter menu after this recording?" is displayed.



- 8** Press the **◀▶** buttons to select **Yes** and press the **OK** button and recording begins.
In XP and SP mode, you must record at least 5 minutes to create a chapter. In LP and EP mode, 15 minutes.

- 9** Press the **STOP** button to stop recording.

- 10** To display the created titles, finalise the disc (see page 86) and then press the **TOP MENU** button. The title menu will be displayed.



- 11** To display the created chapters, select the desired Title and then press the **DISC MENU** button. The chapter menu for the selected Title will be displayed.



Note

- On DVD-RW discs, additional chapters and titles can be added to a finalised disc by unfinalising and recording again. On DVD-RW discs, once finalised, no additional chapters or titles can be recorded.



CAUTION


- The Automatic Chapter Creator function does not work during Timer Recording or when you turn the power off.
- The DVD-R disc cannot be unfinalised.

Front Display

Adjust the brightness of the unit's front panel display.


- 1** With the unit in Stop mode/No Disc mode, press the **MENU** button.

- 2** Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.



- 3** Press the **▲▼** buttons to select **System**, then press the **OK** or **▶** button.

- 4** Press the **▲▼** buttons to select **Front Display**, then press the **OK** or **▶** button.



- 5** Press the **▲▼** buttons to select the desired item, then press the **OK** or **▶** button.


- **Automatic** – Front Panel Display will dim automatically during power off.
- **Bright** – Front Panel Display will be bright all the time.
- **Dim** – Front Panel Display will be dim all the time.

NICAM

NICAM programmes are divided into 3 types. NICAM Stereo, NICAM Mono and Bilingual (transmission in another language). NICAM programmes are always accompanied by a standard mono sound broadcast and you can select the desired sound.


1 With the unit in Stop mode/No Disc mode, press the **MENU** button.

2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.



3 Press the **▲▼** buttons to select **System**, then press the **OK** or **▶** button.

4 Press the **▲▼** buttons to select **NICAM**, then press the **OK** or **▶** button.



5 Press the **▲▼** buttons to select **Off** or **On**, then press the **OK** or **▶** button.

On: NICAM mode.


Off: Only set at this position to record the standard mono sound during a NICAM broadcast if the stereo sound is distorted due to inferior reception conditions.

Video Output


You can enjoy high quality image through RGB or Component video connection.

1 With the unit in Stop mode/No Disc mode, press the **MENU** button.


2 Press the **▲▼** buttons to select **Setup**, then press the **OK** or **▶** button.



3 Press the **▲▼** buttons to select **System**, then press the **OK** or **▶** button.



4 Press the **▲▼** buttons to select **Video Output**, then press the **OK** or **▶** button.



5 Press the **▲▼** buttons to select **Component** or **RGB**, then press the **OK** or **▶** button.

- **Component** : Select this when the Recorder is connected to a TV with Component jack.
- **RGB** : Select this when the Recorder is connected to a TV using SCART cable.

In Component mode, you can set video output to Progressive or Interface, see the table below.

Available video output jacks are as follow.


Available Video Output Jack

Setting mode Output jack		Component mode		RGB Mode
		P-SCAN off mode (Interface mode)	P-SCAN on mode	
Component Output (Y, Pb, Pr)		0	0 (TV in progressive mode)	X
AV1 Scart	R, G, B	X	X	0
	Composite	0	X	X
AV2 Scart	Composite	0	X	0
Composite Video out		0	X	0
S-Video out		0	X	0

Setting up the Progressive scan

If your TV supports PAL Progressive Scan, press the **P-SCAN** button on the front of the DVD Recorder & VCR to enjoy the progressive scan.


- 1 With the unit in Stop mode, press the **P-SCAN** button on the front of the DVD Recorder & VCR. The message "Press [Yes] to confirm Progressive scan mode. Otherwise press [No]" will appear. Press the ◀▶ buttons to select **Yes**, and then press the **OK** button.



- 2 The message "Please, set your TV to Progressive input. To deactivate, press [STOP] key." will appear. Press the **OK** button.



- 3 The message "Video Output Mode Progressive Scan" will appear.



Note

- Progressive setting is only available when the Video Out is set to Component (See page 38).
- If the **P-SCAN** button on the DVD Recorder & VCR's front panel is pressed during playback, the message "This function is possible only on stop mode" appears on the screen.
- Progressive setting is only available when the DVD Recorder & VCR is in stop mode.

Canceling the Progressive scan




Note

- Do not press the **P-SCAN** button if you are using a TV that does not support Progressive mode. Nothing will be displayed on the screen if pressed.
- If you press the **P-SCAN** button by mistake when your TV does not support Progressive mode, you need to release the Progressive mode. To release the Progressive mode, press the **P-SCAN** button on the front panel 3 times. The screen will recover after the **PSO** icon on the front panel display turns off.

System Setup


- 1** With the unit in Stop mode, press the **P-SCAN** button on the front of the DVD Recorder & VCR.
The message "Press [Yes] to confirm Interlace scan mode. Otherwise press [No]" will appear. Press the ◀▶ buttons to select **Yes**, and then press the **OK** button.



- 2** The message "Please set your TV to Interlace input. To deactivate, press [STOP] key." will appear. Press the **OK** button.



- 3** The message "Video Output Mode Interlace Scan" will appear.



Playback

This section introduces basic functions of playback by disc type.



Dolby Digital



DTS



Digital Audio



Stereo



PAL broadcast system
in U.K, France,
Germany, etc.



MP3

◆ DVD Playback

- Before Playing41
- Playing a Disc42
- Using the Disc menu and Title menu43
- Using the Search & Skip Functions43
- Slow Motion Play / Step Motion Play44
- About QUICK44
- Repeat Play45
- Selecting the Subtitle & Audio Language ...47
- Changing the Camera Angle48
- Zooming-In48
- Using the Bookmarks49
- Using the Markers50
- Playing back an Audio CD (CD-DA)51
- Playing back an MP3 Disc52
- Play Option Mode53
- To Programme Tracks53
- Playing back a Picture Disc54

◆ VCR Playback

- Playing back a VHS Tape (VCR)55
- Tracking55
- Special VCR Playback Features55
- Variable Search System56

Before Playing

Read the following information before playing a disc.

■ Region code (DVD-Video only)



Both the DVD Recorder & VCR and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play. The Region Number for this DVD Recorder & VCR is printed on the rear panel of the DVD Recorder & VCR.

■ Disc types that can be played

Disc Types	Disc Logo	Recorded content	Disc Shape	Max. Playing Time
DVD-VIDEO		AUDIO + VIDEO	Single sided(5")	240
			Double sided(5")	480
			Single sided(3.5")	80
			Double sided(3.5")	160
AUDIO-CD		AUDIO	Single sided(5")	74
			Single sided(3.5")	20
DVD-RAM		AUDIO + VIDEO	Single-sided 5" (4.7GB)	1 (XP: Excellent Quality)
				2 (SP: Standard Quality)
				4 (LP: Long Playback)
				6 or 8 (EP: Extended)
DVD-RW		AUDIO + VIDEO	5" (4.7GB)	2 (XP: Excellent Quality)
				4 (LP: Long Playback)
				6 or 8 (EP: Extended)
				12 or 16 (EP: Extended)
DVD-R		AUDIO + VIDEO	5" (4.7GB)	1 (XP: Excellent Quality)
				2 (SP: Standard Quality)
				4 (LP: Long Playback)
				6 or 8 (EP: Extended)
CD-R/RW		JPEG	-	-
DVD-RAM/-RW/-R		MP3	-	-

■ Discs that cannot be played


- DVD-Video with a region number other than "2" or "ALL"
- 3.9 GB DVD-R Disc for Authoring.
- DVD-RAM not recorded following the Video Recording Standard
- Unfinalised DVD-R recorded on other equipment.
- DVD-ROM/DVD+RW/PD/MV-Disc, etc
- CVD/CD-ROM/CDV/CD-G/CD-I



Note

- This DVD Recorder & VCR can only operate with discs that are compatible with DVD-RAM Standard Version 2.0.
- Playback and/or recording may not work for some types of discs, or when specific operations, such as angle change and aspect ratio adjustment, are being performed. Information about the discs is written in detail on the box. Please refer to this if necessary.
- Do not allow the disc to become dirty or scratched, fingerprints, dirt, dust, scratches or deposits of cigarette smoke on the recording surface may make it impossible to use the disc for recording.
- DVD-RAM/-RW/-R discs may not be able to play on some DVD players, depending on the player, disc and the condition of the recording.
- Discs with NTSC programmes recorded on them cannot be recorded using this DVD Recorder & VCR.

Playing a Disc



1

Press the **DVD** button to select the DVD mode.

2

Press the **OPEN/CLOSE** button.

3

Place a disc gently into the tray with the disc's label facing up.

4

- Press **OPEN/CLOSE** button to close the disc tray.
 - Your DVD Recorder & VCR closes the disc tray and plays the disc automatically.
 - The recorder does not play discs automatically after the initial power on.
 - When the recorder is powered on and a disc is in the tray, the unit will be activated and wait in stop status.
 - Press the **PLAY** button to start playback.
 - If you insert an MP3 Disc, your DVD Recorder & VCR will display the file list on the screen and start playing.
 - If you insert a JPEG Disc, folders and files are displayed in thumbnail picture.

5

Press the **STOP** button to stop playback.



Note

- When you stop playing back a disc, the DVD Recorder & VCR remembers where you stopped. When you press **PLAY** button again, it will pick up where you left off. (unless the disc is removed or the DVD Recorder & VCR is unplugged, or if you press the **STOP** button twice.) This function is only applicable to DVD-VIDEO/DVD-RAM/-RW/-R or audio CDs (CD-DA).



CAUTION

- Do not move your DVD Recorder & VCR while playing, as this may cause damage to the disc.
- Make sure to press the **OPEN/CLOSE** button to open or close the disc tray.
- Do not push the disc tray while it is being opened or closed, as this may cause a product malfunction.
- Do not place foreign materials on or in the disc tray.
- Some functions may perform differently or be disabled depending on the disc type. If this occurs, refer to the instructions written on the disc case.
- Be especially careful that children's fingers are not caught between the disc tray and the tray chassis when it closes.
- After turning power on, it will take about 10 seconds before the DVD Recorder & VCR operates.

Using the Disc Menu and Title Menu

Some discs contain a dedicated menu system that allows you to select special functions for title, chapters, audio track, subtitles, film previews, information on characters, etc.

■ For DVD-VIDEO disc



- 1** Press the **DISC MENU** button to enter the disc menu of the disc.
 - Move to the setup menu related to playback operation.
 - You can select audio language and subtitle etc. provided by the disc.
- 2** Press the **TOP MENU** button to move to the title menu of the disc.
 - Use this button if the disc contains more than one title. Some discs may not support the title menu functionality.

■ For DVD-RAM/-RW/-R disc



- 1** Press the **TITLE LIST** button to display title list.



- **Title List** : Title refers to a recorded video stream. Title List shows a list to help you select a title. Since the title list consists of the information on stream that is actually recorded, if one title is deleted, that title cannot be played again.
- **Play List** : This refers to a unit of playback, which is made by selecting a desired scene in the entire Title List. When one playlist is played, only the scene selected by the user will play and then stop. Since only the information necessary for playing a desired scene is included in a playlist, even if that playlist is deleted, the original data will not be deleted.

Using the Search & Skip Functions

■ Searching through a Chapter or Track



During the playback, press the **SEARCH** ◀◀ or ▶▶ button on the remote control. Each time you press the **SEARCH** button, the playback speed will change as follows.

DVD-VIDEO/DVD-RAM/-RW/-R	▶▶Fast X 2 →▶▶Fast X 4 →▶▶Fast X 8 → ▶▶Fast X 16 →▶▶Fast X 32 →▶▶Fast X 128
AUDIO CD(CD-DA)	→▶▶Fast X 2 →▶▶Fast X 4 →▶▶Fast X 8

- You can scan the programme in reverse order. To return to normal speed playback, press the **▶II** button.



- No sound is heard during Scan(Search) mode, except CDs (CD-DA).

■ Skipping Chapters or Tracks



During the playback, press the **I◀◀** or **▶▶I** button on the remote control.

- **If you press the I◀◀ button**
If you press the **I◀◀** button after more than 3 seconds of playback, it moves to the beginning of the chapter, track or marker (DVD-RAM/-RW(VR mode)). Pressing the button again in quick succession to return to the beginning of the previous chapter, track or marker(DVD-RAM/-RW (VR mode)).
- **If you press the ▶▶I button**
If you press the **▶▶I** button, it moves to the next chapter, track or marker(DVD-RAM/-RW(VR mode)).

■ Skipping ahead 30 seconds



In play mode, press **F.ADV/SKIP** button to skip ahead exactly 30 seconds.

Slow Motion Play/ Step Motion Play

■ Slow Motion Play



During pause mode, press the **SEARCH** ◀◀ or ▶▶ button on the remote control for more than 1 second.

- Each time you press the ▶▶ button :
▶▶ Slow 1/8 → ▶▶ Slow 1/4 → ▶▶ Slow 1/2
- Each time you press the ◀◀ button :
◀◀ Slow 1/8 → ◀◀ Slow 1/4 → ◀◀ Slow 1/2

To return to normal speed playback, press the ▶II button.

■ Step Motion Play



During pause mode, press the **F.ADV/SKIP** button on the remote control.

- Each time the button is pressed, a new frame will appear.

To return to normal speed playback, press the ▶II button.



Note

- No sound is heard during STEP or SLOW mode.

About QUICK

The QUICK functions allows you to easily search for a desired scene by accessing title, chapter, track and time. You can also change the subtitle and audio settings and set some features including Repeat, Angle and Zoom.

■ Moving to a scene directly using the QUICK

- If you want to move to a title, a chapter or a track to find a desired scene.

- 1 Press the **QUICK** button during playback.




- 2 Press the ▲▼ buttons to select **Title**, **Chapter** or **Track**.



- 3 Press the ◀▶ buttons or number (0~9) buttons to select the desired scene. Then, press the **OK** button.

- If you want to move to a desired time to help you find a scene.

1 Press the **QUICK** button during playback.



2 Press the **▲▼** buttons to select **Time**.



3 Enter the time in the sequence of hours, minutes, and seconds using the number buttons, then press the **OK** button.



Note

- This may not work for some discs. When an audio CD (CD-DA) or an MP3 disc is inserted, according to a disc type, the information display may not be appear.
- The Time Search function does not operate in some discs.
- To make the screen disappear, press the **QUICK** button again.

Repeat Play



■ Playing Repeatedly (Repeat Playback)



1 Press the **QUICK** button during playback.



2 Press the **▲▼** buttons to select **Repeat**.



3 Select repeat mode (Title or Chapter) using **◀▶** button.

Press the **OK** button.

- To make the screen disappear, press the **QUICK** or **RETURN** button.




Note

- DVD-RAM, DVD-RW(VR mode), unfinalised DVD-RW (V mode) and unfinalised DVD-R do not repeat a chapter.

■ Playing Repeatedly (Repeat Playback)



- 1** Press the **QUICK** button during playback. Repeat is highlighted.



- 2** Press the **▲▼** buttons to select the **Track** or **Disc** you want to play repeatedly. Press the **OK** button. For MP3 discs, you can select **Track**, **Folder** or **Disc**.

- 3** **To return to normal playback**
Press the **CLEAR** button to return to normal playback.

■ Playing a Certain section Repeatedly (A-B Repeat Playback)



- 1** Press the **QUICK** button during playback.



- 2** Press the **▲▼** buttons to select **Repeat**.



- 3** Press the **◀▶** button to select the **A-B**, then press the **OK** button.

- 4** Press the **OK** button at the point where you want the repeat play to start (A) and press it again at the point where you want the repeat play to stop (B). Repeat playback of the A-B section starts.



- If you set point (B) before five seconds has lapsed, the prohibition mark (⊘) will appear.
- Audio CDs (CD-DA) and MP3 discs do not support the Repeat A-B function.

- 5** **To return to normal playback**
Press the **CLEAR** button to return to normal playback.

Selecting the Subtitle & Audio Language



Selecting the SUBTITLE language

Subtitle languages may not work depending on the disc type. This is only available during playback.



Using the SUBTITLE button

- 1 Press the **SUBTITLE** button during playback.



- 2 Press the **▲▼** buttons to select the desired subtitle language.
 - To make the screen disappear, then press the **CLEAR** or **RETURN** button.




Using the QUICK button

- 1 Press the **QUICK** button during playback.



- 2 Press the **▲▼** buttons to select **Subtitle**, then press the **◀▶** buttons to select the desired subtitle language.



Note

- The subtitle display may be different depending on the disc type.
- Some discs allow you to select the language from the disc menu only.


Selecting the Audio language

Audio languages may not work depending on the disc type. This is only available during playback.



Using the AUDIO button

- 1 Press the **AUDIO** button during playback.



- 2 Press the **▲▼** buttons to select the desired audio language.



Using the QUICK button

- 1 Press the **QUICK** button during playback.



- 2 Press the **▲▼** buttons to select **Audio**, then press the **◀▶** buttons to select the desired audio language.



Note

- Audio languages may be different because they are disc-specific.
- Some discs allow you to select the audio language from the disc menu only.

Changing the Camera Angle



QUICK

Using the QUICK button

- 1 Press the **QUICK** button during playback.



- 2 Press the **▲▼** buttons to select **Angle**, then press the **◀▶** buttons or number (0~9) buttons to select the desired angle scene.



Note

- This function is disc-dependent, and may not work all DVDs.
- This function does not work when a DVD has not been recorded with a multi-camera angle system.


Playback

Zooming-In



Using the ZOOM button

- 1 Press the **ZOOM** button during playback.



- 2 Press the **▲▼** buttons to select **On** or **Off**.

QUICK

Using the QUICK button

- 1 Or use the **QUICK** button during playback.



- 2 Press the **▲▼** buttons to select **Zoom**, then press the **OK** button. (🔍) will be displayed.



- 3 Press **▲▼**, **◀▶** buttons to move to the area you want to enlarge.

DVD-VIDEO/
DVD-RAM/-RW/-R

normal size→X2→X4→X2→normal size

- 4 Press the **OK** button.
The screen will be enlarged to twice the normal size. The screen size will be enlarged to four times the normal size.



Note

- When recording is done in the EP mode, the Zoom function will not be supported. (except when the recording has been done in V mode)

Using the Bookmarks



(V mode)

Set marks at scenes you want to see again so that you can start playback from the marked position.

- 1 Press the **MARKER** button during playback.



- 2 Press the **OK** button when the desired scene appears.

- The number 1 is displayed and the scene is memorized.



- 3 Press the **◀▶** button to move to the next position.

- 4 Press the **OK** button again when the desired scene appears.


- The number 2 is displayed and the scene is memorized. Repeat above to bookmark other positions. You can bookmark up to 10 scenes.



Playing back a Bookmark

- 1 Press the **MARKER** button.

- 2 Press the **◀▶** buttons to select a bookmarked scene.



- 3 Press the **OK** or **▶II** button to start playing from the selected scene.


Clearing a Bookmark

- 1 Press the **MARKER** button.

- 2 Press the **◀▶** buttons to select a bookmarked scene.



- 3 Press the **CLEAR** button to delete the selected bookmark.



Using the Markers



- 1 Press the **MARKER** button during playback.



- 2 Press the **OK** button when the desired scene appears.
 - The number 01 is displayed and the scene is memorized.



- 3 Press the **◀▶** button to move to the next position.

- 4 Press the **OK** button again when the desired scene appears.



- The number 02 is displayed and the scene is memorized.
- DVD-RAM or DVD-RW (VR mode) discs have the Marker function instead of the Bookmark function. The Marker function allows you to mark up to 99 scenes. Since the scenes may be displayed as many different pages, numbering is necessary. If a disc in use is encoded with disc Protect, Markers cannot be set or delete. Only playback is available.

Playing back a Marker

- 1 Press the **MARKER** button during playback.

- 2 Press the **◀▶** buttons to select a marked scene.



- 3 Press the **OK** or **▶II** button to start playing from the selected scene.
 - If you press the **NEXT SKIP (▶▶I)** button, playback starts from the next marked point.
 - If you press the **PREVIOUS SKIP (I◀◀)** button after playing the marked point for longer than 3 seconds, playback will start from the beginning of the current marked point. To start playback from previous marked point, press **PREVIOUS SKIP (I◀◀)** button again.

Clearing a Marker

- 1 Press the **MARKER** button during playback.

- 2 Press the **◀▶** buttons to select a marked scene. Press the **CLEAR** button to delete the selected mark.




- When a marker is cleared while DVD-RAM/-RW (VR mode) is playing, marker numbers will change. For example, if the 7th marker is cleared after ten markers are registered, the marker numbers after the eighth will automatically move ahead by one and the 8th marker becomes the 7th.

Playing back an Audio CD (CD-DA)

Each disc has a variety of menu functions available.

■ Playing back an Audio CD (CD-DA)


- 1 Insert an audio CD (CD-DA) into the disc tray.
 - The audio CD menu appears and the tracks (songs) are played automatically.



- Press the menu button when the audio CD menu disappear. Press the **▲▼** buttons to select Disc Navigation, and then press the **OK** button twice.


- 2 Press the **▲▼** buttons to select the track (song) to start playback from, and then press the **OK** button.
 - You can also select the track (song) by pressing the number buttons on the remote control.

■ Audio CD (CD-DA) Screen Elements



1. **Repeat mode:** Repeat off/Repeat Track/Repeat Disc.
2. **Current track (song):** Displays the number of the track currently being played.
3. Displays the current play index and total track number.
4. This shows the operating state of a disc and a playback time corresponding to a portion that is currently played.
5. Displays the track list (song list) and the playing time of each track.
6. Button display.
7. **Play Option:** Normal, Random, Intro or Playlist

■ Buttons on the Remote Control used for CD playback




1. **▲▼, 0~9** : Selects a track (song).
2. **▶** : Plays the selected track (song).
3. **OK button** : Plays the selected track (song).
4. **▶▶I** button : Plays the next track.
5. **I◀◀** button : Returns to the beginning of the current track when pressed during playback.
 - If pressed again, playback starts from the beginning of the preceding track.
 - If you press this button within three seconds after playback starts, the previous track will be played.
 - If you press this button after three seconds, the current track will be replayed from the beginning.
6. **Press the (◀◀/▶▶) button** : Fast Play (▶▶X2, ▶▶X4, ▶▶X8)
7. **■** : Stops a track(song).
8. **▶I** : Plays a track(song) or pauses playback.
9. **QUICK** : To select the top menu on screen display (Repeat or Play Option).

Playing back an MP3 Disc

■ Playing back an MP3 Disc


- 1 Insert an MP3 CD into the disc tray.
Press the ▲▼ buttons to select the **Disc Navigation**, and then press the **OK** or ► button.



- Only disc with both JPEG files and MP3 files will display the Disc Navigation menu.
- For disc with only mp3 files, the mp3 menu is displayed and the tracks (songs) are played automatically.


- 2 Press the ▲▼ buttons to select the **Music**, and then press the **OK** or ► button.

- 3 Press the ▲▼ buttons to select the folder you want to hear, and then press the **OK** button.



- Press the ▲▼ buttons to select the track (song) you want to hear, and then press the **OK** button.
- You can also select the desired track (song) by pressing the number buttons on the remote control.

■ MP3 Screen Elements



1. **Repeat mode** : Repeat off, Repeat Track, Repeat Folder or Repeat Disc
2. **Current track (song)** : Displays the name of the track being played.
3. Displays the current folder and play index.
4. This shows the operating state of a disc and a playback time corresponding to a portion that is currently played.
5. Displays the information for the folder and its tracks.
6. Button display.
7. **Play Option** : Normal, Random, Intro or Playlist

■ Buttons on the Remote Control used for MP3 playback




1. **▲▼, 0~9**: Selects a track (song).
2. **►** : Plays the selected track (song).
3. **OK button**: Plays the selected track (song) or displays the files in the selected folder.
4. **RETURN button**: Moves to the folder to which the current song belongs.
5. **►► button**: Plays the next track.
6. **◄◄ button**: Returns to the beginning of the current track when pressed during playback. If pressed again, playback starts from the beginning of the preceding track.
If you press this button within three seconds after playback starts, the previous track will be played.
If you press this button after three seconds, the current track will be replayed from the beginning.
7. **■** : Stops a track(song).
8. **►||** : Plays a track(song) or pauses playback.
9. **QUICK** : To select the top menu on screen display (Repeat or Play Option).

Play Option Mode


The Play Option can be used with an audio CD or MP3 in the Play or Stop mode.

- 1 Press the **QUICK** button during playback. Repeat mode will be highlighted.



- During Stop, Play option will be highlighted.

- 2 Press the **◀▶** buttons to select **Play Option**.



- 3 Press the **▲▼** buttons to select a desired Play option, then press the **OK** button.

- **Normal** : Tracks on a disc are played in the order in which they were recorded on the disc.
- **Random** : The Random option plays a disc's tracks in random order. After a random list is generated and played completely, another random list is generated and played. Random Play is continued until the play option is changed.
- **Intro** : The first 10 seconds of each track will be played. If you want to listen to the music that you have selected, press the **OK** button or **▶||** button. The play option will be changed to Normal Play. When Intro Play is completed, Normal Play is performed.
- **Playlist** : The Playlist playback option allows you to select the order in which you want tracks to play.


To Programme Tracks

You can register a maximum 30 tracks in the playlist.


- 1 Press the **QUICK** button during playback. Repeat mode will be highlighted.
 - During Stop, Play option will be highlighted.

- 2 Press the **◀▶** buttons to select **Play Option**.


- 3 Press the **▲▼** buttons to select **Playlist**, then press the **OK** button. Playlist screen is displayed.



- 4 Press the **▲▼** buttons to select tracks in the order in which you want them to play, then press the **OK** button.



- 5 If you playlisted a wrong track, press the **▶** button, then press the **▲▼** buttons to select wrong track. Press the **CLEAR** button. The wrong track will be removed.




- 6 Press the **PLAY** button to playback the playlist.
 - The playlist will be played continuously until stop button is pressed.

Playing back a Picture Disc




There are two types of Picture CD. One is a CD with only JPEG files. The other one is a CD with JPEG files and MP3 files.(mixed CD)

- 1 Insert a JPEG into the disc tray.




- The picture menu is displayed (as in Step 4) when the CD with only JPEG files are played.

- 2 Press the ▲▼ buttons to select the **Disc Navigation**, and then press the **OK** or ► button.




- 3 Press the ▲▼ buttons to select the **Photo**, and then press the **OK** or ► button.

- 4 Press the ▲▼◀▶ buttons to select a picture.




- To see the next 6 pictures, press the ►► button.
- To see the previous 6 pictures, press the ◀◀ button.

- 5-1 If you press the ►► button, the Slide show screen will appear. Press the ◀▶ buttons to set the slide show speed, then press the **OK** button.



- 5-2 Press the ◀▶ buttons to select a picture file in Album screen and then press the **OK** button.




- ☰ : Returns to the Album screen.
- ⏮ : The unit enters slide show mode. Before the slide show can begin, the picture interval (Slide show speed) must be set.
- ⏭ : Each time the **OK** button is pressed, the picture rotates 90 degrees clockwise.
- 🔍 : Each time the **OK** button is pressed, the picture is enlarged up to 4X(four times the normal size).
Normal → 2X → 4X → 2X → Normal

- Press the **QUICK** button to display menu bar.
- Press the **RETURN** button to clear the menu bar.

Playing back a VHS Tape (VCR)

To play a standard VHS tape, just insert it into the VCR deck and press the **PLAY** button. You can turn on the Auto Play to enable the VCR deck to play automatically when you insert a videotape that is missing the Record Safety Tab.



- 1** Insert a standard VHS tape into the VCR deck.
 - When a videotape is inserted, power will turn on automatically.
- 2** Press the **VCR** button to select the VCR mode.
- 3** Press the **▶||** (PLAY/PAUSE) button on the remote control or on the front panel of the unit to start playback. The videotape will begin to play automatically if the Record Safety Tab is removed and Auto Play is turned on.
- 4** Press the **■** (STOP) button on the remote control or on the front panel of the unit to stop playback.

Tracking

The Tracking adjustment removes the white lines that sometimes appear during playback because of slight differences in recording decks. The **PROG/TRK** (\wedge/\vee) button will automatically align the recorded tracks with the playback heads to solve this problem. You may also set tracking manually.

- 1** Adjust Tracking Manually
During playback, press the **PROG/TRK** (\wedge/\vee) buttons to remove white lines from the picture.

Special VCR Playback Features

While a videotape is playing, you can enjoy a variety of special playback features, including Still, Frame Advance, Skip, Slow motion, and more.

■ Pause

In Play mode, press **▶||**(PLAY/PAUSE) button to still a single frame.

■ Frame Advance

In the pause mode, press **F.ADV/SKIP** button to advance to the next frame.

■ FPS/RPS

In Play mode, press Forward (**▶▶**) button or Rewind (**◀◀**) button to FPS/RPS :

- Picture Search - Press and release repeatedly to advance the tape forward or backward at variable speeds.
- Jet Search - Press and hold to advance the tape forward or backward at 7 times normal speed. Upon release, it will resume normal playback.



Note

■ The forward (**▶▶**) button and Rewind (**◀◀**) button operate slightly different with front Panel buttons and remote control buttons. When the **▶▶/◀◀** button on the front panel is pressed during playback, there is only one search speed available.

■ Skip

In Play mode, press **F.ADV/SKIP** button to cue ahead exactly 30 seconds. Press **F.ADV/SKIP** button repeatedly up to 4 times to cue ahead 2 minutes.

■ Slow motion

In pause mode, press **▶▶** button for slow motion. Press the **▶▶** button repeatedly to vary slow motion speed from 1/5 to 1/30 of normal playback. Press the **PLAY** button twice to resume normal viewing.

Variable Search System



Each time you record a cassette on this DVD Recorder & VCR, an **index** is automatically marked on the tape when recording starts. The Search function allows you to fast-forward or rewind to a specific index and start playback from that point. Depending on the direction selected, the indexes are numbered as follows


- This DVD Recorder & VCR uses a standard indexing system (VISS). As a result, it will recognize any indexes marked by other VCRs using the same system and vice versa.

Go To [0:00:00] Stop

Use this feature when you want to search for the 0:00:00 counter position on a cassette.

- 1 Press the **CLEAR** button at the point on the tape where you want to set the counter to 0:00:00.

- 2 While a cassette is stopped, press the **QUICK** button.




- 3 Press the **▲▼** buttons to select **Go To [0:00:00]**, then press the **OK** button. The VCR will rewind or fast forward, searching for the 0:00:00 counter position, and then automatically stop at that position.




End Search

Use this feature when you want to search for a blank position to record a programme on a cassette.

- 1 While a cassette is stopped, press the **QUICK** button.




- 2 Press the **▲▼** buttons to select **End Search**, then press the **OK** button. The VCR will fast forward, searching for a blank position, and then automatically stop at that position. If the VCR reaches the end of the tape during end search, the tape will be ejected.




Forward/Backward Intro Scan

Use scan and play when you don't know exactly where a programme is located on a cassette tape.

- 1 While a cassette is stopped, press the **QUICK** button.



- 2 Press the **▲▼** buttons to select **Forward Intro Scan** or **Reverse Intro Scan**, then press the **OK** button. When an Index mark is found the DVD Recorder & VCR will playback the tape for 5 seconds, after which it will continue searching for the next Index mark.



Recording

This section shows various DVD recording methods.

- ◆ **DVD Recording**
 - **Before Recording**57
 - **Recording the current Programme you are watching**59
 - **Recording From External Devices**60
 - **Watching the Images Being Recorded (Time Slip)**60
 - **Making a One Touch Recording(OTR)**61
 - **Making a Timer Recording**61
 - **Editing the Scheduled Record List**63
 - **Deleting the Scheduled Record List**64
 - **Using the Video Plus+ Feature**65
 - **Video Plus+ Extended**66




- ◆ **VCR Recording**
 - **Basic VCR Recording**66
 - **Check Remaining Time**67
 - **Special Recording Features**67
 - **Copy to DVD or VCR**68

Before Recording

This unit can record on various types of discs. Before recording, read the following instructions and select the disc type according to your preference.

Recordable discs

This recorder can record on the following discs.

DVD-RAM	DVD-RW	DVD-R
		

- DVD-RWs and DVD-RAMs are rewritable.
- DVD-Rs are non-rewritable.

Compatibility between Toshiba and Other Company's Recorder.

Disc Types	Recording format	Recording Device	Finalising	Additional Recording in Toshiba Recorder
DVD-RAM	VR Mode	Toshiba	X	Recordable
		Other Company	X	Recordable
DVD-RW	VR Mode	Toshiba	finalised	Not recordable
			not finalised	Recordable
		Other Company	finalised	Not recordable
			not finalised	Recordable
	V Mode	Toshiba	finalised	Not recordable
		Other Company	finalised	Not recordable
DVD-R	V Mode	Toshiba	finalised	Not recordable
			not finalised	Recordable
		Other Company	finalised	Not recordable
			not finalised	Not recordable



Note

Finalise

- This closes the DVD-RW/-R so no additional recording can be done.

Unfinalise

- This allows additional recording on a DVD-RW disc originally recorded on the DVD Recorder & VCR
- A DVD-RW disc that has been recorded by DAO(Disc At Once) in a PC cannot be unfinalised.
- A DVD-RW disc that has been recorded in V Mode of a different maker's recorder cannot be unfinalised.
- A DVD-R disc cannot be unfinalised.

■ Recording Formats

Since available functions differ depending on the disc type, select a disc that best fits your preferences. When you insert an unused disc, the following message appears.


DVD-RAM: Use after formatting the disc.



DVD-RW: When an unused DVD-RW disc is first inserted, the message "Do you want to initialize this disc" will be displayed. If you select Yes, the disc will be formatted in VR mode.



If you want to change the mode, refer to [Formatting a Disc on page 85](#).



DVD-R: Formatting DVD is unnecessary and only V mode Recording is supported.

DVD-RW (V mode)/-R

- Chapters will be created automatically when you finalise recording on DVD-RW/-R discs in V mode with the Chapter Creator has been set to On.
- Simple editing (erasing titles/changing title name).

DVD-RW (VR mode)/-R

- This mode involves multiple editing functions (such as deletion of the whole title, partial deletion of a title, etc.).
- Various editing options using a created Playlist.

■ Recording Mode

Select one of four recording modes by pressing the **REC SPEED** button repeatedly while the unit is in Stop mode for the desired recording time and picture quality. In general, picture quality improves as the recording time decreases.

In AUTO Mode, the most suitable record mode is adjusted automatically, according to remaining time on the disc and length of the timer recording.

This function is selected only one mode in XP, SP, LP and EP modes and you can use this mode for timer recording.

Mode	Characteristic	Recording Times Data Rates
XP (high quality mode)	Select when the video quality is important.	Approx. 1 hours about 8 Mbps
SP (standard quality mode)	Select to record in standard quality.	Approx. 2 hours about 4 Mbps
LP (long recording mode)	Select when a long recording time is required.	Approx. 4 hours about 2 Mbps
EP (extended mode)	Select when a long recording time is required.	Approx. 6 hours/ about 1.2 Mbps Approx. 8 hours/ about 0.8 Mbps
AUTO	for timer recording only see page 62.	Approx 60 to 480 Min Approx 0.8 to 8Mbps

■ Unrecordable video

Pictures with copy protection cannot be recorded on this DVD Recorder & VCR.

When the DVD Recorder & VCR receives a copy guard signal while recording, recording stops and the following message appears on the screen.



Concerning Copy Control Signals

TV broadcasts that contain copy control signals may have one of the following three signal types, Copy-Free, Copy-Once and Copy-Never. If you want to record a copy-once type programme, use DVD-RW with CPRM in VR Mode and DVD-RAM.

	Copy-Free	Copy-Once	Copy-Never
DVD-RW(Ver.1.1)	O	-	-
DVD-RW(Ver.1.1) with CPRM			
VR mode	O	O*	-
V mode	O		-
DVD-R	O	-	-
DVD-RAM(Ver.2.0)	O	O*	-

Once **Copy Once** has been recorded, additional recording cannot be performed.

This * marked parts are compatible with CPRM.

- Content Protection for Recordable Media (CPRM)

CPRM is a mechanism that ties a recording to the media on which it is recorded. It is supported by some DVD recorders, but not by many DVD players. Each blank recordable DVD has a unique 64-bit media ID etched in the BCA. When protected content is recorded onto the disc, it can be encrypted with a 56-bit C2 (Cryptomeria) cipher derived from the media ID. During playback, the ID is read from the BCA and used to generate a key to decrypt the contents of the disc. If the contents of the disc are copied to other media, the ID will be absent or wrong and the data will not be decryptable.

Recording the current programme you are watching



1. Check the antenna cable is connected.
2. Check the remaining time on the disc.
DVD-RAM/RW discs should be formatted in advance before beginning recording. Most new discs are sold unformatted. Make sure to format your unformatted discs before recording.

1 Press the **OPEN/CLOSE** button and place a recordable disc on the disc tray.

2 Press the **OPEN/CLOSE** button to close the disc tray.
Wait until **LOAD** disappears from the front panel display.

3 Press the **PROG/TRK** (\wedge/\vee) buttons or number buttons to select the programme you want to record.

4 Press the **REC SPEED** button repeatedly, to select the recording speed (quality).

- XP (High, approx. 1 hour) → SP (Standard, approx. 2 hours) → LP (Low, approx. 4 hours) → EP (Extended Play, approx. 6hours/8hours)



5 Press the **REC** button.
• “●” is displayed on the screen and recording begins.

6 Press the **STOP** button to stop or finish a recording in progress.
• The message “Updating the information of disc. Please wait for a moment” is displayed.

■ Pausing / Resuming

- Press the **REC PAUSE** button to pause a recording in progress.
- Press the **REC PAUSE** button again during pause to resume recording.
- You can switch channels by pressing the **PROG/TRK** (\wedge/\vee) buttons while recording pauses.



Note

- You can not change the recording mode and the programme while recording.
- Recording will stop automatically if there is no free space left for recording.
- Up to 99 titles can be recorded onto a disc.
- If the power interrupted due to power failure or other reasons, the title being recorded will not be saved onto the disc.
- Recording will stop automatically if a copy protected image is selected.
- Do not use DVD-R authoring discs with this unit.

Recording From External Devices

Follow these directions to record onto a disc or a tape from External Devices.

- 1 Connect the output jack of your External Devices to the SCART input connector by SCART cable or AUX on the front by Audio/Video Cable.

- 2 Power on your DVD Recorder & VCR and switch to AV mode by pressing the **INPUT SEL** button on the remote control. The front panel display changes in the following sequence

→ PR → AV1 → AV2 → AUX →

- 3 Press the **REC SPEED** button repeatedly to select the recording speed(quality).

→ SP → LP → EP → XP →

- 4 When your DVD Recorder & VCR is in the stop mode, set the operation mode of your External Devices to play mode.

- 5 Press the **REC** button on your DVD Recorder & VCR when the image from which you want to start recording is displayed.

- 6 Press the **STOP** button on your DVD Recorder & VCR when the recording is finished.



Note

- Also refer to the user manual for your External Devices when recording through Audio/Video or Scart input.

Watching the Images Being Recorded (Time Slip)



This function allows you to watch the recently recorded images on the screen while a recording is in progress, with a 10 second delay.

- 1 Press the **● (REC)** button on the remote control.
 - Wait 10 seconds and press the **TIME SLIP** button.
 - The recently recorded images are played back on the screen, with a 10 second delay.
 - On the TIME SLIP screen, you can playback, scan, or perform other operations for the recorded program using the playback related buttons. Press the **◀◀** button to scan the recording in the reverse order, from the end to the start. Press the **▶▶** button to scan to the recently recorded 10- second images.

- 2 Press the **■ (STOP)** button once to clear the TIME SLIP function.
 - To stop a recording while a TIME SLIP function is in progress, press the **■ (STOP)** button twice.



Note

- The Time Slip feature only works with DVD-RAM discs.
- Time Slip function - Pause TV operation
To enable Pause TV while watching a live programme on the DVD Recorder proceed as follows:
 - 1) Ensure DVD-RAM disc is inserted.
 - 2) Press Record **● (REC)** button.
 - 3) Allow recording to continue for 10 seconds.
 - 4) Press 'TIME SLIP' button.
 - 5) Press Play/Pause button.
 - 6) When desired, press Play/Pause button once more to commence playback and view the recorded programme on the screen from the original Pause position.

Making a One Touch Recording (OTR)



One-Touch Recording (OTR) allows you to add recording time from 30 minutes up to 9 hours by pressing the **REC** button:

- 30-minute increment up to 4 hours
- 1-hour increment from the 4th hour to 9 hours

1 Press the **PROG/TRK** (\wedge / \vee) buttons or number buttons to select the programme to record. If you want to record through a connected external component, press the **INPUT SEL.** button to select an appropriate external input (AV1, AV2, or AUX).

2 Press the **REC** button.

3 While in Record mode, press the **REC** button again to activate One-Touch Recording (OTR).
• Record length 0:30 appears on the On-Screen Display and the DVD Recorder & VCR will record for exactly 30 minutes.

4 Continue pressing **REC** to add recording time from 30 minutes to 9 hours.
• The DVD Recorder & VCR stops recording automatically when the time has elapsed.

To stop recording

Press the **STOP** (■) button.
The message "Press **STOP** button once more to cancel Timer Record" is displayed.
Press the **STOP** (■) button again.
The message "Updating the Information of disc. Please wait for a moment" is displayed.



- The timer counter decreases by minute to 0:00, then the DVD Recorder & VCR stops recording.

Making a Timer Recording




1. Check the antenna cable is connected.
2. Check the remaining time of the disc.
3. Check the date and time are correct.
Make sure the Clock (Setup-Clock Set) must be set before you proceed with a timer recording.
(See page 25)

1 Press the **OPEN/CLOSE** button, and place a recordable disc on the disc tray.


2 Press the **OPEN/CLOSE** button to close the disc tray. Wait until **LOAD** disappears from the front panel display.

3 With the unit in Stop mode, press the **MENU** button.

4 Press the \blacktriangle / \blacktriangledown buttons to select **Programme**, then press the **OK** or \blacktriangleright button.



5 Press the \blacktriangle / \blacktriangledown buttons to select the **Standard Timer**, then press the **OK** or \blacktriangleright button twice.
• The Timer Recording screen is displayed.



6 Fill in the items using the ▲▼◀▶ buttons.

- ◀▶ : Moves to the previous/next item,
- ▲▼ : Sets a value.

- **To** : Select the media to record DVD or VCR.
- **PR** : The video input source (AV1, AV2 or AUX), or the broadcasting channel you want to make a timer recording from.
- **Day** : Set the recording day.
Daily, MO-SA, MO-FR, W-SA, ...W-SU, MON01, ...WED31
- **Start/End Time** : Start and end time of the timer recording.

• Recording Speed (DVD)

AUTO : Select when you want to set video quality automatically. In AUTO Mode, the most suitable record mode is adjusted automatically, according to remaining time on the disc and length of the timer recording. This function is selected only one mode in XP, SP, LP and EP modes and you can use this mode for timer recording.

XP (high quality) : Select when audio and video qualities are important. (Approx. 1 hour)

SP (standard quality) : Select to record in standard quality. (Approx. 2 hours)

LP (low quality) : Select when a long recording time is required. (Approx. 4 hours)

EP (extended mode) : Select when a longer recording time is required. (Approx. 6 hours at 1.2Mbps or Approx. 8 hours at 0.8 Mbps.)

• Recording Speed (VCR)

AUTO : Select when you want to set video quality automatically. It depends on remaining time of VCR tape.

SP : Standard Play, for best picture quality.

LP : Long Play, for maximum recording time (3 times SP).

• V/P(VPS/PDC)

VPS : Video Programme System

PDC : Programme Delivery Control

- Do not select V/P unless you are sure the programme you wish to record is broadcast with VPS/PDC. If you do set V/P to On, then you must set up the start-time EXACTLY according to the published TV schedule. Otherwise the timer recording will not operate.



- When you are recording at EP mode on a DVD-RW (V mode)/-R disc, it may not record the full 6 or 8 hours because the unit uses the VBR(Variable Bit Rate) ENCODING system. For example, if you record a programme with a lot of action, it uses a higher bit rate which in turn consumes more disc memory.

7 Press the OK button.

If the timer settings overlap

The programmes are recorded in order of priority. If timer recording is set for the first programme and then again for the second programme and both programmes overlap, the following message will appear on the screen: "This setting is identical with 1" The message shows that the first programme has priority. After recording of the first programme is complete, the second programme starts being recorded.

To exit without saving the current setting

Press the **MENU** or **RETURN** button.

To return to the previous menu

Press the **RETURN** button if you don't want to set a timer recording.

8 Turn the power off to finish the timer recording.

- ⏻ will blink if disc or tape is not inserted.
- ⏻ will appear on the front panel. It means that a timer recording is registered.





- The timer recording time may differ from the set time depending on disc status and overall timer recording status (for example, recording times overlapping, or when the previous recording ends within 3 minutes before the start time of the next recording.)

Editing the Scheduled Record List




Follow these directions to edit the timer record list.


- 1** With the unit in Stop mode, press the **MENU** button.
- 2** Press the **▲▼** button to select **Programme**, then press the **OK** or **▶** button.
- 3** Press the **▲▼** button to select **Standard Timer**, then press the **OK** or **▶** button.



- 4** Press the **▲▼** button to select the number of the scheduled record list you want to edit, then press the **OK** or **▶** button.
 - The Edit and Delete items are displayed.



- 5** Press the **▲▼** button to select **Edit**, then press the **OK** or **▶** button.
 - The Timer Recording screen is displayed. Edit the items you want to modify. See the Timer Recording section for more information on Timer Recording Input items. (See page 62)



- 6** Press the **OK** button to confirm the edited setting.
- 7** Press the **MENU** button after finishing the operation. The menu screen will disappear.


Deleting the Scheduled Record List




Follow these directions to delete a title from the timer record list.

1 With the unit in Stop mode, press the **MENU** button.

2 Press the **▲▼** button to select **Programme**, then press the **OK** or **▶** button.




3 Press the **▲▼** button to select **Standard Timer**, then press the **OK** or **▶** button.




4 Press the **▲▼** button to select the number of the scheduled record list you want to delete, and then press the **OK** button.

- The Edit and Delete items are displayed.



5 Press the **▲▼** button to select **Delete**, then press the **OK** or **▶** button.

- You will be prompted with the delete confirm message such as "Do you want to delete 'No.01'?".



6 Press the **◀▶** buttons to select **Yes**, then press the **OK** button.

- The selected title will be deleted from the list.

7 Press the **MENU** button after finishing the operation.
The menu screen will disappear.



Note

- You can not delete programmes that are currently recording.

Using the Video Plus+ Feature



Before presetting your DVD Recorder & VCR:


- Switch on both the television and your DVD Recorder & VCR.

- Check that the date and time are correct.

Up to twelve programmes can be preset.


- 1 With the unit in Stop mode, press the **MENU** button.

- 2 Press the **▲▼** button to select **Programme**, then press the **OK** or **▶** button.



- 3 Press the **▲▼** buttons to select **Video Plus+**, then press the **OK** or **▶** button.

- A message is displayed to allow you to enter the Video Plus+ code.





- 4 Press the number buttons to enter the code of the programme that you want to record in your television magazine.

- If you want to correct the Video Plus+ code that you are entering:
- Press the **◀** button until the digit to be corrected is cleared.
- Enter the correct digit.

- 5 Press the **OK** button.

- The information concerning the programme is displayed.
- When using the Video Plus+ function for the first time with stored stations, the programme number flashes. This one time, you must enter the PR number manually by pressing the **▲▼** buttons or number buttons.



- 6 If the programme and times are correct, press the **OK** button.

- 7 Turn the power off by pressing the **ON/STANDBY** button to activate the timer recording setting.

- 8 Refer to pages 63~64 if you want to:
 - Check whether the timer Recording has set correctly or not.
 - Cancel a preset recording.



Note

- The numbers next to each TV programme listing in the magazines or newspapers are Video Plus+ code numbers, which allow you to programme your DVD Recorder & VCR instantly with the remote control. Enter the Video Plus+ code for the programme you wish to record.
- Video Plus+ is a trademark of Gemstar Development Corporation. The Video Plus+ system is manufactured under licence from Gemstar Development Corporation.


Video Plus+ Extended

To prevent delays or over-runs the DVD Recorder & VCR has a function called Video Plus+ Extended allowing you to extended the recording time by up to 60 minutes.


- Only use if PDC is not available or set to OFF.

1 With the unit in Stop mode, press the **MENU** button.

2 Press the **▲▼** buttons to select **Programme**, then press the **OK** or **▶** button.



3 Press the **▲▼** buttons to select **Video Plus+ Extended**, then press the **OK** or **▶** button.



4 Press the **▲▼** buttons to select the Video Plus+ Extended time, then the press **OK** or **▶** button.

5 Press the **MENU** button to exit the menu.

Basic VCR Recording

Before starting

1. Check TV channel and Antenna connections.
2. Check the remaining time on the tape.

You can record a TV show in progress by inserting a blank tape and pressing the **●(REC)** button. You can even add recording time from 30 minutes up to 9 hours by pressing the **●(REC)** button repeatedly.



- Be sure your videotape has a Record Safety Tab. If the tab is missing, you can cover the opening with a small piece of tape.



- **Warning:** Do not cover this opening unless you are sure you want to record over the tape.

1 Insert a blank VHS tape into the VCR deck.
• Make sure the tape is long enough to record the entire programme.

2 Press **VCR** button to select the VCR mode.

3 Press the **0–9** buttons or the **PROG/TRK** (**▲/▼**) buttons to select the desired channel.
Press the **INPUT SEL.** button to select AV1, AV2 or AUX if recording from an external device connected to the front or rear inputs, respectively.

4 Press the **REC SPEED** button on the remote control to set the Record Speed to one of the following options:
• **SP** – Standard Play, for best picture quality.
• **LP** – Long Play, for maximum recording time (3 times SP).



- The selected Record Speed will appear on the front panel display and on-screen display.

Maximum Recording Time - SP vs. LP

Tape Length	Recording Time (in SP)
E180	180 mins or 3 hours
E240	240 mins or 4 hours
E280	280 mins or 4 hours and 40mins
E300	300 mins or 5 hours



Note

- When you watch or record on the VCR during DVD Recording, some function buttons may not operate. The message "This function is not available." will be displayed.

- 4 Press the **•(REC)** button on the remote control or front panel.
For options while recording is in progress, see "Special Recording Features".


- 5 Press the **STOP** button to stop or finish a recording in progress.

■ Pausing / Resuming

- Press the **REC PAUSE** button to pause a recording in progress.
- Press the **REC PAUSE** button again during pause to resume recording.
- You can switch programme by pressing the **PROG/TRK** (\wedge/\vee) buttons while recording pauses.

Check Remaining Time

- 1 Press **DISPLAY** button on the remote control. Following information will be displayed.
(Current deck status, recording speed, remaining time, input mode, current time.)



Special Recording Features

While a recording is in progress, you can watch a different channel, watch a different media, or add recording time. (see page 61)

1 Watch a Different Channel

When you watching through the Antenna input during recording, press the TV/VCR button on the remote control. Change the programme you want to watch.
When you watching through AV input during recording, change the input of your TV from AV to Antenna. Change the programme you want to watch.

2 Watch a different media during recording

You can watch a DVD during VCR recording or watch a Video tape during DVD recording.

- During VCR recording, insert a DVD in the DVD deck. The output will automatically change to the DVD and start playback.
- During DVD recording, insert a Video tape in the VCR deck. The output will automatically change to the VCR and start playback. (Only if tape is missing the safety tab)

3 Add Recording Time

Refer to the One-Touch Recording (OTR).
(See page 61)

4 Recording DVD and VCR at the same time

You can record DVD and VCR at the same time, but both modes must be set up to record separately.

- Press the **DVD** or **VCR** button to set the unit to DVD or VCR mode respectively.
- Choose input mode (PR, AV1, AV2 or AUX) for DVD or VCR.
- Choose **REC SPEED** for DVD or VCR.
- Press **REC** button for DVD or VCR.



Note

- When DVD Recorder & VCR is connected to your TV using S-Video or component video cable, the playback screen on the video tape will not display during DVD recording.
- You cannot record different channels at the same time, however you can record from different input source at the same time.
- The DVD and VCR cannot start recording at the exact same time. You must set one mode to start recording, then the other.

Copy to DVD or VCR




You can copy from the DVD to VCR or VCR to DVD.
Check the remaining time on the tape.

To copy from DVD to VCR




(VR mode)


- 1 With the unit in Stop mode, press the **MENU** button.
- 2 Press the **▲▼** buttons to select **Copy**, then press the **OK** or **▶** button.




- 3 Press the **▲▼** buttons to select **DVD → VCR**, then press the **OK** or **▶** button.




- 4 Press the **▲▼** buttons to select **Edit Copylist**, then press the **OK** or **▶** button.



- 5 Press the **▲▼** buttons to select desired copylist, then press the **OK** or **▶** button.



- 6 Press the **▲▼** buttons to select **Copy**, then press the **OK** or **▶** button.



Direct copy DVD to VCR

- Insert a DVD disc you want to copy.
- Insert a VHS tape.
- Press the VCR copy button on the remote control or TO VCR button on the front panel.
- To stop recording, press the **STOP** button.




Note

- If you want to make a new Copylist and copy this scene directly from the Edit Copylist, select the New Copylist and make scene. This is the same function as creating the New Playlist (See page 76).


■ To copy from VCR to DVD

1 With the unit in Stop mode, press the **MENU** button in stop mode.


2 Press the **▲▼** buttons to select **Copy**, then press the **OK** or **▶** button.



3 Press the **▲▼** buttons to select **VCR-->DVD**, then press the **OK** or **▶** button.




4 You can use the **▶II**, **I◀◀** or **▶▶I**, **◀◀** or **▶▶** buttons to search for the Start position. Press the **OK** button at the start point.




5 You can use the **▶II**, **I◀◀** or **▶▶I**, **◀◀** or **▶▶** buttons to search for the end position. Press the **OK** button at the end point.


- A copylist will be generated.
- Repeat the above steps to create the copylist.
- In VCR mode, the copylist cannot be saved.



6 Press the **▲▼** buttons to select desired copylist, then press the **OK** or **▶** button.



7 Press the **▲▼** buttons to select **Copy**, then press the **OK** or **▶** button.



- The VCR will fast forward, searching for a start position and then automatically start a copy.
- It may not be match up with Start and END point exactly.
- If you want to copy all copylists, select **Copy All**.

■ Direct copy VCR to DVD

- Insert the VHS tape you want to copy.
- Insert Recordable DVD disc.
- Press DVD copy button on the remote control or TO DVD button on the front panel.
- To stop recording press the **STOP** button.

Editing

This section introduces basic functions of DVD editing and explains both edit functions for the recording on a disc and edit functions for the entire disc.

- *Playing the Title List*70
- *Basic Editing (Title List)*72
- *Advanced Editing (Playlist)*76
- *Disc Manager*84


Playing the Title List



Follow these instructions to play back a scene from the Title List.

Using the TITLE LIST button

- 1 Press the **TITLE LIST** button.
The Title List screen is displayed.




- 2 Press the **▲▼** buttons to select a title you want to play from Title List, and then press the **PLAY** button.
The selected title will be played back.


- 3 To stop title play, press the **STOP** button.
To return the title list screen, press the **TITLE LIST** button.

Using the MENU button


- 1 Press the **MENU** button.




- 2** Press the **▲▼** buttons to select **Disc Navigation**, then press the **OK** or **▶** button twice. The Title List screen is displayed.



- 3** Press the **▲▼** buttons to select **Title**, then press the **OK** or **▶** button. The Edit menu is displayed: Play, Rename, Delete, Edit, Protection (See pages 72~75)



- 4** Press the **▲▼** buttons to select **Play** to play the title list, then press the **OK** button. The selected title will be played back.



- 5** Press the **STOP** button to stop playing. To return the title list screen, press the **TITLE LIST** button.




Note

- You can also play a recorded programme by pressing the **QUICK** button.



- Press the **▲▼** buttons to select **Title**.
- Press the **◀▶** buttons to select to play the title list, then press the **OK** button.

Title List Screen Elements



- Playback screen for recorded titles.
- Information window for the selected title: Title name, recording date, recording time, lock status, recording mode
- Recorded title No.
- Recorded title name
- Recording Length (i.e., the playing time)
- Edit menu
Play: Plays the selected title.
Rename: Renames the title of a selected title.
Delete: Deletes the selected title from the list.
Edit: Deletes a section of title.
Protection: Locks or unlocks the selected title.
- Button display.



Note

- This may depend on the type of disc.
- DVD-RW (V mode)/-R has limited editing function.

Basic Editing (Title List)

I Renaming (Labeling) a Title


Follow these instructions to rename a title list, i.e., to edit the title of a recorded programme.




- 1** Press the **TITLE LIST** button.
The Title List screen is displayed.

Or use the **MENU** button:


- Press the **MENU** button.
- Press the **▲▼** buttons to select **Disc Navigation**, then press the **OK** or **▶** button twice.




- 2** Press the **▲▼** buttons to select a title you want to rename from the **Title List**, then press the **OK** or **▶** button.



- 3** Press the **▲▼** buttons to select **Rename**, then press the **OK** or **▶** button.
The Rename screen is displayed.




- 4** Select the desired characters using the **▲▼◀▶** buttons, press the **OK** button.



- **Back Space**: Moves the cursor one position backwards.(Equivalent to the **CLEAR** button)
- **Space**: Enters a blank and moves the cursor one forward (to the right).
- **Delete**: Deletes the character at the cursor position.
- **Clear**: Deletes all the character inputs.
- **Save**: Registers the character inputs.

- 5** Press the **▲▼◀▶** buttons to select **Save**, and then press the **OK** button.
The changed title name is displayed in the title field of the selected title.



I Locking (Protecting) a Title


Follow these instructions to lock a title to protect it from accidental deletion.




- 1 Press the **TITLE LIST** button.
The Title List screen is displayed.

Or use the **MENU** button:



- Press the **MENU** button.
- Press the **▲▼** buttons to select **Disc Navigation**, then press the **OK** or **▶** button twice.




- 2 Press the **▲▼** buttons to select a title you want to protect in the **Title List**, then press the **OK** or **▶** button.



- 3 Press the **▲▼** buttons to select **Protection**, then press the **OK** or **▶** button.



- 4 Press the **◀▶** buttons to select **On**, then press the **OK** button. The key icon on the information window for the selected title changes to the locked status. (🔒 → 🔒)



Deleting a Title

Follow these instructions to delete a title from the Title List.




- 1 Press the **TITLE LIST** button.
The Title List screen is displayed.

Or use the **MENU** button:


- Press the **MENU** button.
- Press the **▲▼** buttons to select **Disc Navigation**, then press the **OK** or **▶** button twice.




- 2 Press the **▲▼** buttons to select a title you want to delete in the Title List, then press the **OK** or **▶** button.



- 3** Press the **▲▼** buttons to select **Delete**, then press the **OK** or **▶** button.



You will be prompted with a confirmation message. DVD-RAM/-RW (VR mode): Since Playlist is present, the message 'Do you want to delete?(Related playlists may be deleted.)' is displayed.



DVD-RW (V mode)/-R: Since Playlist is not present, the message 'Do you want to delete?' is displayed.

- The message depend on the type of disc.

- 4** Press the **◀▶** buttons to select **Yes**, then press the **OK** button.



Note

- You cannot delete a protected title. If you want to delete a protected title, select **Off** in the Title Protection menu. (See page 73)
- Once a title is deleted from the Title List it cannot be recovered.
- Once DVD-R, DVD-RW is finalised, it cannot be deleted.
- With DVD-R, titles are only deleted from the menu, however, the Title remains physically on the disc.

Deleting a Section of a Title

Follow these instructions to delete a section of a Title List title.



(VR mode)


- 1** Press the **TITLE LIST** button.
The Title List screen is displayed.

Or use the **MENU** button:


- Press the **MENU** button.
- Press the **▲▼** buttons to select **Disc Navigation**, then press the **OK** or **▶** button twice.




- 2** Press the **▲▼** buttons to select a title you want to delete from the Title List, then press the **OK** or **▶** button.




- 3** Press the **▲▼** buttons to select **Edit**, then press the **OK** or **▶** button.
The Edit Title List screen is displayed.



- 4** Press the **OK** button at the starting point.
The image and starting point time are displayed in the section deletion starting point window.




Edit Title List Screen Elements





- ① Playback bar
- ② Playtime
- ③ Section deletion starting point window and time
- ④ Section deletion end point window and time
 - Select the start and end points of the section you want to delete using the playback related buttons.
 - Playback related buttons: (▶||, I◀◀, ◀◀, ▶▶).

- 5** Press the **OK** button at the end point.
The image and end point time are displayed in the Section deletion ending point window.



- 6** Press the **▲▼** buttons to select **Delete**, then press the **OK** button.



- 7** Press the **◀▶** buttons to select **Yes**, then press the **OK** button.
The selected section has been deleted.
To return to the Title List, press the **▲▼** buttons to select **Return**.



Note

- The length of the section to be deleted must be at least 5 seconds long.
- If the length of the section to be deleted is less than 5 seconds, you will be prompted with the message 'The range is too short.'.
- If the end time precedes the starting time, you will be prompted with the message 'End point cannot be marked earlier than start point'.
- The section cannot be deleted when it includes a still picture.
- Press the **MENU** button after the operation has finished.
The Title List screen will disappear.


Advanced Editing (Playlist)

■ Creating a Playlist


Follow these instructions to create a new playlist title from a recorded title.




- 1 With the unit in Stop mode, press the **MENU** button.
- 2 Press the **▲▼** buttons to select **Playlist**, then press the **OK** or **▶** button.



- 3 Press the **▲▼** buttons to select **New Playlist**, then press the **OK** or **▶** button.
The Make Scene screen is displayed.



- 4 Press the **OK** button at the start point.



- The image and time at the start point are displayed on the Start window.
- The yellow-coloured selection bar moves to the End item.
- Select the starting point of the section from which you want to create a new scene using the playback related buttons (**▶II, I◀◀, ▶▶I, ◀◀, ▶▶▶**).

- 5 Press the **OK** button at the end point.



- The image and end point time are displayed in the End window.
- The yellow-coloured selection bar moves to the Make icon.

- To make a new playlist -

- 6 Press the **▲▼** buttons to select **Make**, then press the **OK** button.
A new Make Scene screen is displayed.
A new Scene will be added to the current Playlist.




Note

- You can check and see all the scenes on Edit Playlist screen. (See page 79)
- Repeat steps 1~6 if you want to make a new playlist.
- Repeat steps 3~6 if you want to make scenes of the playlist.

- To return to Edit Playlist menu -

- 7 Press the **▲▼** buttons to select **Return**, then press the **OK** button.
The Edit Playlist screen is displayed.



- 8 Press the **MENU** or **PLAY LIST** button after the operation has finished.
The Edit Playlist screen will disappear.



Note

- You can create up to 99 playlist titles.
- Depending on the kind of disc, the displayed screen may have a slight difference.


■ Playing Titles in the Playlist

Follow these instructions to play the playlist titles.




(VR mode)

- 1 Press the **PLAY LIST** button with the disc stopped. The Edit Playlist screen is displayed.



Or use the **MENU** button:



- Press the **MENU** button with the disc stopped.
- Press the **▲▼** buttons to select **Playlist**, then press the **OK** or **▶** button.
- Press the **▲▼** buttons to select **Edit Playlist**, then press the **OK** or **▶** button.



- 2 Press the **▲▼** buttons to select the title you want to play from the Playlist, then press the **OK** or **▶** button.

The Edit Playlist menu is displayed : Play, Rename, Edit Screen, Copy, Delete.

- 3 Press the **▲▼** buttons to select **Play**, then press the **OK** or **▶** button. The playlist titles will be played back.



- 4 Press the **STOP** button to stop playing. The screen returns to the Edit Playlist screen.


Renaming a Playlist Title

Follow these instructions to rename a playlist Title, i.e. to edit the title of a playlist title.



(VR mode)


- 1 Press the **PLAY LIST** button with the disc stopped. The Edit Playlist screen is displayed.





Or use the **MENU** button:

- Press the **MENU** button with the disc stopped.
- Press the **▲▼** buttons to select **Playlist**, then press the **OK** or **▶** button.
- Press the **▲▼** buttons to select **Edit Playlist**, then press the **OK** or **▶** button.


- 2 Press the **▲▼** buttons to select the title you want to rename from the Playlist, then press the **OK** or **▶** button. The Edit Playlist menu is displayed :Play, Rename, Edit Scene, Copy, Delete



- 3 Press the **▲▼** buttons to select **Rename**, then press the **OK** button. The Rename screen is displayed.




- 4 Enter the desired characters using the **▲▼◀▶** buttons.



- This function is the same as the Rename function in the renaming the title list. (See page 72)
- The maximum number of characters that can be entered is 31.

- 5 Press the **▲▼◀▶** buttons to select **Save**, then press the **OK** button. The changed title is displayed in the title field of the selected playlist title.




■ Editing a Scene for the Playlist

Follow these instructions to edit scenes for a playlist.




- 1 Press the **PLAY LIST** button with the disc stopped. The Edit Playlist screen is displayed.





Or use the **MENU** button:

- Press the **MENU** button with the disc stopped.
- Press the **▲▼** buttons to select **Playlist**, then press the **OK** or **▶** button.
- Press the **▲▼** buttons to select **Edit Playlist**, then press the **OK** or **▶** button.

- 2 Press the **▲▼** buttons to select the title you want to edit from the Playlist, and then press the **OK** or **▶** button. The Edit Playlist menu is displayed: Play, Rename, Edit Scene, Copy, Delete




- 3 Press the **▲▼** buttons to select **Edit Scene**, then press the **OK** or **▶** button. The Edit Scene screen is displayed.



Playing a Selected Scene

- 4 Press the **▲▼◀▶** buttons to select the scene you want to play, then press the **OK** button. The playlist title to be played is selected.



- 5 Press the **OK** button again. The selected scene will be played back.




- To stop scene play, press the **STOP** button.


Modifying a Scene (Replacing a Scene)

To setup, follow steps 1 to 3 in page 79.


- 4 Press the ▲▼◀▶ buttons to select the scene you want to modify, then press the **OK** button.



- 5 Press the ▲▼ buttons to select **Modify**, then press the **OK** button.
The Modify Scene screen is displayed.




- 6 Press the **OK** button at the start point of the scene.




- The image and starting point time are displayed on the Start window.
- Select the starting or ending point of the section you want to modify using the playback related buttons (▶II, I◀◀, ▶▶I, ▶▶, ◀◀).

- 7 Press the **OK** button at the end point of the scene.



- The image and ending point time are displayed in the End window.

- 8 Press the ▲▼ buttons to select **Change**, then press the **OK** button.




- The scene you want to modify is changed with the selected section.


Moving a Scene (Changing the Position of a Scene)

To setup, follow steps 1 to 3 in page 79.

- 4** Press the ▲▼◀▶ buttons to select the scene you want to move (change the position), then press the OK button.




- 5** Press the ▲▼ buttons to select **Move**, then press the OK button.




- A yellow selection window is displayed on the scene to be moved.

- 6** Press the ▲▼◀▶ buttons to select the position to which you want to move the selected scene, then select the OK button.



- The selected scene is moved to the selected position.




Note

- You cannot move the selected scene to the position of the next scene, because the selected scene should be inserted before that position, which requires no action.
- Depending on the kind of disc, the displayed screen may have a slight difference.


Adding a Scene

To setup, follow steps 1 to 3 in page 79.


- 4** Press the ▲▼◀▶ buttons to select the scene that will have a new scene inserted before it, then press the OK button.
A yellow selection window is displayed on the scene to be added as the new scene.



- 5** Press the ▲▼ buttons to select **add**, then press the OK button.
The Add Scene screen is displayed.




- 6** Press the OK button at the starting point of the scene.




- The image and starting point time are displayed in the Start window.
- Select the end point of the section where you want to add the new scene using the playback related buttons (▶II, I◀◀, ▶▶I, ◀◀, ▶▶).

- 7** Press the **OK** button at the end point of the scene.



- The image and time of the end point are displayed in the End window.
- To cancel, press the **▲▼** buttons to select **Cancel** and then press the **OK** button.

- 8** Press the **▲▼** buttons to select **Add**, then press the **OK** button.




- The section you want to add is inserted prior to the scene selected in step.


Deleting a Scene

To setup, follow the steps 1 to 3 in page 79.

- 4** Press the **▲▼◀▶** buttons to select the scene you want to delete, and then press the **OK** button.




- 5** Press the **▲▼** buttons to select **Delete**, then press the **OK** button.



Copying a Playlist to the VCR


- 1** Press the **PLAY LIST** button with the disc stopped. The Edit Playlist screen is displayed.




Or use the **MENU** button:

- Press the **MENU** button with the disc stopped.
- Press the **▲▼** buttons to select **Playlist**, then press the **OK** or **▶** button.
- Press the **▲▼** buttons to select **Edit Playlist**, then press the **OK** or **▶** button.

- 2** Press the **▲▼** buttons to select the title you want to edit from the Playlist, and then press the **OK** or **▶** button. The Edit Playlist menu is displayed: Play, Rename, Edit Scene, Copy, Delete



- 3** Press the **▲▼** buttons to select **Copy**, then press the **OK** button.
- The title you choose is played and copied to VCR tape.



- 4** Press the **MENU** button after the operation has finished. The menu screen will disappear.




Note

- The playlist can contain up to 99 playlist titles.

■ Deleting a Playlist from the Playlist


- 1 Press the **PLAY LIST** button with the disc stopped. The Edit Playlist screen is displayed.




Or use the **MENU** button:

- Press the **MENU** button with the disc stopped.
- Press the **▲▼** buttons to select **Playlist**, then press the **OK** or **▶** button.
- Press the **▲▼** buttons to select **Edit Playlist**, then press the **OK** or **▶** button.


- 2 Press the **▲▼** buttons to select the title you want to edit from the Playlist, then press the **OK** or **▶** button. The delete Playlist menu is displayed: Play, Rename, Edit Scene, Copy, Delete



- 3 Press the **▲▼** buttons to select **Delete**, then press the **OK** button.





- You will be prompted with the delete confirmation message 'Do you want to delete?'.



- 4 Press the **◀▶** buttons to select **Yes**, then press the **OK** button.

You automatically returned to the Edit Playlist screen after the delete operation has finished.




Disc Manager

■ Editing the Disc Name


Follow these instructions to give a name to a disc.



- 1** With the unit in Stop mode, press the **MENU** button.




- 2** Press the **▲▼** buttons to select **Disc Manager**, then press the **OK** or **▶** button.




- 3** Press the **▲▼** buttons to select **Disc Name**, then press the **OK** or **▶** button.
The Edit Name screen is displayed.



- 4** Enter the desired characters using the **▲▼◀▶** buttons.



- 5** Press the **▲▼◀▶** buttons to select **Save**, then press the **OK** button.
A disc name is given to the disc.



Note


- You may need to clear disc protection before beginning editing.
- Depending on the kind of disc, the displayed screen may be different.

Disc Protection


Disc Protect allows you to protect your discs from being formatted or deleted due to unintended operations.




- 1 With the unit in Stop mode, press the **MENU** button.




- 2 Press the **▲▼** buttons to select **Disc Manager**, then press the **OK** or **▶** button.



- 3 Press the **▲▼** buttons to select **Disc Protection**, then press the **OK** or **▶** button.



- 4 Press the **▲▼** button to select **Protected**, then press the **OK** or **▶** button.




Formatting a Disc


Use these instructions to format a disc.
The disc protect should be cleared




- 1 With the unit in Stop mode, press the **MENU** button.



- 2 Press the **▲▼** buttons to select **Disc Manager**, then press the **OK** or **▶** button.




- 3 Press the **▲▼** buttons to select **Disc Format**, then press the **OK** or **▶** button.



DVD-RAM


- You will be prompted with the confirmation message 'Do you want to format disc?'.



- If you select "Yes", you will be prompted with the confirmation message 'All data will be deleted. Do you want to continue?'.

DVD-RW

- You will be prompted with the confirmation message 'Choose the recording format for DVD- RW.'



4 Press the ◀▶ buttons to select **Yes**, then press the **OK** button. The disc is formatted.

DVD-VR mode and DVD-V mode are defined according to their recording format.


	DVD-VR mode	DVD-V mode
DISC	DVD-RAM DVD-RW	DVD-RW DVD-R

Finalising a disc


Use these instructions to format a disc.
The disc protect should be cleared





1 With the unit in Stop mode, press the **MENU** button.



2 Press the ▲▼ buttons to select **Disc Manager**, then press the **OK** or ▶ button.




3 Press the ▲▼ button to select **Disc Finalise**, then press the **OK** or ▶ button.



You will be prompted with the message 'Do you want to finalise disc?'.



If you select Yes, you will be prompted again with the message 'Disc will be finalised. Do you want to continue?'.



4 Press the ◀▶ buttons to select **Yes**, then press the **OK** button. The disc is finalised.




Note

- Once a disc is finalised, you cannot delete titles from the record list.
- After being finalised, the DVD-RW(V mode)/-R operates in the same manner as a DVD-Video.
- Depending on the disc type , the displayed screen may be different .
- Finalising time may be different depending on the amount of data recorded on the disc.
- Data on the disc will be damaged if the recorder is powered off during finalise process.

■ Unfinalising a disc (V/VR mode)




- 1** With the unit in Stop mode, press the **MENU** button.




- 2** Press the **▲▼** buttons to select **Disc Manager**, then press the **OK** or **▶** button.



- 3** Press the **▲▼** button to select **Disc Unfinalise**, then press the **OK** or **▶** button.
You will be prompted with the message 'Do you want to unfinalise disc?'.



If you select Yes, you will be prompted again with the message 'Disc will be unfinalised. Do you want to continue?'.



- 4** Press the **◀▶** buttons to select **Yes**, then press the **ENTER** button.
The disc is unfinalised.



Note

- A DVD-RW can be finalised or unfinalised in V mode.

	Finalise	Unfinalise
Mark	DVD-Video(RW)	DVD-RW(V mode)
Operation	Same as DVD-Video	Additional recording, protection and deletion are possible.


- A DVD-RW can be finalised or unfinalised in VR mode.

	Finalise	Unfinalise
Mark	DVD-RW(VR:F)	DVD-RW(VR mode)
Operation	Additional recording, deletion, editing, and protection are impossible.	Additional recording, deletion, editing, and protection are possible.


Delete All Title Lists




- 1** With the unit in Stop mode, press the **MENU** button.




- 2** Press the **▲▼** buttons to select **Disc Manager**, then press the **OK** or **▶** button.



- 3** Press the **▲▼** button to select **Delete All Title Lists**, then press the **OK** or **▶** button.



- You will be prompted with the confirmation message 'Do you want to delete all title lists?'.



- When Protected Title exists: The Delete All Title List function will not operate. If there is a title containing a still picture, however, that function will not operate.
If you want to delete a protected title, disable Protect for it on the Lock item.

- 4** Press the **◀▶** buttons to select **Yes**, then press the **OK** button.
All title lists are deleted.

14. Circuit Operating Descriptions

14-1 Power

14-1-1 About S.M.P.S




Fig. 14-1

◆Terms

- 1) 1st : Common power input to 1st winding.
- 2) 2nd : Circuit followings output winding of transformer.
- 3) f (Frequency) : Switching frequency (T : Switching cycle)
- 4) Duty : $(T_{on}/T) \times 100$

14-1-2 Circuit description Control

(a) AC Power Rectification/Smoothing Terminal

- 1) BD01 : Convert AC power to DC (Wave rectification).
- 2) CIS01 : Smooth the voltage converted to DC.
- 3) L1S02, C1S04, C1S05 : Noise removal at power input/output.
- 4) R1S04 : Rush current limit resistance at the momemt of power cord insertion.
 - Without R1S04, the bridge diode might be damaged as the rush current increases.

(b) SNUBBER Circuit : R1S02, R1S03, C1S08, C1S07, D1S05




Fig. 13-2

- 1) Prevent residual high voltage at the terminals of switch during switch off/Suppress noise.
High inverted power occurs at switch off, because of the 1st winding of transformer :
($V = -L1 \times di/dt$. $L1$: Leakage Induction)
A very high residual voltage exist on both terminals of Q1S01 because dt is a very short.
- 2) SNUBBER circuit protects Q1S01 from damage through leakage voltage suppression by RC,
(Charges the leakage voltage to D1S05 and C1S08 and discharges to R1S02, R1S03).
- 3) C1S38 : For noise removal

(c) IC1S01 Vcc circuit

- 1) R1S05, R1S07, R1S08 : IC1S01 driving resistance (IC1S01 works through driving resistance at power cord in)
- 2) IS1S01 Vcc : R1S06, D1S07, C1S09
 - ① Use the output of transformer as Vcc, because the current starts to flow into transformer while IC1S01 is active
 - ② Rectify to D1S07 and smooth to C1S09.
 - ③ Use the output of transformer as IC1S01 Vcc : The loads are different before and after IC1S01 driving.
(Vcc of IC1S01 decreases below OFF voltage , using only the resistance due to load increase after IC1S01 driving.)

(d) Feedback Control Circuit




Fig. 14-3

- 1) F/B terminal of IC1S01 determines output duty cycle.
- 2) C-E (Collector-Emitter) of IC1S01 and F/B potential of IC1S01 are same.

14-1-3 Internal Block Diagram (Internal Block Diagram of S.M.P.S. Circuit)




Fig. 14-4

14-2 AV Codec




Fig. 14-5

- Main system control
- A/V Encoding/Decoding
- Transcoding/rating
- IEEE 1394 link layer function
- ATAPI interface with DVD-Multi Drive
- Analog Progressive/interlaced video output

14-2-1 DIC1 Processor Internal Architecture Diagram




Fig. 14-6

14-2-2 A/V Processor (DIC1) Functional description

1) SPARC Processors

Two 32-bit SPARC processors, one dedicated to video processing and the other assigned general system tasks and audio processing, perform three classes of functions: system processing, audio processing, and high-level control flow and decision-making tasks for video processing. Optionally, they can also perform 2D graphics and host functions.

The DMN8602 also support multiple video inputs, windowed video and graphics with arbitrarily relocatable and resizable windows, letterbox, and side-by-side display of SD sources.

2) Host Interface

The host communication functions include initializing the DMN-8602 device, downloading software to the local SDRAM, sending commands, monitoring status, and downloading graphics data such as OSD bitmap.

3) Bitstream/Storage interface

◆ ATAPI Controller

ATAPI is an asynchronous, 120ns, 16-bit word interface commonly used to connect devices such as hard disks, CD/DVD ROMs, and DVD RAMs. All operations are initiated by reading/writing a set of ATAPI device registers through programmed input/output(PIO) data transfer. ATAPI has DMA commands for transferring long data. The ATAPI register address is defined by the output pins CS0, CS1, DA[2:0].

- ◆ The IEEE1394 interface can receive MPEG-2 transport stream or DV stream data contained in isochronous packets (IPs). The DMN-8602 device filters the packets by matching channel IDs. In the case of MPEG-2 transport streams, the DMN-8602 device performs descrambling on the data that is scrambled with 5C encryption. Software is responsible for transport section processing and demultiplexing.

4) Video Interface

◆ Video Input channel

The video input channel captures ITU-R BT.656-compliant 10-bit digital YUV component video stream from Video decoder chip(TIC1)

◆ Video Digital Encoder (DENC)

The NTSC/PAL digital video encoder (DENC) module converts a digital video data stream into NTSC or PAL composite or component video output.

The DMN-8602 DENC output can be in one of the following formats:

- Baseband composite NTSC (M) or PAL (B,D,G,H,I) analog video.
- Separate analog luma(Y) and chroma(C) output to support S-Video.
- Separate analog component video RGB or SMPTE YPbPr output.

5) Audio Interface

The serial audio input port receives uncompressed 16- to 24-bit serial digital audio data from external audio ADC(AIC9). An internally generated clock provides bit serial clocking of the data coming from external ADC. The serial audio output port sends uncompressed 16- to 24-bit serial digital audio data to external audio DAC(AIC1). An internally generated clock provides bit serial clocking of the data coming from external ADC.

6) Serial I/O interface

◆ SPI interface

The SPI(Serial Peripheral Interface) port provides a bus for a serial interface with front panel micom(FIC1)

◆ IDC interface

The IDC bus is a simple, two-wire, bidirectional communication bus. The two signals, clock and data, are common to every device connected to the bus.

In this system, IDC bus is connected to EEPROM(DIC8) and Video Decoder(TIC1)

14-3 SERVO (DVP Multi Drive)

1) Pick-Up

Data in the disc is processed from the optical pick-up unit (OPU). OPU includes the Elantec chip (EL6912c) which is a highly integrated laser diode driver designed to support multi-standard writable optical drives. This chip also has an IV amplifier with concurrent read and write sampling. The architecture allows reprogramming of the timers to support different media DVD or CD standards, and different speed.

2) A-Chip

A chip is RF processor. This module performs RF signal processing which includes RFIP, RFIN, AGC, RF equalizer. This processor is able to detect tracking error, focus error and various signals such as CE, PE, SBAD, DEFECT, BCA, MIRROR, Wobble, TZC, RC, and RECD.

3) C-Chip

C-Chip is composed of DP1, PRML and WS.

First, the Data processor1 (DP1) performs EFM/EFM+ Demodulation and data is stored in the buffer memory in data processor2 (DP2). DVD data in this buffer is transferred to CSS/ATAPI through error-correction code

(ECC), descramble process and error detection code (EDC).

Second, WS performs the following processes.

- ① Delay compensation using Shift register
 - ② Sample/Hold pulse generation
 - ③ I/V Gain Control
 - ④ Providing clock for RF chip
 - ⑤ OPC Control signal generation
- Lastly, PRML completes the adaptive EQ/VD and Digital PLL.

4) D-Chip

D-Chip consists of Servo DSP, DP2 and 1Mbit memory. Servo DSP is dealing with controlling the servo-mechanism in DVD recorder. Servo-DSP has the following features.

- ① Built-in 10Bit ADC(8ch), DAC(3ch) and PWM(7ch)
- ② Step Motor Control Logic: Macro/Micro Step
- ③ Track Counter: long distance velocity control direct seek
- ④ Shock/Defect detection
- ⑤ Header (DVD-RAM)/Land Pre-Pit (DVD-R/RW) Detection
- ⑥ Several Servo Monitor Signal Detection
- ⑦ RF IC Interface
- ⑧ Micom Interface
- ⑨ Digital Servo Control of focus, tracking, sled and seek
- ⑩ Disc Auto-Detection
- ⑪ Automatic Adjustment of the offset, balance and gain of Focus and Tracking Signal
- ⑫ Direct Seek with Velocity Control
- ⑬ Step Motor Control: Macro Seek
- ⑭ De-Track and Lens Shift Detection and Compensation
- ⑮ Center Error Control
- ⑯ DVD Layer Jump
- ⑰ Tilt Detect and Compensation

DP2 performs High Speed ECC and CD DA Decoder.

5) ATAPI Controller

ATAPI (ATA Packet Interface) the standard interface protocol used to connect the CD/DVD Drive to IDE interface. Data from the front-end is processed to back-end through this ATAPI protocol. Sanyo chip (LC98600CT-XB0) is utilized for ATAPI interface. LC98600CT-XB0 has the following features.

- ① ECC and EDC correction/addition for CD-ROM data
- ② Subcode decoding/encoding
- ③ Spindle servo control
- ④ CLV/CAV servo control using ATIP data
- ⑤ ATIP decoding and CRC check functions
- ⑥ Providing random EFM output for PCA use
- ⑦ High-accuracy write strategy signal output enabled (CD-R 52x)
- ⑧ Buffer RAM can be accessed by the microcontroller through the LC98600CT-XB0
- ⑨ Built-in ATA-PI(IDE) interface (supports Ultra DMA modes 0,1, and 2)
- ⑩ 52x decoding speed/52x encoding speed supported with 33.8688Mhz
- ⑪ Maximum transfer speed PIO mode: 16.6 MB/s (with IORDY), Ultra-DMA: 66MB/s (with DMARQ)
- ⑫ User can freely set the CD main channel, C2 flag, and subcode areas in buffer RAM
- ⑬ Built-in batch transfer function for transferring (CD main channel, C2 flag, etc., in a single operation)
- ⑭ Built-in multi-transfer function (allows multiple blocks to be sent to the host automatically in a single operation)




Fig. 14-7

14-4 Video Input

14-4-1 Video Input Outline

D-VR15-S is the two Line Video input. Line 1 Video input is CVBS1 & S-Video1 at the Rear Panel. Line 2 Video input is CVBS2 at the Front Panel.

The analog Video signal select Line 1 or Line 2 by the IC601 (Front Micom).

TIC1 (Video Decoder) diverges from the 27MHz crystal, then generates ITU-R656 (10bits) and 27MHz clock.

TIC1 (Video Decoder) does closed caption, copy guard detect processing and A/D conversion of analog Video signal converted into 11bit Digital Video signal (ITU-R656 Format) is outputted via DIC1 (MPEG2 Decoder & Encoder with video Encoder) of digital part.




Fig. 14-8

14-4-2 Analog Mux (TEA6425)

IC801 is Analog Mux.

As Pin 9, 10 of the IC801 are controlled by the Front Micom, IC801 select RF OF CVBS(Pin1) AV1 of CVBS[Pin6] and AV2 of CVBS[Pin 5].

The analog Video Signal of IC801 output is selected by the ic601 via TIC1(Video Decoder : TW9909) of analog Video input parts.

14-4-3 NTSC/PAL Video Decoder (TW9909 : Video Decoder)

The TIC1 (Video Decoder : TW9909) device is a high quality, single-chip digital video decoder that digitizes and decodes all popular baseband analog video formats into digital component video. The TIC1 (Video Decoder : TW9909) supports the analog-to-digital (A/D) conversion of component RGB and YPbPr signals, as well as the A/D conversion and decoding of NTSC, PAL and SECAM composite and S-video into component YCbCr. This TIC1 (Video Decoder : TW9909) includes four 10-bit 30-MSPS A/D converters. and A/D conversion of 10bit analog Video signal converted into Digital Video signal (ITU-R656 Format) is outputted via DIC1 (MPEG2 Decoder & Encoder with video Encoder) of digital part.

The following output formats supply 10-bit 4:2:2 YCbCr to the DIC1 (MPEG2 Decoder & Encoder with video Encoder) of digital part.

On CVBS and S-video inputs, the user can control video characteristics such as contrast, Brightness, saturation, and hue via an I2C DIC1 port [PIN V17, V18] interface.

The TW9906 decoder includes methods for advanced vertical blanking interval (VBI) data retrieval. The VBI data processor (VDP) slices, parses, and performs error checking on teletext, closed caption (CC), Copy Guard Detect Processing and other VBI data.

14-5 Video Output

14-5-1 Outline

DIC1 (MPEG2 Decoder & Encoder with video Encoder) diverges from the 13.5MHz crystal, then generates VSYNC and HSYNC.

DIC1 (MPEG2 Decoder & Encoder with video Encoder) does RGB encoding, copy guard processing and D/A conversion of 10bit Video signal converted into analog signal is outputted via amplifier of analog part.




Fig. 14-9

14-5-2 NTSC/PAL Digital

DIC1 inputted from pin E1 with 13.5MHz generates HSYNC and VSYNC which are based on video signal. DIC1 is synchronous signals with decoded video signal.

The above signals, which are CVBS (Composite Video Burst Synchronized), Y(S_Video), C(S_Video), Y(Component)/G(Green), Cr(component)/R(Red), Cb(component)/B(Blue), are selectively outputted 480i (interlaced Video Output), 480P(progressive Video Output) by the Front button DiC1 adopts 10bit D/A converter. DIC1 perform video en-coding as well as copy protection.

14-5-3 Amplifier (LA73054)

VIC1 is 6dB amplifier.

Based on CVBS signal, the final output level must be 2Vpp without 75ohm terminal resistance.

Because the level of video encoder output is only 1Vpp, the level is adjusted with the special amplifier.

When mute of pin 3 is high active, if the pin is floating and connect to power, the output signal is never outputted.

CVBS, Y, C, Y(R), Cb(B), Cr(R) outputted from video encoder are inputted to VIC1 [Pin2, 6, 8, 11, 14, 16] respectively.

The signal to which gain is adjusted by amplifier is outputted from jack via 75ohm Resistance (VR30,11,32,33,34,53,54,55).

14-6 Audio

14-6-1 Input Block

D-VR15-S has two stereo line input terminals, and internal TV-audio from RF Tuner Block. These three Analog audio signal source are converted to digital data by Input Block.

Input Block has a Multiplexer (IC802), Input Filter (AIC81, AIC82), and A/D converter (AIC9).

IC802 change it's output by selection control signal from IC601 (Front Micom).

The output signal of IC802 are filtered by OP-Amp (AIC81, AIC82).

AIC81 (L-ch) have two op-amp in each.

14-6-2 Output Block

D-VR15-S has two stereo analog line out terminal, and two digital output terminal.

Decoded signal by DIC1 is inputted to AIC1 (D/A Converter), then filtered and amplified by AIC4 (OP-Amp).

And the digital audio signal (IEC-958) is driven by AIC3 inverter and ouputted in Optical/Coaxial (S/PDIF) terminal.




Fig. 14-10

14-7 Tuner

1) Low Pass Filter & High Pass Filter

This consists of IF trap circuit and UHF & VHF separation circuit. If the input signal is IF (45.75MHz), this filter prevents interference.

2) Single tune

This consists of a filter circuit, RF AMF, impedance conversion circuit, image trap and a single tuning circuit. It prevents noise and other interference signals. It is very important part which improves NF (noise figure) and prevents the various of spurious signals.

3) RF AMF

RF AMF is made of FET (Field Effects Transistor). It is controlled by AGC coming from IF DEMOD block.

4) Double tune

It consists of a double tuning circuit to improve characteristic of rejection that results in a better band characteristic.

5) Mixer IC (Mixer, OSC, PLL)

It consists a VHF and UHF OSC and Mixer circuit. We applied mixer to make better characteristic of rejection, it shows especially various beat characteristic.

6) PLL IC

The PLL IC plays a role selection of Tuner channel. It was built-in three wire PLL IC, charge pump and band driver.

The minimum of step frequency is 31.25KH z.




Fig.14-11

14-8 IF

1) SAW FILTER

It passes only needed band of the signal that is converted to IF frequency and decrease the others band to minimize the effect of adjacent channel.

2) RF AGC Control

It used adjusting to determine RF AGC working point in tuner.

3) VCO Tank

When VCO tank detects PLL, it makes the signal which sets a standard.

4) AFT (Auto Frequency Tuning)

AFT automatically controls the oscillator frequency in the tuner, so that it retains a constant level.

It is a quadrature detection type. The carrier, which is detected from video det is directly input to AFT.

The 90 degree delayed phase signal is input at the same time to AFT and, the results come out.

5) IF AMP

IF signal, which is selected in Saw filter, is amplified in IF amp frequency enough to be detected. The IF amp has parallel inputs & outputs structure.




Fig. 14-12

14-9 VCR System Control




Fig. 14-11 Micom Block Diagram

(1) Outline

The system control circuit inputs the commands given by the operator to set the mechanism and circuit to the commanded mode. The circuit also inputs the detected output from the tape and mechanism protection sensor and protects the VCR and tape against abnormal operation.

Fig. 14-11 is a simplified system control block diagram.

The system control is performed by 4 control sections. (System and timer control, Servo control, F/S Tuner, On Screen Display).



Fig. 14-12 IC601 Block Diagram

(2) Mechanism/Circuit Control

When the u-COM inputs operator's commands via the key input or remote input, the mechanism and circuits are set to the command mode. This function controls mechanism/servo section and audio/video processing section.

1) Cassette Loading Control

Controls loading and ejection of a cassette and determines the mechanism operation mode; tape loading/unloading, action/release of various breaks, tension, take up mechanism etc.

2) Tape Protection Sensor Monitoring

Detects abnormal operation in tape using the supply and take up end sensor, reel sensor and SW 30Hz pulse for drum rotation.

3) Capstan Motor Control

Determines the tape speed and direction, fast forwards and rewinds the tape etc.

4) Tape Counter Control

Counts the control pulses on the control track, picked up by the control head and shows it on the digital multidisplay.

5) Servo Control

Determines the operation mode of the servo circuit. Control the speed of drum and capstan motor, and then Control the phase of drum and capstan motor.

6) Record Safety Tap Detection

Detects the safety tab on the rear of a cassette to prevent a prerecorded program from being erased.

7) Loading/Unloading control

Controls a series of loading/unloading operation after the u-COM judges the operation mode and sets the mechanism to suitable mode. Fig. 14-13 show correlation between u-COM and peripheral components during the loading/unloading operation.

The mechanism state switch (PROG. SW) detects the mechanism position. When the driving gear is turned by the loading motor, the switch driving slider traces the groove, and this switch stops at the correct position corresponding to each mode. In other words, the u-COM judges the present mechanism state from the PROG SW after receiving the mode data, then it outputs the loading motor and capstan motor control signals. This continues until the PROG SW reaches the correct state by the u-COM.




Fig. 14-13 The Relationship Between u-COM, Capstan, Cylinder and Loading Motor

(3) Program SW Input

The mechanism state for each mode is shown in table 1 below. The mechanism state is classified into position, and correlation between the switch position and mechanism state is shown in table 1, also.

Table 1 : Prog. SW State in Each Mode

POSITION	CAM S/W			START SEN	ACTION MODE
	A	B	C		
STANBY	0	0	0	0	Eject
POWER OFF	0	0	0	1	Unload POWER OFF
LOADING START	0	0	0	1	(Tape loading start point)
LOADING END	1	0 1	1	1	(Tape loading end point)
REV	1	1	0	X	Reverse picture search, reverse SLOW
PLAY	0	1	0	X	Play, Rec, F-PS, Still, SLOW, F-ADV
STOP 1	0	0	1	1	Stop (Play position 5 Min. over)
STOP 2	0	0	1	X	(MAIN Break ON MODE)
FF/REW 1	1	0	0	X	High speed Rew, Low speed FF
FF/REW 2	0	1	1	X	High speed FF, Low speed Rew

(4) Motor Control

In case of Scorpio-2 Deck, Loading Motor Drive IC lies in Capstan Motor, not like Scorpio-1 Deck.

In detail, Capstan Motor Drive IC is designed to drive Loading Motor + Capstan Motor + Cylinder Motor in one IC. (See Fig. 14-14)

Table 2 : Motor Control Logic

CN604-PIN10	MOTOR
0 ~ 1V	Reverse
2 ~ 3V	Stop
4 ~ 5V	Forward




Fig. 14-14 Loading Motor + Capstan Motor + Cylinder Motor Block Diagram

(5) Stop Mode

The VCR enters the stop mode when the stop button is pressed during playback, record, rewind and fast forward mode. When trouble is detected, the VCR enters the stop mode to protect the tape and mechanism or when the tape reaches the end, etc.

- State Input ;
Power switch on position.
- Stop button operation in all mode, except for timer recording and XPR.

(6) Play Mode

- State input ; Play button operated in stop, fast forward, rewind, forward search, reverse search, still mode, etc.,
- Indication output ;
“PLAY” lights in LED Module.
- Output at ;
IC601 Pin 46 (CAP F/R) : H

(7) Trick Play Mode

Trick play modes are classified into forward search, reverse search, still, slow and frame advance. Audio signal is muted by pin 32 of IC601 (A.MUTE). V-lock is controlled by pin 24 of IC601.

(8) Forward Search Mode

7 Times play speed search in SP and SLP, 21 times play speed search in SLP.

- State input ; Press the fast forward button on the VCR front panel or the remote control in play or still mode.
- Indication output ; “FPS ” display in LED Module during 3 seconds.
- Output at ;
IC601 Pin 46 (CAP F/R) : H
IC601 Pin 32 (A.MUTE) : H

(9) Reverse Search Mode

7 times play speed reverse search in SP, 21 times play speed reverse search in SLP.

- State input ;
Press the rewind button on the VCR front panel or on the remote control in play or still mode.
- Indication output ;
“RPS” display in LED Module during 3 seconds.
- Output ;
IC601 Pin 46 (CAP F/R) : L
IC601 Pin 32 (A.MUTE) : H

(10) Slow Mode

- State input ; Press “⏮” button and then press “⏭” button on the remote control.
The slow speed can be changed when “⏭” or “⏮” button is pressed.
- Indication output ; “SLOW” lights in LED Module.
- Output at ;
IC601 Pin 46 (CAP F/R) : H
IC601 Pin 32 (A.MUTE) : H

(11) Play/Still Mode

The same track is traced by the video heads.

- State input ; Press “▶||” button in play modes.
- Indication output ; “STILL” display in LED Module.
- Output at ;
 - IC601 Pin 46 (CAP F/R) : H
 - IC601 Pin 32 (A.MUTE) : H

(12) Record Mode

Must use a cassette with the safety tab.

Index signal is recorded on the control track of the tape at the start of recording.

- State input ;
Press the record button during stop mode and record pause mode or at the preset time reached in the timer record mode. Press the REC button in stop mode.
- Indication output ;
“REC” lights in LED Module in normal record mode, “0:30, 1:00, 1:30, 2:00, 3:00 or 4:00” display in timer XPR modes.
- Output at ;
 - IC601 Pin 46 (CAP F/R) : H

(13) Record Pause Mode

The pinch roller is released from the capstan shaft in a moment.

The brake is applied to the take up reel to prevent tape slack during the record pause mode.

- State input ; Press “||” button in the record mode.

Note : Inoperative during recording and XPR mode.

- Indication output ; “PAUSE” display in LED Module.

(14) Fast Forward Mode

Tape fast forward operation using capstan motor.

- State input ; Press the rewind button in the stop or fast forward modes.
- Indication output ; “FF” lights in LED Module.
- Output at ;
 - IC601 Pin 46 (CAP F/R) : H

(15) Rewind Mode

Tape rewind operation using the capstan motor.

- State input ; Press the rewind button in the stop or fast forward modes.
- Indication output ; “REW” lights in LED Module.
- Output at ;
 - IC601 Pin 46 (CAP F/R) : L

(16) Rewind Shut-Off Mode

Tape rewind operation then power off mode.

- State input ; Press the power button in the rewind mode.

(17) Trouble Detection

The trouble detection circuits are provided to protect from damage (Fig. 14-15). The reel lock sensor detects incorrect rotation of supply and take up reel. The reel lock sensor consists of the disk and photo sensor installed at the bottom of the reel disk. the disk has 6 or 8 shielder parts and the photo sensor consists of the LED and photo transistor assembly. When the light is shielded by the the shielder or enters the photo transistor, the output is obtained from the photo sensor. IC601 measures the period of the pulse. When it is 4 seconds or more during record/play, the VCR enters the reel emergency mode.

The VCR maintains the unload-power-on state in the reel emergency.




Fig. 14-15 Reel and Cylinder Lock T.END/S.END Sensor

(18) Cylinder Lock Sensor

If the frequency of D-FG is less than 230Hz or more than 430Hz during 500msec, and such situation occurs 3 times continued, micom makes the VCR drum emergency.

(19) Tape End Sensor

When end sensor detects the transparent section at the end of tape, the VCR enters auto rewind mode, except during timer recording and OTR mode. The cassette LED emits light through the transparent section of tape to the photo transistors, which are installed at both ends of the cassette. When start sensor detects the start section of the tape during reverse search and rewind, the VCR automatically goes to stop mode.

(20) Tape Counter Control

Fig. 14-16 is a simplified diagram of the tape counter control circuit. The tape counter in the u-COM counts the control pulses derived from control head. The control signal on the control track of the tape is picked up by the control head and supplied to pins 74, 75 of IC601. The control pulse is amplified by the u-COM IC. The u-COM determines the tape direction so the counter counts up when the “CAP F/R” signal is Hi and the counter counts down when the “CAP F/R” signal is Low. By counting the control pulse, the counter data is supplied to the VF display. Counter displays the time and it is increased or decreased by one minute after counting 1800 control pulses. Counter mode is switched to clock mode when the display button is pushed or when the VCR goes to power off mode. When the Clear button is pressed, the counter is reset to “00 : 00”. The tape counter has a memory stop function.




Fig. 14-16 Counter Display

(21) Timer/OTR Control

The timer can preset 12 programs in one month including daily and weekly programs.
Express recording lets the operator record up to 4 hours without programming the timer.

(22) Clock Display

The clock generator inside of the u-COM counts the oscillation signal of XT601 for the timer clock data.

(23) Power Failure Detection

u-COM goes to the power failure mode when the 88 port is lower than 4/5 of AD Vcc level.

(24) 4H'D Control

During trick play (still,slow,F-advance), it is necessary to control pre-amp,video circuit. the micom control pin 98 (C-ROTARY), pin 99 (HD-AMP) of the IC601 during PB period in Slow mode.
These port is applied to video IC to operate the trick play.

14-10 VCR Servo

(1) Outline

The servo system is divided into three loops. The cylinder servo controls the rotation of video heads, the capstan servo controls the tape speed, and the tension. In addition it's necessary to control cylinder motor, especially during trick play in 4H'D models. The tension servo maintains the tape tension constant: it keeps the compression strength of tape against the video heads at the optimum level so that a stable RF signal is produced during recording and playback. The tension servo operation is entirely mechanical. The cylinder servo loop controls the phase and speed of the cylinder motor. The speed is kept at a constant 1800 RPM and the phase determines the mechanical position relative to the vertical Sync signal. The capstan servo loop controls the phase and speed of the capstan motor so that the video head can trace the video track correctly. It keeps tape speed constant according to the mode (SP, SLP) during playback and recording.

Table 3 : Servo System Signal

MOTOR	SYSTEM	MODE	REFERENCE SIGNAL	COMPARISON SIGNAL
CYLINDER (VIDEO HEAD) (4H' D)	PHASE	REC	V-SYNC	SW 30Hz
		PB	REF30Hz	
	SPEED	COMMON	8MHz	CYLINDER FG(720Hz)
	SPEED& PHASE	TRICK PLAY (STILL. SLOW)	MICOM CONTROL CYLINDER SPEED TO MATCH H-SYNC SPEED	
CAPSTAN (4H' D)	PHASE	REC	DIVIDED CFG PULSE	REF 30Hz
		PB	CTL 30Hz	
	SPEED	COMMON	8MHz	CAPSTAN FG
	SPEED& PHASE	TRICK PLAY (STILL. SLOW)	MICOM CONTROL CAPSTAN DRIVE SIGNAL WITH CAP C.L	




Fig. 14-17 Block Diagram

(2) Capstain Speed Error Detector

The capstan speed control operates so as to hold the capstan at a constant rotational speed, by measuring the period of the CFG signal. A digital counter detects the speed deviation from a preset value. The speed error data is added to phase error data in a digital filter. This filter controls a pulse-width modulate (PWM) output, which controls the rotational speed and phase the capstan.

When the error is zero, the PWM circuit outputs a waveform with a 50% duty cycle.

The CFG input signal from the capstan motor is a square wave the CFG input signal is compared by a comparator and then sent to speed error detector as the CFG signal.

The speed error detector uses the system clock to measure the period of the CFG signal, and detects the deviation from a preset data value. The preset data is the value that would result from measuring the CFG signal period with the clock signal if the capstan motor were running at the correct speed.

The error detector operates by latching a counter value when it detects an edge of the CFG signal.

The latched counter provides 16 bits of speed error data for the digital filter to operate on.

The digital filter adds the speed error data to phase error data from the capstan phase control system, then sends the result to the pulse-width modulator as capstan error data.

(3) Capstain Phase Error Detector

The capstan phase error detector consists of a 16-bit counter, a capstan phase preset data register pair, a latch signal circuit driven by a feedback signal, and a capstan phase error data register pair.

The capstan phase control in rec mode is executed by comparing HD S/W, which is synchronized with V-sync, with divided CFG signal. And then it does in playback mode by comparing HD S/W, which is synchronized with DFG and DPG, with PB CTL signal.

The latch signal for the phase error data in record mode is the divided CFG signal, which is divided from the CFG signal in the CFG frequency divider to a frequency of 30HZ.

In playback, the latch signal is the divided CFG signal obtained by frequency division from the rising edge of PB-CTL signal (playback control pulse signal).

The error data is a signed binary value centered on a phase error of zero (corresponding to the correct rotational phase). If the phase lags the correct phase, the error is positive (+).

If the phase leads the correct phase, the error is negative (-).

(4) Drum Speed Error Detector

Drum speed control operates so as to hold the drum at a constant rotational speed, by measuring the period of the DFG signal. A digital counter detects the speed deviation from a preset value. The speed error data is added to phase error data in a digital filter. The filter controls a pulsewidth modulated (PWM) output, which controls the rotational speed and phase of the drum.

The DFG input signal from the drum motor is a square wave. The DFG input signal is compared by a comparator and then sent to the speed error detector as the DFG signal.

The speed error detector uses the system clock to measure the period of the DFG signal, and detects the deviation from a preset data value. The preset data is the value that would result from measuring the DFG signal period with the clock signal if the drum motor were running at the correct speed.

The error detector operates by latching a counter value when it detects an edge of the DFG signal. The latched count provides 16 bits of speed error data for the digital to operate on.

The digital filter adds the speed error data to phase error data from the drum phase control system, then sends the result to the pulse-width modulator as drum error data.

(5) Drum Phase Error Detector

Drum phase control must start operating after the drum motor is brought to the correct rotational speed by the speed control system . Drum speed control works as follows in record and playback.

- Record : Phase is controlled so that the vertical blanking intervals of the recorded video signal will line up along the edge of the tape.
- Playback : Phase is controlled so as to trace the recorded tracks accurately.

A digital counter detects the phase deviation from a preset value. The phase error data is added to speed error data in a digital filter. this filter controls a pulse-width modulated (PWM) output, which controls the rotation phase and speed of the drum. When the error is zero, the PWM circuit outputs a waveform with a 50% duty cycle.

The phase counter error detector compares the phase of the DPG pulse (tach pulse), which contains video head phase information, with a reference signal. In the actual circuit , the comparison is carried out by comparing the head-switching (HSW) signal, which is delayed by a counter that is reset by DPG, with a reference signal. The reference signal is the REF 30Hz signal, which differs between record and playback as follows.

- Record : V sync signal extracted from the video signal to be recorded (frame rate signal, actually 1/2V sync).
- Playback : 30Hz signal divided from the system clock.

14-11 VCR Video

(1) Luminance Signal Recording System




Fig. 14-18 Luminance Record Process

1) Outline

Fig. 14-18 shows the video signal recording system.

The selected video input signal goes to pin 28 of Luma/Chroma processor IC (IC301). And then it enters VIDEO AGC circuit. The gain of AGC circuit is controlled by AGC detector so that the output is constant (approx. 2Vp-p). The output signal of AGC is clamped by the FBC(Feed Back Clamp) circuit. This signal appears at pin 26, after being amplified at the internal video amp and driver.

The output signal from the clamp circuit enter the detail enhancer circuit. In the detail enhancer circuit, the low level high frequency video signal is emphasized to improve the original signals frequency characteristics. nonlinear emphasis circuit is employed to improve S/N and frequency response characteristics together with the following main emphasis. Noise effects the FM wave at a higher frequency, so the S/N can be improved by emphasizing the higher frequency before recording and by suppressing the play signal during demodulation. The difference of non linear emphasis from main emphasis is that the emphasis characteristics change is depending on the input level. The gain of the emphasis circuit is inversely proportional to the level of the high frequency component of the signal. That is, if the high frequency portion of the signal is low the main emphasis circuit will amplify the signal.

2) Main Emphasis Circuit

The dynamically emphasized luminance signal is now supplied to the main emphasis circuit where all the high frequency components of the signal are boosted more than the low frequency components. The boosting action is required for the high frequency components because in the FM recording method, the noise of the playback signal increases in proportion to the modulated signal frequency or low level signal. By using the nonlinear emphasis and main emphasis system, the total S/N ratio is increased. The output of the main emphasis circuit is then supplied to the white and dark clip circuit.

3) White and Dark Clip Circuit

After emphasis is performed, large overshoots and undershoots in the luminance signal are limited to a specified level. This is done to avoid FM over modulation. The output of the main emphasis circuit is then supplied to the FM modulator circuit.

4) FM Modulator

A. The amplitude of the FM signal is limited, so the signal is recorded on tape near the maximum record level which increases the S/N ratio.

B. The FM carrier is set to 3.4MHz (at the Sync tips) and the deviation to 4.4MHz by inside IC circuit (for the white peak). The actual device which constitutes the FM modulator is a stable multivibrator.

This multivibrator generates a sine wave output of variable frequency.

The frequency of sine wave is governed by the level of the processed video signal at any given point. Therefore, the processed video signal varies the frequency of the sine wave which is frequency modulation (FM). During playback in SLP mode, the crosstalk of the adjacent track is more apparent than in standard mode. It appears as jitter and noise on the monitor. To reduce this noise from the screen, the FM carrier frequency has to be $1/2f_h$ shifted up during recording. This is done by applying the head switching pulse to the FM modulator control pin57 during SLP recording. The FM modulated luminance signal goes to record equalizer circuit and it is mixed with chrominance signal at the record Amp circuit inside video IC.

5) Record Amp

The frequency modulated luminance signal and chroma signal are mixed in the record amp of pre-amp block inside video IC. Then this mixed signal is amplified and supplied to the video heads via the rotary transformer and recorded on the magnetic tape.

Tape speed selection determines which video heads will be used. That is, signal output from pin 66 (SLP) and 73 (SP) of pre-amp block are supplied to video heads.

Control signal of speed mode is applied to pin 53(clock), 54(data), 55(chip select) of video IC from Micom IC.

(2) Luminance Signal Playback System




Fig. 14-19 Luminance Playback Process

1) Outline

The video signal recorded on the tape is picked up by CH1, CH2 head and is supplied to pre-amp block via rotary trans. During playback, as per the speed, SP and SLP head is determined by Pin60 of respectively.

CH1 signal inputs to Pins 65 and 74 while CH2 signal inputs to Pins 67 and 72 of video IC. The pick up operation is controlled by the head switching pulse inputted to pin 57. During the high portion of the switching pulse, CH2 is picked-up and just the opposite is true for CH1. In the pre amp IC, the FM signal is amplified 60dB and this signal is applied to FM AGC.

2) FM AGC AMP

At the FM AGC Amp (FM), signals are automatically balanced. One of the AGC circuit outputs is fed to AGC detector circuit which detects signal level fluctuations. The detector output signal is applied to the FM AGC Amp to keep the output constant. This output is applied to the PB FM EQ block. FM EQ is correct the phase distortion and level. The signal through PB EQ circuit is applied to the double limiter.

3) Double Limiter Circuit

A FM signal on the tape which contains AM components will be read during playback. If there is a severe AM component, a drastic drop in FM carrier can occur. This lack of FM carrier can be called a noise region. Double limiting is used for improving the S/N ratio and carrier loss. The playback FM signal is split into two paths, one goes to high pass filler and sub-limiter. The other goes to the main-limiter after passing through a LPF. ONE path of the FM signal goes to the high pass filter, so that the low frequency(AM) component can be removed, and the other carrier is supplied to the sub-limiter. The output signal of sub-limiter is mixed with the signal from the low-pass filter and sent to the FM demodulation circuit.

4) FM DEMODULATOR

The FM demodulator consists of a stable mono multivibrator balanced modulator (BM) and a LPF. The FM demodulator circuit first converts the FM signal to a pulse width modulator signal. Then the circuit smoothes the PWM signal to demodulate the video signal. This demodulated signal is fed to the LPF to remove its FM carrier component and any other harmonics. The demodulated luminance signal outputs from Pin 21 and is applied to the 3MHz LPF through main deemphasis circuit. To reduce demodulation noise, the output of the 3MHz LPF is applied to a non-linear deemphasis circuit through YNR circuit.

5) Main De-emphasis Circuit

Before modulation, main emphasis was performed. Because the high frequency components of video signal were boosted more than the low frequency components in the recording mode, main deemphasis must be performed to obtain a normal video signal. That is this circuit returns the emphasized high frequency component to the original value.

6) Non Linear De-Emphasis Circuit

This circuit is the counter part of the dynamic pre-emphasis circuit during recording. The characteristics are also the opposite of those in recording.

7) Drop Out Compensator/YNR Circuit

This circuit compensated for missing parts of the FM signal due to dust, dirt on the tape or irregular tape coating, etc. The clamped video signal is supplied to the CCD 1H circuit. The 1H delayed video signal from CCD block is also supplied to the 6MHz LPF to reject the sampling noise of CCD IC.

Then, the output of LPF is applied to Pin 34 of video IC. When the DOC detector detects the FM loss, a 1H delayed video signal is added in place of the missing signal.

8) Noise Canceller Circuit

The noise canceller circuit removes the high frequency noise contained in the video signal which has the reverse characteristics of the detail enhance in the recording mode. The output of the noise canceller circuit is supplied to the Luminance and Chrominance mixer circuit. The mixed chroma and luminance signal are then output at Pin 26.

(3) Chroma Signal Recording System




Fig. 14-20 Chrominance Record Process

1) Outline

Fig. 14-20 shows the chroma signal recording system. The chroma signal recording process is performed by video IC. The input video signal is fed to Pin 28 of IC and supplied to Y/C COMB circuit through AGC AMP.

The output signal of Y/C COMB circuit is applied to ACC amplifier. The ACC amplifier is used for both burst ACC which keeps the burst level at a constant value in recording and the color ACC which controls the reference level of the burst ACC with the color signal level. The color ACC works to maintain a relatively high output level by boosting low level input signals to improve color S/N ratio. The signal is then applied to the burst emphasis circuit. Burst emphasis emphasizes the burst signal by +6dB during recording and feeds it to the main converter. The 3.58MHz signal are mixed in the main converter to perform frequency conversion.

The main converter is a mixer having the two types of output components which are the added frequency of $4.21+3.58=7.8\text{MHz}$ and the difference frequency component 629KHz.

Added frequency is rejected by the 1MHz LPF and the 629KHz down converted chroma signal is supplied to the luma/chroma mixer of pre-amp block and then recorded on the tape via the record amp and heads.

AFC detection is performed with the head switching pulse and the fh signal generated from 321fh VOC output. The detector output controls the VCO frequency which will be locked precisely at 320fh (5.035MHz).

The 320fh signal is counted down to 1/8 and the resultant 40fh (=629KHz) carrier signal is phase shifted triggered by each horizontal sync signal which is wave shaped as a 50% duty pulse by the pulse generator.

The direction of the rotational phase shift depends on the levels of the rotary head switching signal from pin 57 and when the switching signal is "H" level, the phase is retarded by 90 degrees for every 1H, and when it is at a "L" level it will advance by 90° for every 1H this 40fh phase shifted sub-carrier (PSSC) signal enters the sub-converter and the 3.58MHz carrier signal is locked at the color burst frequency by the record APC.

The PSSC signal is frequency converted into $3.58\text{MHz} \pm 629\text{KHz}$. Then 4.21MHz component ($=3.58\text{MHz} \pm 629\text{KHz}$) is extracted through a 4.2MHz BPF.

The 4.21MHz signal is used as a carrier signal for down conversion of the color signal as described previously.

2) ACC (Automatic Color Gain Control) Circuit

The ACC is used as burst ACC in the LP mode, however it is also used for peak ACC in the SP/SLP mode.

The purpose of using two different ACC operations is to improve the overall Chroma S/N ratio during playback. In SP and SLP, there is H-sync alignment. This indicates that there is burst alignment as well. Whenever two video tracks overlap or a video head picks up crosstalk from an adjacent track, beats are produced during playback. Perhaps the most noticeable beats are produced by H-sync and burst. But in SP and SLP, these beats occur right at H-sync and burst and are out of the picture. In LP, however, there is no H-sync alignment and these beats can be seen in the picture. To keep the beats at a minimum in LP, we keep the burst level constant so that the beat intensity is constant. We know that ACC acts to improve the color S/N, and in LP, the ACC detector locks at the burst level, and keeps it constant. Thus we have ACC operation with the least beats. In SP and SLP, the beats caused by burst overlap are out of picture, so we don't really mind if the burst level changes or not. To improve the color S/N ratio even more, we use peak ACC in SP and SLP. That is, if the chroma level is too low to record, the amplification degree is increased by 3dB. However, the chroma level is sufficient for recording, this peak ACC is changed to burst ACC to avoid over amplification. By changing the ACC according to picture color content, the burst level may vary. The color ratio improvement is based on the color content itself during SP and SLP provides a somewhat better S/N ratio.

3) Four (4) Phase Rotation

CH1 is advanced 90° every channel, while CH2 is delayed 90° . When the frequency is set to 629KHz, if phase is shifted by ± 90 it becomes 629KHz ± 90 . The $40f_h \pm 90$ ($=629\text{KHz} \pm 90$) is balanced modulated via fsc (3.58MHz) depending on which side band is detected. That is, the $f_s + 40f_h \pm 90$ (4.2MHz ± 90) of total frequency is supplied to the main converter. In record mode, the signal operates same as in play back mode. During playback, the phase is returned to original state.

4) AFC (Automatic Frequency Control) Circuit

Luminance signal is input to H-sync separator. The H-sync is separated and supplied to phase comparator. This signal can be described as f_h (Horizontal Sync frequency of input video signal). However, VCO oscillates at 320 f_h (5.035MHz). This 321 f_h is counted down by $1/8$ and $1/40$ and resultant f_h is supplied to phase comparator. f_h and f_h are supplied to the phase comparator for comparison of their phases.

After comparison, the phase

differences is output to VCO (320 f_h) in terms of error voltage. Therefore, the oscillation frequency of VCO is controlled by this error voltage. That is, if the f_h phase is changed by H-sync signal f_h , error voltage is changed accordingly and if the phases of f_h and f_h are met due to change of VCO oscillation frequency, error voltage does not feedback. 320 f_h VCO is oscillated in accordance with phase sync at f_h . Therefore, 40 f_h input to sub converter by phase shift is always sync horized with phase.

The AFC loop performs the same operation during record and playback. In recording, phase of VCO is in accordance with H-sync signal of current video signal.

Which in playback, the phase sync of VCO is consistent with H-sync signal which is separated from the video signal.

(4) Chroma Signal Playback System




Fig. 14-21 Chrominance Playback Process

1) Outline

Fig. 14-21 shows the chroma signal playback system.

The FM signals picked up by the CH-1 and CH-2 video heads are supplied to the pre-amp block.

The FM signal from CH-1 and CH-2 are alternately selected by the switch and output signal as a continuous signal. Goes to the ACC amp through the 1.3MHz LPF. The 1.3MHz LPF is used for passing only down converted 629KHz chroma signal in the playback mode. The ACC amp stabilizes the 629KHz color signal level.

The output color signal from amp then enters the main converter circuit. In the main converter circuit this signal is mixed with the 4.21MHz phase shifted carrier signal and converted into 4.21MHz + 629KHz signals.

2) Main Converter

Inside of IC, the main converter converts the 629KHz rotational chroma signal to a 3.58MHz non-rotational signal. The two inputs of this main converter are the 629KHz signal, which comes from the output of the ACC, and a 4.21MHz which has the same rotational phase as the 629KHz signal. It is important that the rotational phase of the 4.21MHz signal is the same direction as the 629KHz playback chroma signal. To obtain the 3.58MHz non-rotational stable signal, the same direction rotational signal should be mixed with the rotational chroma signal.

During the conversion process, the phase is also mixed by the frequency. Therefore, when 629KHz is subtracted from 4.21MHz, the result is the non-rotational 3.58MHz stable signal. The output signal of the main converter goes to the 3.58MHz BPF. In the 3.58MHz BPF, the conversion noise ($4.21\text{MHz} + 629\text{KHz} = 4.8\text{MHz}$) is rejected and the 3.58MHz color signal goes to the comb filter.

In the comb filter, the crosstalk components due to the adjacent track are eliminated and the color signal is applied to PB-AMP, BURST De-Emphasis, Killer and are applied to LUMA and CHROMA mixer input through the CNC block.




Fig. 14-22 Block Diagram of Color REC mode by the method of a Down Converter




Fig. 14-23 Block Diagram of Color PB mode by the method of a Down Converter

14-12 Hi-Fi Audio

(1) Outline

Hi-Fi circuit consists of HiFi audio LPF,VCO,BPF,FM detect circuit and switching noise compensator, PRE-AMP etc. Linear audio consists of an ALC circuit,REC EQ circuit and a PB EQ circuit.
Hi-Fi and Linear audio share the same input selector,output selector and mute circuit.

1) REC Mode (L-CH Only)




Fig. 14-24 REC Mode (L-CH Only)

2) PB Mode (L-CH Olnty)




Fig. 14-25 PB Mode (L-CH Olnty)

(2) Block Description

1) Input Selector

Input selector outputs 1 signal from 4 different signals received. It outputs 1 selected signal from tuner, rear, front.

2) Normal(Linear) Selector

Two signals, L-CH and R-CH are input to Hi-Fi IC. But, linear audio is capable of receiving only one signal. Therefore, the 2 input signals must be selected. Usually, the outputs are mixed signals of L-CH and R-CH unlike the input selector, the normal selector does not amplify the selected signal.

3) Output Selector

It selects to output Hi-Fi L-CH, Hi-Fi R-CH, LINEAR and MIX(Hi-Fi+LINEAR) signals with the final output IC pin 78 (R-CH) and pin 80 (L-CH).

4) Output ALC(Convertor)

ALC is used because when the input level of RF converter gets bigger, it shows up as noise on the screen. But, this block is not used in this model (ALC OFF).

5) PNR(Peak Noise Reduction)

It is a type of emphasis, de-emphasis function to eliminate noise during modulation / demodulation. PNR operates as that of VHS FORMAT to reduce noise.

6) Audio Limiter

Before modulating the signals from PNR block, it limits signals exceeding the size limit to a maximum deviation of ± 150 KHz.

7) VCO(Voltage Control Oscillation)

It is a modulation function that oscillates 1.3 MHz (L-CH) and 1.7 MHz (R-CH).

8) RF LPF

It is a function to eliminate the harmonic components of Hi-Fi carrier formed during VCO, which may affect other blocks. Its pass-band is approximately 2 MHz.

9) MIXER

It mixes the Hi-Fi carrier formed in L-CH and R-CH. However, due to the frequency difference between L-CH and R-CH, when an equal amount of R-CH is recorded to tape, R-CH is much smaller than L-CH. Therefore, the R-CH output is approximately 10 dB bigger than L-CH.

10) Current Amp

It is the final amplifier of the mixed Hi-Fi carrier. IC pin 28's resistance controls current, which changes the size of IC pin 26.

11) AGC(Auto Gain Control)

It maintains uniform size of Hi-Fi envelope, which is input by pre-amp in play back mode.

12) BPF(Band Pass Filter)

L-CH and R-CH each has BPF. The center frequency is same as carrier frequency. It is used to receive only Hi-Fi carrier from all signals input to pre-amp.

13) SW Noise Compensation

Unlike the linear audio, instead of using fixed head, drum heads are used, which creates halting points. However, in order for the audio to be headed continuously, the damages from halting points are modulated, which creates noise. SW noise compensation is a block to minimize this particular noise.

14) Hold Pulse

It makes standard signal(Pulse) to compensate SW noise.

15) DET(Hi-Fi/LINEAR)

From the Hi-Fi envelope inputted from pre-amp, it decides whether the signal passing through L-CH BPF is Hi-Fi or LINEAR tape. If its size (the signal passing through BPF is below 10mVpp, it is not Hi-Fi, therefore, it outputs linear)

16) DOC(Drop Out Compensation)

If demodulation is conducted without properly treating the damage on Hi-Fi envelope caused by scratch on the tape, noise occurs. In order to improve this noise occurrence, DO DET compensates the drop-out using the same method of compensating the switching noise when the damage on the envelope ranges 10~15mVpp.

17) ENV DET

To obtain optimal tracking, envelope must be peak to peak and micom should be in DC. It is a function to convert Hi-Fi envelope to DC. If it is lower than 0.8V at micom, it sends linear mode data to HiFi IC.

18) Serial Data Decoder

It receives IIC BUS to enable the operation of inner block and decodes into serial data.

(3) Pin Port Description (Tuner Mode ; 1KHz, 100% Modulation Input)

PIN NO.	PIN NAME	DC VOLT.	SIGNAL	REMARK
1	LINE MUTE	0 / 5	-	Reduce the line out noise.
2	Linear out to TM	4.2 V	-17 dbm	Converter Model Only
3	Vcc 9V	9 V		Power Supply for in/out Select
4	Linear Input	2.5 V	- 28.2 dBV	Audio from A/V IC
5	Vcc 5V	5 V		Power Supply for in/out Select
6	Linear out to A/V	2.5 V	-21.5 dBV	Audio out to A/V IC
7	EXT1-INPUT (L)	0	-28.2 dBV	Line Input 1 (FRONT)
8	ALC Detector	-		ALC Detector for RF converter
9	EXT2-INPUT (L)	0	-28.2 dBV	Line Input 2 (REAR)
10	GND	-		
11	EXT3-INPUT (L)	0	-28.2 dBV	Line Input 3 (DVD)
12	Monitor Input (L)	2.5 V		DVD Audio (L) Input
13	Input changeover switch output (L)	2.2 V	-21 dBV	PB/REC sitch output . Transform R/P signals into DC.
14	ALC Input (L)	2.5 V	-21 dBV	ALC Input Terminal
15	Vcc 5V	5 V		Power Supply for in/out Select
16	1/2 Vcc	2.5 V		1/2 Vcc Terminal
17	Rec Mute Terminal	0 V		GND (Not in use)
18	NR Waiting Det	-	-	Terminal for waiting dector
19	NR Waiting Filter	2.5 V		NR Waiting Filter 1 For L-CH
20	NR Waiting Filter	2.5 V		NR Waiting Filter 2 For L-CH
21	CCA Reference			CCA Reference for L-CH
22	NR Empha			NR Empahasis for L-CH
23	Tracking DC out	0 ~ 5 v		Hi-Fi Env Det Level Output
24	Audio Pb FM1	2 V / 4 V		Audio Playbak FM 1 input (H)
25	GND			Hi-Fi PRE-AMP GND
26	REC Current OUT			Rec current out to Head
27	Audio Pb FM2	2 V / 4 V		Audio Playbak FM 2 input (L)
28	Crrent adjust	2.4 V		Rec Current adjust point
29	Alc detector			ALC detection
30	Hi-Fi detector			Hi-Fi/ Normal detect
31	Monitor	2.5 V		FM Monitor
32	Vcc 5V	5 V		Power Supply for Hi-Fi
33	Pb FM Out	2.5 V		Output of H'D Amp in PB Mode
34	Pb FM Input	-	350 mVp-p	Input of FM in PB Mode
35	GND			GND FOR LOGIC
36	Vcc 5V	5 V		Power Supply for LOGIC
37	Serial data input	0 / 5 V		
38	Serial clock input	0 / 5 V		
39	Audio head s/w	0 / 5 V		Head s/w 30 hz input
40	Mts Mode out			1V : mo / 2V : St / 3V : Bi

PIN NO.	PIN NAME	DC VOLT.	SIGNAL	REMARK
41	CCA Reference			CCA Reference for R-CH
42	NR Empha			NR Empahasis for R-CH
43	NR Waiting Filter	2.5 V		NR Waiting Filter 2 For R-CH
44	NR Waiting Filter	2.5 V		NR Waiting Filter 1 For R-CH
45	NR Waiting Det	-	-	Terminal for waiting dector
46	Vcc 5V	5 V		Power Supply for in/out Select
47	ALC Input (R)	2.5 V	-21 dBV	ALC Input Terminal
48	Input changeover switch output (R)	2.2 V	-21 dBV	PB/REC sitch output . Transform R/P signals into DC.
49	Mute Control			
50	GND			GND FOR ANALOGE
51	FSC IN		200 mVp-p	3.58 Mhz input
52	DC Reg	1.2 V		Bandgap Power supply for MTS
53	Stereo PLL filter	3.8 V		LPF for Stereo PLL
54	Vcc 5V	5 V		Power Supply for MTS Select
55	Pilot Canceller f	3.8 V		CTL Pin of cancel signal for pilot C.
56	FM Filter			Filter for making stable dc
57	SIF Input			SIF Audio input from TM Block
58	REG Filter	4.5 V		Filter of reference voltage source.
59	Filter Auto Adjust	3.8 V		Loof filterof PLL for auto adj
60	Pilot Det Filter	3.8 V		Detection for pilot detection circuit
61	PC_DC_MO	3.3 V		Absorbing the DC offset
62	PCDOUT	3.8 V		Absorbing the DC offset
63	PCDIN	3.8 V		Absorbing the DC offset
64	PCDBXIN	2.6 V		Absorbing the DC offset
65	Main V/I convert	3.8 V		Converting the voltage of signal
66	SPE Det V/I convert	3.8 V		Connecting pin of smooth capacity of detection circuit.
67	Spectral DET			Converting the voltage of signal
68	Wide Band Det			Connecting pin of smooth capacity of detection circuit.
69	EXT1-INPUT (R)	0	-28.2 dBV	Line Input 1 (FRONT)
70	GND			GND FOR MTS
71	EXT2-INPUT (R)	0	-28.2 dBV	Line Input 2 (REAR)
72	Wid det V/I convert	3.8 V		Converting the voltage of signal
73	EXT3-INPUT (R)	0	-28.2 dBV	Line Input 3 (DVD)
74	Monitor Input (R)	2.5 V		DVD Audio (R) Input
75	PCDCOSPE			Absorbing the DC offset
76	PC_OUT_DBX	3.3 V		Absorbing the DC offset
77	LINE MUTE (R)	0 / 5	-	Reduce the line out noise.
78	Line out (R-CH)			
79	GND			GND FOR AUDIO
80	Line out (L-CH)			

14-13 Linear Audio

(1) Block Diagram




Fig. 14-26 Block Diagram

(2) Block Description

1) ATT (Attenuation)

Line amp is shared between PB mode and E/E mode, which reduces the recorded signal by 20dB and resistor.

2) ALC (Auto Level Control)

If the signal level is lower than the reference signal (-6dBm) level, the output signal will equal the input signal. However, if the input signal is higher than the reference signal, the output will not equal the input and will generate uniform signal.

* ALC Application Purpose : Since linear audio is in AM (amplitude modulation) and uses magnetic recording device, it only records limited size and as the size of input signal increases, distortion increases. To prevent this occurrence, make sure the signal does not get bigger even if the level of distortion repeatedly increases.

3) LINE AMP

Line amp's gain is approximately 23dB. The purpose of the line amp is to amplify to 68dB in order to obtain the recorded signal on the tape during playback. As the amp gain increases, the passband decreases, which enables the amplification of low frequency. However, it is impossible to amplify frequency of 10KHz to 68dB with just 1 OPAMP. Therefore, to satisfy frequency and gain.

Line amp must be constructed into 2 steps of OP AMP. (gain is fixed within IC)

4) 12KHz LPF

There are various noises to signal output. The loudest noise is the "Video SYNC Frequency" of 15.734KHz. In order to eliminate the "Video SYNC Frequency", "LPF" and "TRAP" are combined to "LPF".

5) PB AMP




Fig. 14-27 PB Amp

The diagram to the left is the playback amp and the gain input/output are as follows.

$$A_v = 1 + \frac{Z_1}{Z_2} \approx \frac{Z_1}{Z_2}$$

The playback characteristic of VHS format can be satisfied by using Z_1 , Z_2 in the above equation.

PB amp gain should be designed to be approximately 45dB (1KHz).

6) REC AMP




Fig. 14-28 REC Amp

The diagram to the left is REC AMP. The amp gain is approximately 14dB.

R_1 and R_2 that determine the gain is located inside the IC.

It is uniform and independent to frequency. Frequency characteristics should be considered when designing rec amp. The REC amp should be the opposite to playback characteristics.

7) OSC (Oscillation)

Oscillation frequency is 70KHz. It's size is approximately 45Vp-p. it operates on recoed mode. It is supplied to audio erase head and full erase head used to erase already recorded signals.

Also, it conducts "AM (Amplitude Modulation)" using oscillation signals.

8) BIAS Control

Oscillation coil is used in oscillation Bias. Coil output changes according to the impedance of F/E, A/E and R/P head connected to the coil.

9) 60KHz HPF

There must be standard signal for bias control and that signal uses HPF only to obtain oscillation signal that comes through R/P head.

10) S/W

The switch opens when recording, shorts during playback and exterior transistor is used.

(3) Pin Port Description (IC301 ; LA71207M)

PIN NO.	PIN NAME	DC VOLT.	SIGNAL	REMARK
9	REC OUT	2.3	-2dBm	REC AMP OUTPUT (GAIN ; 14dB)
75	GND	0	-	
6	BIAS	REC:2.3 PB:0	70KHz+1KHz MIX 3Vp-p	It is grounded due to the switch inside of IC during playback. During recording, it operates on 60KHz input HPF
11	BIAS CTL	REC:4.3V PB:5V	-	The BIAS CTL voltage change depends on the external TR.
6	PB EQ (+)	2.3	-	PB EQ AMP INPUT (+)
5	PB EQ (-)	2.3	-	PB EQ AMP INPUT (-)
7	PB EQ SW	2.3	-	PB EQ AMP SLP SW
3	PB EQ OUT	2.3	-32dBm	PB EQ AMP OUTPUT
2	LINE PB IN	2.3	-32dBm	LINE AMP INPUT (PB)
58	A.MUTE	0	-	Operates at HIGH (5V)
76	INPUT 1	2.3	-27dBm	AUDIO INPUT : -27dBm
78	INPUT 2	2.3	-27dBm	AUDIO INPUT : -27dBm
1	Vref Filter	2.3	-	
80	Input 3	2.3	-27dBm	AUDIO INPUT : -27dBm
77	Vcc	5.0	-	
10	Line Out	2.3	-4dBm	AUDIO OUTPUT : -4dBm
79	ALC IN	2.3	-13dBm	ALC level selector

14-14 TM

(1) Outline

RF and frequency synthesized tuning system

General description : The receiving circuit consists of both ANT input and output circuits, channel selection circuit, PIF circuit and SIF circuit. The receiving circuit selects a desired broadcast signal from TV signals induced on an antenna and sends stable video and audio signals to their respective processing circuits.

(2) Tuner modulator block

As explained, this model is designed in one package to contain a RF MODULATOR BLOCK, TUNER BLOCK AND IF DEMODULATOR BLOCK. Its size is greatly reduced and other noise interference can be minimized to make performance high.




Fig. 14-29 Tuner/demodulator Block Diagram

(3) Tuner Block

A. Low pass filter & high pass filter

This consists of IF trap circuit and UHF & VHF separation circuit. If the input signal is IF(45.75MHz), this filter prevents interference.

B. Single tune & RF AMP

This consists of a filter circuit, RF AMP, impedance conversion circuit, image trap and a single tuning circuit. It prevents noise and other interference signals. RF AMP is controlled by AGC come from IF DEMOD block.

C. Double tune

It consists of a double tuning circuit to improve rejection characteristic which results in a better band characteristic.

D. MOP IC (Mixer, OSC, PLL)

It consists a VHS and UHF OSC and mixer circuit. We applied a double balance mixer to have better rejection characteristic, it shows especially various beat characteristic.

It selects channels and contains charge pump band driver. The minimum step standard frequency 31.25KHZ.




Fig. 14-30 Tuner Section Block Diagram

(4) IF Block**A. SAW FILTER**

It passes only needed band of the signal that is converted to IF frequency and decrease other band to minimize the effect of adjacent channel.

B. IF AMP

IF signal, which is selected in SAW FILTER, is amplified in IF amp frequency enough to be detected. The IF AMP has parallel inputs & outputs structure and consists of 3 series step AMP. Each step has about 20dB gains. These gains are controlled by AGC voltage has maximum 63dB attenuation range.

C. RF AGC CONTROL

It is adjusted to determine RF AGC working point in tuner.

D. FM DETECTOR

After removing AM signal in the limiter AMP, amplified SIF signal is applied FM detector. This FM detector is PLL detecting type.

E. AFT DETECTOR

AFT automatically controls the OSC frequency in the tuner, so that it retains a constant level.

It is a quadrature detection type. The carrier, which is detected from video det is directly input to AFT detector. The 90 degree delayed phase signal is input at the same time to AFT detector and, the results come out. Detected AFT voltage is amplified by DC AMP and then applied to pin 13.




Fig. 14-31 IF Ssection Block Diagram

14-15 OSD

The on screen display circuit consist of a character generator decoder, video mixer, sync separator and sync generator, sync detector circuit.

The data is decoded and generates characters in syncro with composite video signal applied pin 49, 50.

Also the sync detector circuit discriminates the presence of a video signal by detecting sync, if no sync is detected, a blue screen is displayed. In other word, the OSD circuit displays character on the video when there is a video signal or on blue screen when there is no video signal. (No sync).




Fig. 14-32 Block Diagram

MEMO

TOSHIBA CORPORATION

1 1, SHIBAURA 1 CHOME, MINATO KU, TOKYO 105 8001, JAPAN

TOSHIBA

FILE NO. 810-200550

SERVICE MANUAL



DVD RECORDER & VCR

D-VR15SB

D-VR25SB

D-VR35SB

D-VR30SF

D-VR30SG




Issued in Japan., June., 2005 ©


9. Block Diagrams

9-1 All Block Diagram- - - - -	9-2
9-2 AIC1(PCM1753) Audio DA Block Diagram - - - - -	9-3
9-3 AIC9(PCM1802) Audio AD Block Diagram - - - - -	9-4
9-4 DIC1(DMN8602) A/V Codec Block Diagram- - - - -	9-5
9-5 DIC3(29DL323) Flash Memory Block Diagram - - - - -	9-6
9-6 IC801(TEA6425)Typical Application Block Diagram - - - - -	9-7
9-7 TIC1(TW9909) Video Decoder Block Diagram - - - - -	9-8
9-8 U23(M13S128168A) DRAM Block Diagram- - - - -	9-9


9-1 All Block Diagram




9-2 AIC1(PCM1753) Audio DA Block Diagram



9-3 AIC9(PCM1802) Audio AD Block Diagram




9-4 DIC1(DMN8602) A/V Codec Block Diagram







9-6 IC801(TEA6425)Typical Application Block Diagram



9-7 TIC1(TW9909) Video Decoder Block Diagram




9-8 U23(M13S128168A) DRAM Block Diagram



MEMO

10. Wiring Diagram




MEMO

11. PCB Diagrams


11-1 VCR Main PCB-	11-2
11-2 DVD Main PCB	11-4
11-3 Jack PCB	11-6
11-4 Function PCB	11-8

11-1 VCR Main PCB

COMPONENT SIDE




CONDUCTOR SIDE




11-2 DVD Main PCB


COMPONENT SIDE




CONDUCTOR SIDE



11-6




CONDUCTOR SIDE




11-4 Function PCB

COMPONENT SIDE



CONDUCTOR SIDE



12. Schematic Diagrams

◆ Block Identification of Main PCB - - - - -	12-2	12-18 Audio Rca Output (Jack PCB) - - - - -	12-20
12-1 S.M.P.S (VCR Main PCB)- - - - -	12-3	12-19 Video Amp (Jack PCB) - - - - -	12-21
12-2 Power (VCR Main PCB) - - - - -	12-4	12-20 VPS/PDC (Jack PCB)- - - - -	12-22
12-3 Secam (VCR Main PCB) - - - - -	12-5	12-21 Front Input (Jack PCB) - - - - -	12-23
12-4 A/V (VCR Main PCB) - - - - -	12-6	12-22 Connection (Jack PCB) - - - - -	12-24
12-5 Hi-Fi (VCR Main PCB) - - - - -	12-7	12-23 TM (Jack PCB)- - - - -	12-25
12-6 E-Timer (VCR Main PCB) - - - - -	12-8		
12-7 OSD (VCR Main PCB) - - - - -	12-9		
12-8 System Control / Servo (VCR Main PCB) - - - - -	12-10		
12-9 Audio In/Out (DVD Main PCB) - - - - -	12-11		
12-10 Connector (DVD Main PCB) - - - - -	12-12		
12-11 DDR (DVD Main PCB) - - - - -	12-13		
12-12 DMN9602 (DVD PCB)- - - - -	12-14		
12-13 IEEE1394 (DVD PCB) - - - - -	12-15		
12-14 Video Decoder (DVD PCB) - - - - -	12-16		
12-15 A/V MUX (Jack PCB) - - - - -	12-17		
12-16 A2/NICAM (Jack PCB) - - - - -	12-18		
12-17 Scart (Jack PCB)- - - - -	12-19		

Note

For schematic Diagram
- Resistors are in ohms, 1/8W unless otherwise noted.


Special note :

Most semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.


Note :

Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list (may be slightly different or amended since this drawing was prepared).


Important safety notices :

Components identified with the mark  have the special characteristics for safety. When replacing any of these components. Use only the same type.

◆ Block Identification of Main PCB





12-1 S.M.P.S (VCR Main PCB)






12-3 Secam (VCR Main PCB)




CN02
33P
CN02B WAFER







12-6 E-Timer (VCR Main PCB)











12-10 Connector (DVD Main PCB)




12-11 DDR (DVD Main PCB)

TERMINATION AT E5. 1


TERMINATION AT DDR




12-12 DMN9602 (DVD PCB)




12-13 IEEE1394 (DVD PCB)




12-14 Video Decoder (DVD PCB)



12-15 A/V MUX (Jack PCB)



12-16 A2/NICAM (Jack PCB)











12-20 VPS/PDC (Jack PCB)




12-21 Front Input (Jack PCB)





12-23 TM (Jack PCB)



MEMO